

User's Manual

Models UT550 / UT520

Digital Indicating Controllers

User's Manual for Single-loop Control

NEW GREEN SERIES

IM 05D01C02-01E

Installation

2nd Edition: Jul 1, 2001

YOKOGAWA
Yokogawa M&C Corporation

This manual describes installation, wiring, and other tasks required to make the controller ready for operation.

Contents

- Safety Precautions
- Model and Suffix Codes
- How to Install
- How to Connect Wires
- Hardware Specifications
- Terminal Wiring Diagrams

Introduction

Thank you for purchasing the UT550/UT520 digital indicating controller. The controller is shipped from the factory with 5 hardcopy user's manuals (A2 size) and 1 user's manual on CD-ROM. The 5 user's manuals in hardcopy format describe the operating procedures required for basic use (factory-set to single-loop control mode). It is recommended that you refer to these user's manuals to understand [1] installation, [2] initial settings, and [3] operating procedures of the controller. The CD-ROM contains an User's Manual (Reference) with descriptions of various functions and setting ranges that can be set as necessary. The manual also contains information on operations used to carry out control other than single-loop control. Moreover, the use of an optional parameter setting tool (Model: LL100-E10) allows you to easily perform settings and adjustments with a PC.

How to Use the Manuals

Purpose	Manual Title	Description	Media
Setup	Installation	Describes the tasks (installation, wiring, and others) required to make the controller ready for operations.	A2-size paper, back and front
Basic operation	Initial Settings	Describes examples of setting PV input types, control output types, and alarm types. Making settings described herein allows you to carry out basic control.	A2-size paper, back and front
Operating procedures and troubleshooting	Operations	Describes key operation sequences. For operation control through external contact inputs, see the back of Installation User's Manual.	A2-size paper, back and front
Brief operation	Parameter Map	Contains the parameter map used as a guideline for setting parameters.	A2-size paper, back and front
Function description and setpoint recording	Parameters	Briefly describes the functions of parameters. In addition, each parameter table has a User Setting column, where you can record your setpoints when setting them in the controller.	A2-size paper, back and front
Detailed description of functions	User's Manual (Reference)	Explains more advanced applications than those found in the 5 hardcopy user's manuals (A2 size).	CD-ROM

1. Safety Precautions

The following symbol is indicated on the controller to ensure safe use.

CAUTION

This symbol on the controller indicates that the operator must refer to an explanation in the user's manual in order to avoid the risk of injury or death of personnel or damage to the instrument. The manual describes how the operator should exercise special care to avoid electric shock or other dangers that may result in injury or loss of life.

The following symbols are used in the hardcopy user's manuals and in the user's manual supplied on the CD-ROM.

NOTE

Indicates that operating the hardware or software in a particular manner may damage it or result in a system failure.

IMPORTANT

Draws attention to information that is essential for understanding the operation and/or features of the controller.

2. Model and Suffix Codes

Before using the controller, check that the model and suffix codes match your order.

Model	Suffix Code	Description
UT550		Digital indicating controller (provided with retransmission output and 15 VDC loop power supply as standard)
Type	-0	Standard type
	-1	Position proportional type
	-2	Heating/cooling type
	-3	Standard type (with 24 V DC loop power supply)
	-4	Position proportional type (with 24 V DC loop power supply)
Optional functions	0	None
	1	With communication, remote input, 6 additional DIs and 4 additional DOs
	2	With communication, remote input, and 1 additional DI
	3	With 5 additional DIs and 4 additional DOs
	4	With remote input and 1 additional DI

Model	Suffix Code	Description
UT520		Digital indicating controller (provided with retransmission output and 15 VDC loop power supply as standard)
Type	-0	Standard type
Optional functions	0	None
	7	With communication, remote input, and 2 additional DIs
	8	With remote input and 2 additional DIs

- Check that the following items are provided:
- Digital indicating controller (of ordered model): 1
 - Brackets (mounting hardware): 1 pair
 - Unit label: 1
 - User's Manuals for Single-loop Control: 5 (A2 size)
 - User's Manual (Reference) (CD-ROM Version): 1

Correspondence between the Model and Suffix Codes, and the Contact Input/Output Terminals Provided

Check the model ordered and the presence/absence of contact inputs and outputs in the following table.

✓ indicate that the contacts are available.

Model and Suffix Codes	Contact input terminals								Contact output terminals						
	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8	DO1	DO2	DO3	DO4	DO5	DO6	DO7
UT550-□0	✓	✓							✓	✓	✓				
UT550-□1	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
UT550-□2	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
UT550-□3	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
UT550-□4	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

Note: For details on the functions of contact inputs/outputs, see "Terminal Wiring Diagrams" on the back of the manual.

✓ indicate that the contacts are available.

Model and Suffix Codes	Contact input terminals								Contact output terminals						
	DI1	DI2	DI3	DI4	DI5	DI6	DI7	DI8	DO1	DO2	DO3	DO4	DO5	DO6	DO7
UT520-00	✓	✓							✓	✓	✓				
UT520-07	✓	✓	✓					✓	✓	✓	✓	✓	✓	✓	✓
UT520-08	✓	✓	✓	✓				✓	✓	✓	✓	✓	✓	✓	✓

Note: For details on the functions of contact inputs/outputs, see "Terminal Wiring Diagrams" on the back of the manual.


3. How to Install

NOTE





To install the controller, select a location where:

- no one may accidentally touch the terminals,
- mechanical vibrations are minimal,
- corrosive gas is minimal,
- temperature can be maintained at about 23°C and the fluctuation is minimal,
- no direct radiant heat is present,
- no magnetic disturbances are caused,
- no wind blows against the terminal board (reference junction compensation element),
- no water is splashed,
- no flammable materials are around,

Never place the controller directly on flammable items or equipment. If the controller has to be installed close to flammable items or equipment, be sure to provide shielding panels all around the controller, at least 150mm away from every side; the panels should be made of either 1.43mm-thick metal-plated steel plates or 1.6mm-thick uncoated steel plates.



External Dimensions and Panel Cutout Dimensions




Note: For details on the functions of contact inputs/outputs, see "Terminal Wiring Diagrams" on the back of the manual.

How to Install

CAUTION

Turn off the power to the controller before installing it on the panel because there is a possibility of electric shock.




4. How to Connect Wires

CAUTION

- Before carrying out wiring, turn off the power to the controller and check that the cables to be connected are not alive with a tester or the like because there is a possibility of electric shock.
- Wiring must be carried out by personnel who have basic electrical knowledge and practical experience.

NOTE

- Provide power from a single-phase instrument power supply. If there is a lot of noise in the power line, insert an insulating transformer into the primary side of the line and use a line filter (recommended part: ZAC2205-00U from TDK) on the secondary side. As a countermeasure against noise, do not place the primary and secondary power cables close to each other.
- For thermocouple input, use shielded compensating lead wires for wiring. For RTD input, use shielded wires that have low conductor resistance and cause no significant differences in resistance between the three wires. The cables to be used for wiring, terminal specifications, and recommended parts are as shown below.
- Control output relays may be replaced. However, because they have a life of 100,000 times that of the resistance load, use auxiliary relays to turn on/off a load.
- The use of inductance (L) loads such as auxiliary relays, motors and solenoid valves causes malfunction or relay failure; always insert a CR filter for use with alternating current or a diode for use with direct current, as a spark-removal surge suppression circuit, into the line in parallel with the load.
- When there is possibility of being struck by external lightning surge, use the arrester to protect the instrument.




Cable Specifications and Recommended Cables

Purpose	Name and Manufacturer
Power supply, grounding, relay contact outputs	600 V PVC insulated wires, JIS C 3307, 0.9 to 2.0 mm ²
Thermocouple	Shielded compensating leadwires, JIS C 1610, □X-□-□-□ (See Yokogawa Electric's GS 6B1U1-E.)
RTD	Shielded wires (three conductors), UL2482 (Hitachi Cable)
Other signals	Shielded wires

Recommended Terminal Lugs

Applicable wire size	Tightening torque
0.3 to 1.65 mm ²	0.8 N·m or less



Terminal Covers (Optional parts)

Target Model	Part Number	Sales Unit
For UT550	T9115YD	1
For UT520	T9115YE	1

5. Hardware Specifications

PV Input Signals

- Number of inputs: 1 (terminals ①-③, ④)
- Input type: Universal input system. The input type can be selected with the software.
- Sampling period: Can be selected from 50, 100, 200 and 500 ms.
- Burnout detection: TC, RTD, standard signal
- Functions at 0.4 to 2 V or 1 to 5 V Upscale, downscale, and off can be specified. For standard signal, burnout is determined to have occurred if it is 0.1 V or less.
- Input bias current: 0.05 μA (for TC or RTD b-terminal)
- Measurement current (RTD): About 0.13 mA
- Input resistance: 1 MΩ or more for thermocouple or mV input About 1 MΩ for DC voltage input
- Allowable signal source resistance: 250 Ω or less for thermocouple or mV input Effects of signal source resistance: 0.1 μV/Ω or less 2 kΩ or less for DC voltage input Effects of signal source resistance: About 0.01%/100 Ω
- Allowable wiring resistance: For RTD input Maximum 150 Ω/wire: Conductor resistance between three wires should be equal However, 10 Ω/wire for a maximum range of -150.0 to 150.0°C. Wire resistance effect: ±0.1°C/10 Ω
- Allowable input voltage: ±10 V DC for thermocouple, mV, or RTD input ±20 V DC for DC voltage input
- Noise rejection ratio: 40 dB (50/60 Hz) or more in normal mode 120 dB (50/60 Hz) or more in common mode

Reference junction compensation error: ±1.0°C (15 to 35°C) ±1.5°C (0 to 15°C, 35 to 50°C)

Applicable standards: JIS, IEC, DIN (ITS-90) for thermocouples and RTD

Remote Input Signals

Available only for controllers with remote input terminals

- Number of inputs: 1 (terminals ⑥-⑧)
- Input type: Settable in a range of 0-2, 0-10, 0-4-2.0, or 1-5 V DC
- Sampling period: 100, 200 and 500 ms
- The sampling period of a remote input signal is associated with the PV input's sampling period. If the PV input's sampling period is 50 ms, however, the sampling period of a remote input signal lengthens to 100 ms.
- Input resistance: About 1 MΩ
- Input accuracy: ±0.3% ±1 digit of input span for 0 to 2 V DC ±0.2% ±1 digit of input span for 0 to 10 V DC ±0.375% ±1 digit of input span for 0.4 to 2.0 V DC ±0.3% ±1 digit of input span for 1 to 5 V DC Under standard operating conditions (23±2°C, 55±10% RH, power frequency of 50/60 Hz)

Feedback Resistance Input

Provided for position proportional type only (terminals ⑧-⑩)

- Slide resistance value: 100 Ω to 2.5 kΩ of overall resistance (burnout detection for sliding wire provided)
- Measuring resolution: ±0.1% of overall resistance

Loop Power Supply

Power is supplied to a two-wire transmitter. (15 V DC: terminals ④-⑤; 24 V DC: terminals ④-⑥) A resistor (10 to 250 Ω) connected between the controller and transmitter converts a current signal into a voltage signal, which is then read via the PV input terminal. Supply voltage: 14.5 to 18.0 V DC, max. 21 mA (provided with a protection circuit against a field short-circuit); 21.6 to 28.0 V DC, max. 30 mA (only for models with 24 V DC loop power supply)

Retransmission Output

Either PV, target setpoint, or control output is output. Either the retransmission output or the loop power supply can be used with terminals ④-⑥.

- Number of outputs: 1 or 2 (terminals ④-⑥, terminals ⑥-⑦)
- Output signal: 4-20, 0-20, 20-4, or 20-0 mA DC (where, outputting signal levels of less than 0 mA is not feasible)
- Load resistance: 600 Ω or less
- Output accuracy: ±0.1% of span (±5% of span for 1 mA or less.) under standard operating conditions (23±2°C, 55±10% RH, power frequency of 50/60 Hz)

Control Output

Universal output system. The output type can be selected with the software. Relay contact output(s) for the position proportional type

(Standard type: terminals ④-⑥; heating-side output: terminals ④-⑤, cooling-side output: terminals ⑥-⑦)

Number of outputs	1 or 2 (two for heating/cooling type), switched between a voltage pulse output and current output.
Output signal	4-20, 0-20, 20-4, or 20-0 mA DC
Load resistance	600 Ω or less
Output accuracy	±0.1% of span (±5% of span for 1 mA or less) Under standard operating conditions (23±2°C, 55±10% RH, power frequency of 50/60 Hz)

(Standard type: terminals ④-⑥; heating-side output: terminals ④-⑤, cooling-side output: terminals ⑥-⑦)

Number of outputs	1 or 2 (two for heating/cooling type), switched between a voltage pulse output and current output.
Output signal	On-voltage = 12 V or more (load resistance: 600 Ω or more) Off-voltage = 0.1 V DC or less
Resolution	10 ms or 0.1% of output, whichever is larger

Relay contact output (Standard type: terminals ①-③, heating-side output: terminals ①-②, cooling-side output: terminals ③-④, position proportional type: terminals ⑤-⑥, ⑦)

Number of outputs	1 or 2 points (two for heating/cooling type)
Output signal	Three terminals (NC, NO, and common)
Contact rating	250 V AC or 30 V DC, 3 A (resistance load)
Resolution	10 ms or 0.1% of output, whichever is larger

Contact Inputs

Purpose: Target setpoint selection, remote/local mode switching, and run/stop switching

Number of inputs: Differs with model and suffix codes as shown in the table below.

Model and Suffix Codes	Number of Inputs
UT550-□0	2
UT550-□1	8
UT550-□2	3
UT550-□3	7
UT550-□4	3
UT520-00	2
UT520-07	4
UT520-08	4

- Input type: Non-voltage contact or transistor open collector input
- Input contact rating: 12 V DC, 10 mA or more
- On/off determination: For non-voltage contact input, contact resistance of 1 kΩ or less is determined as "on" and contact resistance of 20 kΩ or more as "off." For transistor open collector input, input voltage of 2 V or less is determined as "on" and leakage current must not exceed 100 μA when "off."
- Minimum status detection hold time: PV input's sampling period × 3

Contact Outputs

Purpose: Alarm output, FAIL output, and others

Number of outputs: Differs with the model and suffix code as shown in the table below.

Model and Suffix Codes	Number of Outputs
UT550-□0	3
UT550-□1	7
UT550-□2	3
UT550-□3	7
UT550-□4	3
UT520-00	3
UT520-07	3
UT520-08	3

Relay contact rating: 240 V AC, 1 A, or 30 V DC, 1 A
Transistor contact rating: 24 V DC, 50 mA

Display Specifications

PV display: 5-digit, 7-segment, red LEDs, character height of 20 mm for UT550 and 12 mm for UT520

Setpoint display: 3-digit and 5-digit, 7-segment, red LEDs, character height of 9.3 mm (for both UT520 and UT550)

Status indicating lamps: LEDs

Safety and EMC Standards


- Safety: Compliant with IEC1010-1: 1990 and EN61010-1: 1992 Approved by CSA1010 CSA1010 installation category: CATH (IEC1010-1) Approved by UL508
- EMC standards: Complies with EN61326. The instrument continues to operate at a measuring accuracy of within ±20% of the range during tests.

6. Terminal Wiring Diagrams


NOTE

Do not use unassigned terminals as relay terminals.


UT550 Standard Type (Model UT550-0□ or UT550-3□), or Heating/Cooling Type (Model UT550-2□), Single-loop Control




UT550 Heating/Cooling Type (Model UT550-2□), Single-loop Heating/Cooling Control



UT550 Position Proportional Type (Model UT550-1□ or UT550-4□), Single-loop Position Proportional Control



UT520 Standard Type (Model UT520-0□), Single-loop Control



4. Setting Control Output Type (Except for a Position Proportional Controller)

The following operating procedure describes an example of changing time proportional PID relay output (0: factory-shipped value) to current output (2).

Control output terminal Values in parentheses are setpoints
 Time proportional PID relay (0)/on-off(3) output..... ①-②-③
 Current PID (2)/time proportional PID voltage pulse (1) output..... ④-⑦
 For details on the output terminals for heating/cooling control, see "6. Terminal Wiring Diagrams" in the **Installation User's Manual**.

- Bring the operating display into view (display appears at power-on).
 Displays PV
 Displays target setpoint-1 "1.SP".
- Press the **[]** key for more than 3 seconds to call up the main menu "MODE".
 Displays symbol "OP.M".
- Press the **[]** key once to display the main menu "STUP".
 Displays main menu "STUP".
- Press the **[]** key once to display the main menu "LOOP1".
 Displays symbol "ST.M".
- Press the **[]** key once to display the main menu "UTMD".
 Displays main menu "UTMD".
- Press the **[]** key once to display the submenu "MD".
 Displays symbol "ST.S".
- Press the **[]** key twice to display the submenu "OUT".
 Displays sub-menu "OUT".
- Press the **[]** key once to display the parameter "OT1" (control output type).
 Displays parameter "OT1".
- Press the **[]** or **[]** key to display the required setpoint. The figure below shows an example of setting to current output (4 to 20 mA DC).
 Blinks during change.
- Press the **[]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
 Displays PV

List of Control Output Types

Parameter Symbol	Name of Parameter	Setpoint	Control Output Types	
ot 1 (OT1)	Control output type	0	Time proportional PID relay contact output (terminals ①-②-③)	
		1	Time proportional PID voltage pulse output (terminals ④-⑦)	
		2	Current output (terminals ④-⑦)	
		3	On/off control relay contact output (terminals ①-②-③)	
		The following 4 to 12 are displayed only for heating/cooling type controllers.		
		4	Heating-side relay output (terminals ①-②-③), cooling-side relay output (terminals ④-⑤)	
		5	Heating-side pulse output (terminals ④-⑦), cooling-side relay output (terminals ④-⑤)	
		6	Heating-side current output (terminals ④-⑦), cooling-side relay output (terminals ④-⑤)	
		7	Heating-side relay output (terminals ①-②-③), cooling-side pulse output (terminals ④-⑦)	
		8	Heating-side pulse output (terminals ④-⑦), cooling-side pulse output (terminals ④-⑦)	
		9	Heating-side current output (terminals ④-⑦), cooling-side pulse output (terminals ④-⑦)	
		10	Heating-side relay output (terminals ①-②-③), cooling-side current output (terminals ④-⑦)	
11	Heating-side pulse output (terminals ④-⑦), cooling-side current output (terminals ④-⑦)			
12	Heating-side current output (terminals ④-⑦), cooling-side current output (terminals ④-⑦)			

5. Calibrating Valve Position (for a Position Proportional Controller Only)

The following operation describes a procedure of inputting a feedback signal from a control valve to calibrate the full closed and full open positions of the valve automatically. To calibrate the valve position, you need to carry out wire connections and bring the controller into manual mode. For connections, see "6. Terminal Wiring Diagrams" in the **Installation User's Manual** and for entering the manual mode, see "8. Switching between AUTO and MAN" in **Operations User's Manual**.

- Bring the operating display into view (display appears at power-on).
 Displays PV
 Displays target setpoint-1 "1.SP".
- Press the **[]** key for more than 3 seconds to call up the main menu "MODE".
 Displays symbol "OP.M".
- Press the **[]** key once to display the main menu "STUP".
 Displays main menu "STUP".
- Press the **[]** key once to display the main menu "LOOP1".
 Displays symbol "ST.M".
- Press the **[]** key once to display the main menu "UTMD".
 Displays main menu "UTMD".
- Press the **[]** key once to display the submenu "MD".
 Displays symbol "ST.S".
- Press the **[]** key three times to display the submenu "VALV".
 Displays sub-menu "VALV".
- Press the **[]** key once to display the parameter "VAT".
 Displays parameter "VAT".
- Press the **[]** key to display "ON".
 Blinks during change.
- Press the **[]** key once. The controller automatically calibrates the valve position (fully open or closed).
 Displays main menu "STUP".
- The controller is viewed as shown below when the valve position is being automatically calibrated.
 The indication "ON" blinks.
- Calibration has ended successfully when the indication changes from "ON" to "OFF". Go to step [14].
 Displays main menu "UTMD".
- Calibration has ended unsuccessfully if the indication changes from "ON" to "ERR". Check the feedback input wiring and carry out automatic calibration again.
 Displays "ERR".
- Press the **[]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
 Displays PV

6. Initializing Parameters

Be sure to follow the steps below after a change of setting has been made to the data item PV Input Type, PV Input Range or PV Input Scale.

- Bring the operating display into view (display appears at power-on).
 Displays PV
 Displays target setpoint-1 "1.SP".
- Press the **[]** key for more than 3 seconds to call up the main menu "MODE".
 Displays symbol "OP.M".
- Press the **[]** key once to display the main menu "STUP".
 Displays main menu "STUP".
- Press the **[]** key once to display the main menu "LOOP1".
 Displays symbol "ST.M".
- Press the **[]** key once to display the main menu "UTMD".
 Displays main menu "UTMD".
- Press the **[]** key once to display the submenu "MD".
 Displays symbol "ST.S".
- Press the **[]** key twice to display the submenu "INIT".
 Displays sub-menu "INIT".
- Press the **[]** key once to display the parameter "INI".
 Displays parameter "INI".
- Press the **[]** key to display "ON".
 Blinks during change.
- Press the **[]** key once. The display momentarily becomes blank (which is normal), indicating the parameters have been initialized.
 The display momentarily becomes blank.
- Press the **[]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
 Displays PV

7. Changing Alarm Type

The following operating procedure describes an example of changing alarm 1 (factory-set to the PV high limit alarm) to the PV low limit alarm. When you have changed alarm type, the alarm setpoint will be initialized; set the alarm setpoint again.

Alarm output terminals Factory-shipped settings
 Alarm-1 (terminal numbers ①-⑦).....PV high limit alarm
 Alarm-2 (terminal numbers ⑧-⑩).....PV low limit alarm
 Alarm-3 (terminal numbers ⑪-⑬).....PV high limit alarm
 Alarm-4 (terminal numbers ⑭-⑯).....PV low limit alarm

- Bring the operating display into view (display appears at power-on).
 Displays PV
 Displays target setpoint-1 "1.SP".
- Press the **[]** key for more than 3 seconds to call up the main menu "MODE".
 Displays symbol "OP.M".
- Press the **[]** key once to display the main menu "STUP".
 Displays main menu "STUP".
- Press the **[]** key once to display the main menu "LOOP1".
 Displays symbol "ST.M".
- Press the **[]** key once to display the submenu "SP".
 Displays sub-menu "SP".
- Press the **[]** key once to display the parameter "ALM".
 Displays parameter "ALM".
- Press the **[]** key once to display the parameter "AL1" (alarm-1 type).
 Displays parameter "AL1".
- Press the **[]** or **[]** key to display the required setpoint. The figure below shows an example of setting the PV low limit alarm.
 Blinks during change.

- Press the **[]** key once to register the setpoint.
 Displays PV
- When setting alarm setpoints, see "5. Setting Alarm Setpoints" in **Operations User's Manual**.
- Press the **[]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).
 Displays PV


List of Alarm Types

The table below shows the alarm types and alarm actions. In the table, codes 1 to 10 are not provided with stand-by actions, while codes 11 to 20 are provided with stand-by actions.

Alarm type	Alarm action	Alarm type code	Alarm type	Alarm action	Alarm type code
No alarm		OFF	Hysteresis		
PV high limit	Hysteresis Open (unit) / Closed (lit) PV Alarm setpoint	1 11	De-energized on deviation low limit alarm	Hysteresis Open (unit) / Closed (unit) Deviation setpoint / Target SP	6 16
PV low limit	Hysteresis Closed (lit) / Open (unit) Alarm setpoint / PV	2 12	Deviation high and low limits	Hysteresis Closed (lit) / Open (unit) Deviation setpoint / Target SP	7 17
Deviation high limit	Hysteresis Open (unit) / Closed (lit) PV Target SP	3 13	Deviation within high and low limits	Hysteresis Closed (lit) / Open (unit) Deviation setpoint / Target SP	8 18
Deviation low limit	Hysteresis Closed (lit) / Open (unit) Deviation setpoint / Target SP	4 14	De-energized on PV high limit	Hysteresis Closed (lit) / Open (lit) PV Alarm setpoint	9 19
De-energized on deviation high limit alarm	Hysteresis Closed (unit) / Open (lit) PV Target SP	5 15	De-energized on PV low limit	Hysteresis Open (lit) / Closed (unit) Alarm setpoint / PV	10 20
Timer function (control stability report event) (Alarm-1 only)	Upward (hour/minute)	21	Sensor grounding alarm	Sensor grounding alarm	25
	Downward (hour/minute)	22	Fault diagnosis output (Note1)	Fault diagnosis output	26
	Upward (minute/second)	23	FAIL output (Note2)	The controller stops when in a FAIL state. The control output is set to "OFF" or "0%" and the alarm output is set to "OFF".	27
SP high limit	Hysteresis Open (unit) / Closed (lit) SP Alarm setpoint	28	Output high limit	Hysteresis Open (unit) / Closed (lit) Output value / Alarm setpoint	30
	Hysteresis Closed (lit) / Open (unit) Alarm setpoint / SP	29	Output low limit	Hysteresis Closed (lit) / Open (unit) Alarm setpoint / Output value	31

Note 1: The fault diagnosis output turns on in case of input burnout, A/D converter failure, or reference junction compensation (RJC) failure. For input burnout or A/D converter failure, the control output is set to the setpoint of the Preset Output Value operating parameter (PO).

Note 2: The FAIL output is on during normal operation and turns off in case of failure.



8. Description of Multiple Setpoints and PID

The UT550/UT520 has a maximum of eight target setpoints, and has PID for each of these setpoints. The following shows the correspondence between the target setpoint numbers (SPN), target setpoints (SP), and PID parameters. For example, if you have set "2" to the target setpoint number (SPN), the control parameters available are target setpoint (2.SP), proportional band (heating-side proportional band) (2.P), integral time (heating-side integral time) (2.I), derivative time (heating-side derivative time) (2.D), cooling-side proportional band (2.Pc), cooling-side integral time (2.Ic), and cooling-side derivative time (2.Dc).

To use multiple target setpoints, see the table below to check the corresponding parameters.

Target setpoint number (SPN)	Target setpoint (SP)	PID parameter					
		Proportional band (heating-side proportional band)	Integral time (heating-side integral time)	Derivative time (heating-side derivative time)	Cooling-side proportional band	Cooling-side integral time	Cooling-side derivative time
SPN=1	1.SP	1.P	1.I	1.D	1.Pc	1.Ic	1.Dc
SPN=2	2.SP	2.P	2.I	2.D	2.Pc	2.Ic	2.Dc
SPN=3	3.SP	3.P	3.I	3.D	3.Pc	3.Ic	3.Dc
SPN=4	4.SP	4.P	4.I	4.D	4.Pc	4.Ic	4.Dc
SPN=5	5.SP	5.P	5.I	5.D	5.Pc	5.Ic	5.Dc
SPN=6	6.SP	6.P	6.I	6.D	6.Pc	6.Ic	6.Dc
SPN=7	7.SP	7.P	7.I	7.D	7.Pc	7.Ic	7.Dc
SPN=8	8.SP	8.P	8.I	8.D	8.Pc	8.Ic	8.Dc

This manual describes key entries for operating the controller. For operations using external contact inputs, see "6. Terminal Wiring Diagrams" in **Installation User's Manual**. If you cannot remember how to carry out an operation during setting, press the key for more than 3 seconds. This brings you to the display (operating display) that appears at power-on.

Contents


1. Monitoring-purpose Operating Displays Available during Operation
2. Setting Target Setpoint (SP)
3. Performing/Canceling Auto-tuning
4. Setting PID Manually
5. Setting Alarm Setpoints
6. Selecting Target Setpoint Numbers (SPN)
7. Switching between Run and Stop
8. Switching between AUTO and MAN
9. Manipulating Control Output during Manual Operation
10. Switching between Remote (REM) and Local (LCL)
11. Troubleshooting

1. Monitoring-purpose Operating Displays Available during Operation

The monitoring-purpose operating displays available during operation are roughly classified into two groups depending on the types of controller and control output. One group is operating displays for standard and position proportional controllers and the other group is operating displays for a heating/cooling controller.


Operating Displays for Standard and Position Proportional Controllers

- **SP Display**
The PV input value appears on the PV display. The target setpoint (1.SP) appears on the Setpoint display. (can be changed)
- **OUT Display**
The PV input value appears on the PV display. The control output value (OUT) appears on the Setpoint display. (can be changed in MAN mode) When in position proportional control, the Setpoint display shows the valve opening (0% to 100%).
- **PID Number Display**
The PV input value appears on the PV display. The PID number (PID) being used appears on the Setpoint display.




Operating Displays for a Heating/Cooling Controller

- **SP Display**
The PV input value appears on the PV display. The target setpoint (1.SP) appears on the Setpoint display. (can be changed)
- **Heating/Cooling OUT Display**
The PV input value appears on the PV display. The heating and cooling sides control output value (C.H) appears on the Setpoint display. (can be changed in MAN mode)
- **PID Number Display**
The PV input value appears on the PV display. The PID number (PID) being used appears on the Setpoint display.



2. Setting Target Setpoint (SP)


The following operating procedure describes an example of setting 150.0 to a target setpoint. In automatic operation, the controller starts control using set target setpoints.



3. Performing/Canceling Auto-tuning


Auto-tuning should be carried out after setting a target setpoint (SP). Make sure the controller is in automatic operation mode (AUTO) and in running state (RUN) before carrying out auto-tuning. See "8. Switching between AUTO and MAN," to change to AUTO and "7. Switching between Run and Stop," to change to Run.

- NOTE**
- When on-off control is being used, auto-tuning cannot be carried out. Moreover, do not perform auto-tuning when controlling any of the following processes.
- Control processes with quick response such as flow control or pressure control
 - Processes where even temporary output on/off results in inconvenience
 - Processes where a large output change at control element results in inconvenience
 - Processes where variations in PV may exceed an allowable range, adversely affecting product quality



4. Setting PID Manually


If you know the values to be set or if suitable PID constants cannot be obtained by auto-tuning, follow the procedure below to set values.



5. Setting Alarm Setpoints


The following operating procedure describes an example of setting 160.0 to alarm-1 setpoint. Check alarm type before setting the alarm setpoint.

When changing the alarm type, see "7. Changing Alarm Type," in **Initial Settings User's Manual**.




6. Selecting Target Setpoint Numbers (SPN)

The following operating procedure describes an example of changing a target setpoint number (SPN) from 1 to 2.




7. Switching between Run and Stop

Switching between the Run state (RUN) and Stop state (STOP) can be made with contact input 2 (DI2). (Factory-set default)



When the controller is stopped, input and outputs are as follows:

PV input	Displays the PV value.
Control output	Provides the preset output value (factory-set to 0%).
Alarm output	Turns the output on in case of an alarm.




* Switching the target setpoint number (SPN) in STOP allows any preset output value (n.PO) to be switched. The "n" is same as the target setpoint number.

8. Switching between AUTO and MAN



NOTE

If AUTO and MAN have been switched using contact input, when the contact input is ON, switching between AUTO and MAN cannot be achieved by keystroke.




9. Manipulating Control Output during Manual Operation



NOTE


Control output cannot be changed if the controller is stopped. In this case, the preset output value (operating parameter PO) will be output. In heating / cooling control, the heating-side preset output value (operating parameter PO) and cooling-side preset output value (operating parameter Oc) will be output.

A control output value is linked with a display value (changed using the key). Note that the control output changes as displayed without requiring the key.



Manipulating the Control Output during Heating/Cooling Control

Showing the Heating/Cooling OUT display.




Controller behavior and control output manipulation when the dead band is positive

The following is an example when the DB parameter is set at 12.4%. If you hold down the key with the heating-side output under manipulation (i.e., cooling-side output C = 0.0%), the heating-side output (H =) decreases.

Consequently, both the heating-side and cooling-side outputs change to 0.0%. If you keep the key held down longer, you enter the state of manipulating the cooling-side output, and its value begins to increase.


Inversely, if you hold down the key with the cooling-side output under manipulation (i.e., heating-side output H = 0.0%), the cooling-side output (C =) decreases. Consequently, both the heating-side and cooling-side outputs go to 0.0%. If you keep the key held down longer, you enter the state of manipulating the heating-side output, and its value begins to increase.



Controller behavior and control output manipulation when the dead band is negative

The following is an example when the DB parameter is set at -12.4%.

If you hold down the key with the heating-side output under manipulation (i.e., cooling-side output C = 0.0%), the heating-side output (H =) decreases. If the output H falls below 24.8%, the cooling-side output C begins to increase from 0.0%. If you keep the key held down longer and the output C rises above 24.8%, the output H goes to 0.0% and you enter the state of manipulating the cooling-side output.




Manipulating the Control Output during Position Proportional Control

The controller continues to provide control output as long as the key or key is being pressed.

key: Closes the valve.

key: Opens the valve.



Note: Manual output is not limited to output high limit(OH) and output low limit(OL).



10. Switching between Remote (REM) and Local (LCL)

The following operating procedure describes an example of switching from Local (LCL) to Remote (REM).

Switching between REM and LCL is possible for only controllers with remote input.


- Local: Performs control using target setpoints set in the controller.
- Remote: Performs control using external analog signals as target setpoints.

Note: The PID group number when the controller is in Remote operation is the same as the number set in the Target Setpoint Number (SPN) parameter.



NOTE


If Remote state is achieved by external contact input (contact input is ON), switching between REM and LCL cannot be achieved by keystroke.



11. Troubleshooting

Troubleshooting Flow

If the operating display does not appear after turning on the controller's power, follow the measures in the procedure below. If a problem appears complicated, contact our sales representative.



IMPORTANT

Take note of the parameter settings when asking the vendor for repair.

Errors at Power On

The following table shows errors that may be detected by the fault diagnosis function when the power is turned on.


Error indication (on PV display unit)	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy
E000 (E000)	Faulty RAM	None	0% or less or OFF	OFF	0% or less	Stopped	Faulty Contact us for repair.
E001 (E001)	Faulty ROM	None	0% or less or OFF	OFF	0% or less	Stopped	
E002 (E002)	System data error	Undefined	Normal action (out of accuracy)	Undefined	Undefined	Normal action (out of accuracy)	
PV decimal point blinks	Faulty calibration value	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Check and set the initialized parameters.
Error code (Note) (See description below.)	Parameter error	Normal action	0% or less or OFF	Normal action	Normal action	Normal action	

Note: An error code is displayed on the setpoint display unit.

An error code is displayed in the event of an error, according to its type. An error code is a two-digit figure in which a combination of 6 bits of on and off is converted into a decimal number. The following shows the relationship between each bit and parameter to be checked for abnormality.

Bit No.	6	5	4	3	2	1	0
Parameter to be checked	Operation mode/output	Operating parameters	Setup parameters	Range data	UT mode	-	Calibration data

For example, if an error occurs with the operating parameter and calibration data, the error code will be as follows:



Possible Errors during Operation

The following shows possible errors occurring during operations.

Error indication (on PV display unit)	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy
Displays "RJC" and PV alternately	RJC error	Measured with RJC=OFF	Normal action				Faulty Contact us for repair.
Decimal point of item part in SP display unit blinks.	EEPROM error	Normal action					
E300 (E300)	ADC error	105%	In AUTO: Preset value output In MAN: Normal action		Normal action		Check wires and sensor.
baUt (B.OUT)	PV burnout error	Dependent on the BSL parameter Up-scale: 105% Down-scale: -5%					
oHEr (OVER) or -aHEr (-OVER)	Excessive PV Out of -5 to 105%	-5% or 105%	Normal action	Normal action		Normal action	Check process.
E200 (E200)	Auto-tuning failure (Time-out)		Action with PID existing before auto-tuning				
Setpoint display	Feedback resistor breakdown	Normal action	Stopped		Stopped		Check the feedback resistor.
Left end of SP display unit blinks.	Faulty communication line		Normal action		Normal action		
Decimal point at right end lights.	Runaway (due to defective power or noise)	Undefined	0% or less or OFF	OFF	0% or less	Stopped	Faulty if power off/on does not reset start the unit. Contact us for repair.
All indications off	Power off	None					

Remedies if Power Failure Occurs during Operations

The operation status and remedies after a power failure differ with the length of power failure time:

- Instantaneous power failure of 20 ms or less: A power failure is not detected. Normal operation continues.
- Power failure of about 2 seconds or less: The following show effects caused in "settings" and "operation status."

Alarm action	Continues. Alarm with standby function will enter standby status.
Setting parameter	Set contents of each parameter are retained.
Auto-tuning	Cancelled.
Control action	Action before power failure continues.

- Power failure of more than about 2 seconds: The following show effects caused in "settings" and "operation status."

Alarm action	Continues. Alarm with standby function will enter standby status.
Setting parameter	Set contents of each parameter are retained.
Auto-tuning	Cancelled.
Control action	Differs with setting of setup parameter "R.MD" (restart mode).
	R.MD setting Control action after recovery from power failure
CONT	Continues action before power failure. (Factory-set default) For position-proportional type, when V.MD = Valve position estimating type, starts action from 0%.
MAN	Outputs preset output value (PO) as control output and continues action set before power failure in MAN mode. For position-proportional type, when V.MD = Valve position feedback type, starts action from feedback input condition at recovery from power failure. When V.MD = Valve position estimating type, starts action from 0%. For heating/cooling control, starts action from heating-side output value and cooling-side output value of 50% of control computation output.
AUTO	Outputs preset output value (PO) as control output and continues action set before power failure in AUTO mode. For position-proportional type, when V.MD = Valve position feedback type, starts action from feedback input condition at recovery from power failure. When V.MD = Valve position estimating type, starts action from 0%. For heating/cooling control, starts action from heating-side output value and cooling-side output value of 50% of control computation output.

Troubleshooting When the Controller Fails to Operate Correctly

If your control tasks are not successful, check the preset parameters and controller wiring before concluding the controller to be defective. The following show some examples of troubleshooting you should refer to in order to avoid the possibility of other problems.

The controller does not show the correct measured input (PV).

- The UT550/UT520 controllers have a universal input. The type of PV input can be set/changed using the parameter "INI1". At this point, the controller must be wired correctly according to the selected type of PV input. Check the wiring first if the controller fails to show the correct PV value. To do this, refer to **Initial Settings User's Manual**. With the parameters "RH1", "RL1", "DP1", "SH1" and "SL1", it is possible to scale the input signal and change its number of decimal places. Also check that these parameters are configured correctly.

The controller does not provide any control output or the control output does not change at all.




- The UT550/UT520 controllers have a universal output. The type of control output can be set/changed using the parameter "OT1". At this point, the controller must be wired correctly according to the selected type of control output. Check the wiring first if the controller provides no control output. To do this, refer to "6. Terminal Wiring Diagrams," in **Installation User's Manual**. With the parameters "OH" and "OL", it is possible to set/change the high and low limits of control output. The control output may not change at all, however, because of restrictions on these parameters. Also check the restrictions on these parameters.

- The control output can only be changed when the controller is in the MAN mode. If the MAN lamp is off (i.e., the controller is in the AUTO mode), you cannot change the control output using key operation.

The control output does not change soon after the target setpoint (SP) has been changed.

- If this happens, check the setpoint of the parameter "MOD". In cases where fixed-point control is selected as the PID control mode (MOD = 1), tracking based on the I-term works to prevent the control output from changing suddenly even if the target setpoint SP is varied. The control output therefore may appear to be working incorrectly at first; however it gradually adapts itself to the new target setpoint.

Setup Parameter Setting Display



NOTE

Changing the registered value of a setup parameter may cause the registered value of an operating parameter to be initialized automatically. Thus, when you have changed a setup parameter, always check that the registered value of the operating parameter is appropriate. If it is initialized to default, reset it to the required value.

This manual describes the functions of parameters briefly. In addition, each parameter table has a "User Setting" column, where you can record your setpoints when setting them in the controller.

* Parameters relating to PV or setpoints should all be set in real numbers. For example, use temperature values to define target setpoints and alarm setpoints for temperature input.

Operating Parameters

Operation Mode Parameters

Located in: Main menu = **MODE** (MODE)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
nod (MOD)	Remote/Local switching	Set to "Local" when carrying out control using the target setpoints of the controller or to "Remote" when using target setpoints acquired via a remote input signal or communication. Use the setup parameter RMS, "Remote Input Selection," to determine whether the target setpoints should be acquired via the remote input signal or communication. REM: Remote mode LCL: Local mode	LCL		
nod (MOD)	Run/Stop switching	Outputs the predetermined (preset) fixed value when the controller stops. A preset output value can be defined for each target setpoint using the operating parameter "PO". Stop: Stops operation. Run: Starts operation.	RUN		
SPn (SPN)	Target setpoint number selection	1: Selects target setpoint-1 (1.SP); 2: Selects target setpoint-2 (2.SP); 3: Selects target setpoint-3 (3.SP); 4: Selects target setpoint-4 (4.SP). Likewise, options 5 to 8 select target setpoints 5 (5.SP) to 8 (8.SP).	1		

Operation-related Parameters

Located in: Main menu = **LP1** (LP1); Submenu = **PAR** (PAR)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
AT (AT)	Auto-tuning	OFF: No auto-tuning 1: Auto-tuning for 1.SP; 2: Auto-tuning for 2.SP 3: Auto-tuning for 3.SP; 4: Auto-tuning for 4.SP 5 to 8: Perform auto-tuning on a group basis in the same way as 1 to 4 9: Performs auto-tuning to all groups 1 to 8.	OFF		
SC (SC)	"SUPER" function	OFF: Disable 1: Overshoot suppressing function Suppresses overshoots generated by abrupt changes in the target setpoint or by disturbances. 2: Hunting suppressing function (Stable mode) Stable to stabilize the state of control when the load varies greatly, or the target setpoint is changed. Enables to answer the wider characteristic changes compared with Response mode. 3: Hunting suppressing function (Response mode) Enables quick follow-up and short converging time of PV for the changed target setpoint. Note: Use "SUPER" function (SC) 2 or 3 in PID control or PI control. "SUPER" function 2 or 3 is not available in the following controls: 1) ON/OFF control 2) P control (control for proportional band only) 3) PID control (control for proportional band and derivative item only) 4) Heating/cooling control Do not use hunting suppressing function when control processes with response such as flow or pressure control.	OFF		Ref.2.1(5) Ref.2.1(6)
b5 (BS)	PV input bias	-100.0% to 100.0% of PV input range span Used to correct the PV input value.	0.0% of PV input range span		Ref.1.1(1)
FL (FL)	PV input filter	OFF, 1 to 120 second Used when the PV input value fluctuates.	OFF		Same as above
UPr (UPR)	Setpoint ramp-up-rate	OFF 0.0% + 1 digit of PV input range span to 100.0% of PV input range span Set ramp-up-rate or ramp-down-rate per hour or minute. Sets unit in ramp-rate-time unit (TMU).	OFF		Ref.4.1(4)
dnr (DNR)	Setpoint ramp-down-rate	Used to prevent the target setpoint from changing suddenly. The ramp setting function works when: 1. the target setpoint is changed (e.g., "1.SP" is changed from 100.0°C to 150.0°C); 2. the target setpoint number (SPN) is changed (e.g., the parameter is changed from 1.SP to 2.SP); 3. the power is turned on or has recovered from a failure; or 4. the operating mode is changed from Manual to Auto.	OFF		Same as above
rt (RT)	Ratio setting	0.001 to 9.999 Target setpoint = Remote input × Ratio setpoint + Remote bias	1.000		Ref.1.2(3)
rbs (RBS)	Remote input bias	-100.0 to 100.0% of PV input range span Used to correct the remote input value.	0.0% of PV input range span		Same as above
rfl (RFL)	Remote input filter	OFF, 1 to 120 second Used when the remote input value fluctuates.	OFF		Same as above
orb (ORB)	ON/OFF rate detection band	0.0 to 100.0% of PV input range span	1.0% of PV input range span		Ref.3.3(4)
orh (ORH)	ON/OFF rate high limit	ORL + 1 digit to 105.0%	100.0%		Same as above
orl (ORL)	ON/OFF rate low limit	-5.0% to ORH - 1 digit	0.0%		Same as above

Setpoint-, Alarm- and PID-related Parameters

Located in: Main menu = **LP1** (LP1); Submenu = **IP1d** (1.P1D)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
1SP (1.SP)	Target setpoint-1	0.0 to 100.0% of PV input range However, between target setpoint limiter lower limit (SPL) and upper limit (SPH).	0.0% of PV input range		Ref.4.1(1)

* The "User Setting" column in the table below is provided for the customer to record setpoints.
 * The column "Target Item in CD-ROM" in the table below provides references from User's Manual (Reference) (CD-ROM Version) which describes items in more detail and items that are not contained in this manual.


Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
1A1 (1.A1)	Alarm-1 setpoint	PV alarm / SP alarm: -100.0 to 100.0% of PV input range Deviation alarm: -100.0 to 100.0% of PV input range span Output alarm: -5.0 to 105.0% Timer alarm (for alarm-1 only): 0.00 to 99.99 (hour, min) or (min, sec)			Ref.4.1(1)
1A2 (1.A2)	Alarm-2 setpoint				Same as above
1A3 (1.A3)	Alarm-3 setpoint				Same as above
1A4 (1.A4)	Alarm-4 setpoint	Allows alarms 1 to 4 (1.A1 to 1.A4) to be set for target setpoint 1 (1.SP). Four alarms can also be set for target setpoints 2 to 8.			Same as above
1P (1.P)	Proportional band/Heating-side proportional band (in heating/cooling control)	0.1 to 999.9% of PV input range In heating/cooling control: 0.0 to 999.9% (heating-side on/off control applies when 0.0)	5.0%		Same as above
1I (1.I)	Integral time Heating-side integral time (in heating/cooling control)	OFF, 1 to 6000 second	240 second		Same as above
1D (1.D)	Derivative time Heating-side derivative time (in heating/cooling control)	OFF, 1 to 6000 second	60 second		Same as above
1OH (1.OH)	Output high limit Heating-side output high limit (in heating/cooling control)	-5.0 to 105.0% Heating-side limiter in heating/cooling control: 0.0 to 105.0% (1.OL < 1.OH)	100%		Ref.2.1(3)
1OL (1.OL)	Output low limit Cooling-side output high limit (in heating/cooling control)	-5.0 to 105.0% Cooling-side limiter in heating/cooling control: 0.0 to 105.0% (1.OL < 1.OH) SD (shutdown): Set in manual operation in 4-20 mA control output.	0.0%		Ref.4.1(1)
1MR (1.MR)	Manual reset	-5.0 to 105.0% (enabled when integral time "1.I" is OFF) The manual reset value equals the output value when PV = SP is true. For example, if the manual reset value is 50%, the output value is 50% when PV = SP becomes true.	50.0%		Ref.4.1(1)
1H (1.H)	ON/OFF control hysteresis Heating-side ON/OFF control hysteresis (in heating/cooling control)	In ON/OFF control: 0.0 to 100.0% of PV input range span Position proportional PID control or heating/cooling control: 0.0 to 100.0% Hysteresis can be set in the target setpoint when the controller is performing ON/OFF control.	0.5%		Same as above
1DR (1.DR)	Direct/reverse action switching	RVS: reverse action, DIR: direct action Control output	RVS		Ref.2.1(1) Ref.4.1(1)
1Pc (1.Pc)	Cooling-side proportional band	0.0 to 999.9% of PV input range (Cooling-side ON/OFF control applies when 0.0)	5.0%		Ref.4.1(1)
1Ic (1.Ic)	Cooling-side integral time	OFF, 1 to 6000 second	240 second		Same as above
1Dc (1.Dc)	Cooling-side derivative time	OFF, 1 to 6000 second	60 second		Same as above
1Hc (1.Hc)	Cooling-side ON/OFF control hysteresis	0.0 to 100.0%	0.5%		Same as above
1Db (1.Db)	Dead band	In heating/cooling control: -100.0 to 50.0% In position proportional PID control: 1.0 to 100.0% * In heating/cooling control: When setting any positive, there is a region where the heating and cooling-side output is presented; when setting any negative value, there is a region where both of the heating- and cooling-side outputs are presented. When setting a value of zero, either the heating- and cooling-side output is provided. * In position proportional control: Set the range so none of the outputs turn on.	3.0%		Same as above
1Po (1.Po)	Preset output/Heating-side preset output (in heating/cooling control)	-5.0 to 105.0% In heating/cooling control: Heating side 0.0 to 105.0% In Stop state, fixed control output can be generated.	0.0%		Ref.2.1(8)
1Oc (1.Oc)	Cooling-side preset output	0.0 to 105.0% In Stop state, cooling-side fixed control output can be generated.	0.0%		Ref.4.1(1)

If you are using two or more groups of setpoint, alarm and PID parameters, use the following table to record their values.

Parameter	n=2	n=3	n=4	n=5	n=6	n=7	n=8
n.SP							
n.A1							
n.A2							
n.A3							
n.A4							
n.P							
n.I							
n.D							
n.OH							
n.OL							
n.MR							
n.H							
n.DR							
n.Pc							
n.Ic							
n.Dc							
n.Hc							
n.DO							
n.Oc							

Ten-segment Linearizer1 Parameters

Located in: Main menu = **PYS1** (PYS1)



Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
1A1 (1.A1)	Ten-segment linearizer 1 input-1	-66.7% to 105.0% of PV input range	0.0% of PV input range		Ref.1.1(2)
1B1 (1.B1)	Ten-segment linearizer 1 output-1	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A2 (1.A2)	Ten-segment linearizer 1 input-2	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B2 (1.B2)	Ten-segment linearizer 1 output-2	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A3 (1.A3)	Ten-segment linearizer 1 input-3	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B3 (1.B3)	Ten-segment linearizer 1 output-3	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A4 (1.A4)	Ten-segment linearizer 1 input-4	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B4 (1.B4)	Ten-segment linearizer 1 output-4	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A5 (1.A5)	Ten-segment linearizer 1 input-5	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B5 (1.B5)	Ten-segment linearizer 1 output-5	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A6 (1.A6)	Ten-segment linearizer 1 input-6	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B6 (1.B6)	Ten-segment linearizer 1 output-6	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A7 (1.A7)	Ten-segment linearizer 1 input-7	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B7 (1.B7)	Ten-segment linearizer 1 output-7	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A8 (1.A8)	Ten-segment linearizer 1 input-8	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B8 (1.B8)	Ten-segment linearizer 1 output-8	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A9 (1.A9)	Ten-segment linearizer 1 input-9	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B9 (1.B9)	Ten-segment linearizer 1 output-9	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A10 (1.A10)	Ten-segment linearizer 1 input-10	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B10 (1.B10)	Ten-segment linearizer 1 output-10	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1A11 (1.A11)	Ten-segment linearizer 1 input-11	-66.7% to 105.0% of PV input range	0.0% of PV input range		Same as above
1B11 (1.B11)	Ten-segment linearizer 1 output-11	-66.7% to 105.0% of PV input range span -66.7% to 105.0% of PV input range when in ten-segment linearizer approximation	0.0% of PV input range span 0.0% of PV input range when in ten-segment linearizer approximation		Same as above
1MD (1.MD)	Ten-segment linearizer 1 mode	0: Ten-segment linearizer biasing 1: Ten-segment linearizer approximation	0		Same as above

Setup Parameters

Target Setpoint-related Parameters

Located in: Main menu = **LOOP1** (LOOP1); Submenu = **SP** (SP)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
rns (RMS)	Remote input selection	RSP: Uses the value set remotely via remote input (terminals). COM: Uses the value set remotely via communication.	RSP		Ref.1.2(1)
SPT (SPT)	SP tracking selection	OFF, ON Tracking is performed when the mode changes from Remote to Local (The local setpoint keeps track of the remote setpoint). Causes the setpoint to keep track of the PV value so the setpoint automatically reverts to its original value at a preset rate of change. The Setpoint Ramp-up rate (UPR) and Setpoint Ramp-down rate (DNR) parameters are used in combination.	ON		Ref.1.2(4)
PVt (PVT)	PV tracking selection	Causes the setpoint to keep track of the PV value so the setpoint automatically reverts to its original value at a preset rate of change. The Setpoint Ramp-up rate (UPR) and Setpoint Ramp-down rate (DNR) parameters are used in combination.	OFF		Ref.1.1(7)
tau (TMU)	Ramp-rate time unit setting	Time unit of setpoint ramp-up rate (UPR) and setpoint ramp-down rate (DNR) HOUR: Denotes "per hour." MIN: Denotes "per minute."	HOUR		Ref.4.1(4)
SPH (SPH)	Target setpoint limiter upper limit	0.0% to 100.0% of PV input range. Note that SPL < SPH. Places limits on the ranges within which the target setpoints (1.SP to 8.SP) are changed.	100.0% of PV input range		
SPL (SPL)	Target setpoint limiter lower limit	0.0% to 100.0% of PV input range	0.0% of PV input range		

Alarm-related Parameters

Located in: Main menu = **LOOP1** (LOOP1); Submenu = **ALn** (ALM)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
AL1 (AL1)	Alarm-1 type	OFF, 1 to 31 Common to all target setpoints.	1		Ref.3.3(3) Ref.3.3(4)
AL2 (AL2)	Alarm-2 type	OFF, 1 to 20, 25 to 31 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action)	2		Ref.3.3(4)
AL3 (AL3)	Alarm-3 type	OFF, 1 to 20, 25 to 31 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action)	1		Same as above
AL4 (AL4)	Alarm-4 type	OFF, 1 to 20, 25 to 31 1: PV high limit (energized, no stand-by action) 2: PV low limit (energized, no stand-by action) 3: Deviation high limit (energized, no stand-by action) 4: Deviation low limit (energized, no stand-by action) 5: Deviation high limit (de-energized, no stand-by action) 6: Deviation low limit (de-energized, no stand-by action)	2		Same as above
HY1 (HY1)	Alarm-1 hysteresis	0.0 to 100.0% of PV input range span Output alarm: 0.0 to 100.0%	0.5% of PV input range span		Ref.3.3(2)
HY2 (HY2)	Alarm-2 hysteresis	Allows margins to be set for an alarm setpoint. With the hysteresis settings, it is possible to prevent relays from chattering.	0.5%		Same as above
HY3 (HY3)	Alarm-3 hysteresis				Same as above
HY4 (HY4)	Alarm-4 hysteresis				Same as above

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
dy1 (DY1)	Alarm-1 delay timer	0.00 to 99.99 (min. sec.) (enabled when alarm-1 type "AL1" is 1 to 20 or 28 to 31) An alarm is output when the delay timer expires after the alarm setpoint is reached.	0.00		
dy2 (DY2)	Alarm-2 delay timer	0.00 to 99.99 (min. sec.) (enabled when alarm-2 type "AL2" is 1 to 20 or 28 to 31)			
dy3 (DY3)	Alarm-3 delay timer	0.00 to 99.99 (min. sec.) (enabled when alarm-3 type "AL3" is 1 to 20 or 28 to 31)			
dy4 (DY4)	Alarm-4 delay timer	0.00 to 99.99 (min. sec.) (enabled when alarm-4 type "AL4" is 1 to 20 or 28 to 31)			
Rnd (AMD)	Alarm mode	Allows the alarm function to be enabled or disabled according to the operating condition. 0: Always active 1: Not active when in Stop mode 2: Not active when in Stop mode or manual operation 3: Eight alarms are used and always enabled. 4: Eight alarms are used and disabled when the controller is at a stop. 5: Eight alarms are used and disabled when the controller is at a stop or in manual operation.	0		Ref.3.3(1)

Control Action-related Parameters

Located in: Main menu = **LOOP1** (LOOP1); Submenu = **CTL** (CTL)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
OPr (OPR)	Output velocity limiter	OFF (0) 0.1 to 100.0%/second can limit control output velocity	OFF		
nod (MOD)	PID control mode	0: Standard PID control (with output bump at SP change) 1: Fixed-point control (without output bump at SP change) Choose "Fixed-point Control" when controlling pressure or flow rate.	0		Ref.2.1(2)
Ar (AR)	Anti-reset windup (Excess integration prevention)	AUTO (0), 50.0 to 200.0% The larger Setting, the sooner PID computation (integral			

Retransmission Output Parameters

Located in: Main menu = **CLP** (CMLP) ; Submenu = **RET** (RET)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
rt1 (RT1)	Retransmission output-1 type	OFF: Disable 1: PV1, 2: SP1, 3: OUT1, 4: LPS loop power supply (15 V), 5: PV2, 6: SP2, 7: OUT2 Setpoints 5 to 7 are not available for single-loop control. Retransmission output 1 is always provided via terminals 14 and 15.	1		Ref.2.2(1)
th1 (TH1)	Maximum value of retransmission output-1 scale	In position proportional control, a valve opening signal (0% to 100%) is transmitted if setpoint "3" is selected. In heating/cooling control, an output value before allocation to heating/cooling control (0% to 100%) is transmitted if setpoint "3" is selected. (0% to 50%: Cooling-side output; 50% to 100%: Heating-side output)	100.0% of PV input range		Ref.2.2(3)
tl1 (TL1)	Minimum value of retransmission output-1 scale	RT1=1, 2: TL1 + 1 digit to 100.0% of PV input range RT1=3: 0.0% to TH1 - 1 digit	0.0% of PV input range		Same as above
rt2 (RT2)	Retransmission output-2 type	Retransmission output-2 is available when the type of control output is not "current" or "voltage pulse." The output is provided via terminals 16 and 17. OFF: Disable 1: PV1, 2: SP1, 3: OUT1, 4: LPS loop power supply (15 V), 5: PV2, 6: SP2, 7: OUT2 Setpoints 5 to 7 are not available for single-loop control.	OFF		Ref.2.2(1)
th2 (TH2)	Maximum value of retransmission output-2 scale	In position proportional control, a valve opening signal (0% to 100%) is transmitted if setpoint "3" is selected. In heating/cooling control, an output value before allocation to heating/cooling control (0% to 100%) is transmitted if setpoint "3" is selected. (0% to 50%: Cooling-side output; 50% to 100%: Heating-side output)	100.0% of PV input range		Ref.2.2(3)
tl2 (TL2)	Minimum value of retransmission output-2 scale	RT2=1, 2: TL2 + 1 digit to 100.0% of PV input range RT2=3: 0.0% to TH2 - 1 digit	0.0% of PV input range		Same as above

Deviation Monitor Parameters

Located in: Main menu = **CLP** (CMLP) ; Submenu = **TRND** (TRND)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
dbb (DVB)	Deviation display band	0.0 to 100.0% of PV input range span Permits a change in the span of deviation shown on the front-panel deviation monitor.	1.0% of PV input range span		Ref.6.1(3)

Security-related Parameters

Located in: Main menu = **CLP** (CMLP) ; Submenu = **LOCK** (LOCK)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
dAt (DAT)	Front panel data setting (Δ, ∇) key lock	OFF: Unlock ON: Lock	OFF		Ref.7.1(2)
Arn (A/M)	Front panel A/M key lock	OFF: Unlock ON: Lock	OFF		Same as above
mod (MOD)	Operating parameter main menu [MODE] lock	OFF: Unlock ON: Lock	OFF		Same as above
LP1 (LP1)	Operating parameter main menu [LP1] lock	OFF: Unlock ON: Lock	OFF		Same as above
LP2 (LP2)	Although not used in single-loop control, it is shown on the display.				
PI d (PID)	Operating parameter main menu [PID] lock	OFF: Unlock ON: Lock	OFF		Same as above
USR (USR)	Although not used in single-loop control, it is shown on the display.				
PY1 (PY1)	Operating parameter main menu [PYS1] lock	OFF: Unlock ON: Lock	OFF		Same as above
PY2 (PY2)	Although not used in single-loop control, it is shown on the display.				
PWD (PWD)	Password setting	0: Password not set 1 to 30000	0		Ref.7.1(1)

SELECT Display Parameters

Located in: Main menu = **CONF** (CONF) ; Submenu = **CSEL** (CSEL)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
CS1 (C.S1)	SELECT display-1 registration	OFF: 201 to 1023 Select the desired parameter from among the operating and setup parameters, then register the number (D register No.) accompanying that parameter.	OFF		Ref.6.1(1)
CS2 (C.S2)	SELECT display-2 registration	For example, registering "302" for C.S1 allows you to change alarm-1 setpoint in operating display.			Same as above
CS3 (C.S3)	SELECT display-3 registration	Numbers for registering alarm SP parameter for operating display: Alarm-1 setpoint: 302 Alarm-2 setpoint: 303 Alarm-3 setpoint: 304 Alarm-4 setpoint: 305			Same as above
CS4 (C.S4)	SELECT display-4 registration	Above numbers are alarm setpoint parameters for target setpoint-1 (1.SP).			Same as above
CS5 (C.S5)	SELECT display-5 registration	Set the registration number of the alarm setpoint parameter for target setpoint 2 (2.SP), to a value obtained by adding 25 to the registration number of the alarm setpoint parameter for the parameter 1.SP. Likewise, set the registration number of the alarm setpoint parameter for target setpoint 3 (3.SP), to a value obtained by adding 25 to the registration number of the alarm setpoint parameter for the parameter 2.SP.			Same as above

Contact Output Registration Parameters

Located in: Main menu = **CONF** (CONF) ; Submenu = **DO** (DO)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
do1 (DO1)	Relay output flag registration for DO1	The following setpoints are registration numbers for Single-loop Control only: 5689: Alarm-1 output 5690: Alarm-2 output 5691: Alarm-3 output 5693: Alarm-4 output 1609: FAIL output	5689	0: No function	Ref.3.2(1)
do2 (DO2)	Relay output flag registration for DO2		5690		Same as above
do3 (DO3)	Relay output flag registration for DO3		5691		Same as above
do4 (DO4)	Open-collector transistor output flag registration for DO4		5693		Ref.3.2(1)

do5 (DO5)	Open-collector transistor output flag registration for DO5	The following setpoints are registration numbers for single-loop control only: 5689: Alarm-1 output 5690: Alarm-2 output 5691: Alarm-3 output 5693: Alarm-4 output 1609: FAIL output	0		Same as above
do6 (DO6)	Open-collector transistor output flag registration for DO6		0		Same as above
do7 (DO7)	Open-collector transistor output flag registration for DO7		1609		Same as above

Contact Input Registration Parameters

Located in: Main menu = **CONF** (CONF) ; Submenu = **DI** (DI)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
Arn (A/M)	Auto/Manual switching	These parameters determine which contact input to use to make selections/switches listed on the left. DI1: 5161 DI2: 5162 DI3: 5163 DI4: 5164 DI5: 5165 DI6: 5166 DI7: 5167 DI8: 5169 No function: 0	5161		Ref.3.1(3)
rL (R/L)	Remote/Local switching		5168		Same as above
Sr (S/R)	Run/Stop switching		5162		Same as above
CAS (CAS)	Switch to Cascade mode (when in cascade control)	The contact inputs are factory-set as shown below. The contact inputs are factory-set as shown below. Contact input 1 (DI1): Auto (ON)/Manual (OFF) switching Contact input 2 (DI2): Run (OFF)/Stop (ON) switching Contact inputs 3 to 6 (DI3 to DI6): SP selection (see table below) Contact input 8 (DI8): Remote (ON)/Local (OFF) switching	0		Same as above
AUT (AUT)	Switch to Auto mode (when in cascade control)		0		Same as above
MAN (MAN)	Switch to Manual mode (when in cascade control)	SP Selection: 1.SP 2.SP 3.SP 4.SP 5.SP 6.SP 7.SP 8.SP	0		Same as above
SP0 (SP.0)	Bit-0 of SP number setting		5163		Same as above
SP1 (SP.1)	Bit-1 of SP number setting		5164		Same as above
SP2 (SP.2)	Bit-2 of SP number setting	If all of the SP parameters of a contact input are set to "OFF", the controller uses the immediately preceding SP.	5165		Same as above
SP3 (SP.3)	Bit-3 of SP number setting		5166		Same as above

UT Mode Parameters

Located in: Main menu = **UTMD** (UTMD) ; Submenu = **MD** (MD)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
UTM (UTM)	Controller mode (UT mode)	1: Single-loop control For another controller mode, see the User's Manual (Reference) (CD-ROM version).	1		—
SMP (SMP)	PV sampling period setting	50, 100, 200 and 500 ms The controller restarts if any change is made to the PV sampling period; this does not affect other parameter settings at all, however.	200 ms		Ref.1.1(4)
SMC (SMC)	Sampling period error counter (reading only)	0 to 30000	Shows 0 at power-on.		Ref.1.1(5)

Input-related Parameters



Located in: Main menu = **UTMD** (UTMD) ; Submenu = **IN** (IN)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
IN1 (IN1)	PV input type (INPUT 1 terminals) Terminals ①, ② and ③	Specify the type of PV input as a range code. OFF: 1 to 18, 30, 31, 35 to 37, 40, 41, 50, 51, 55, 56 See "Instrument Input Range Codes" in the INITIAL SETTINGS User's Manual .	OFF		—
UN1 (UN1)	PV input unit	Select the unit of PV input. %: Percent °F: Fahrenheit °C: Degree Celsius -: No unit	Depends on the PV input type.		—
RH1 (RH1)	Max. value of PV input range	Set the PV input range (RL1 < RH1). - For temperature input - Set the range of temperature that is actually controlled.	Depends on the PV input type.		—
RL1 (RL1)	Min. value of PV input range	- For voltage input - Set the range of a voltage signal that is applied. The scale across which the voltage signal is actually controlled should be set using the parameters Maximum Value of PV Input Scale (SH1) and Minimum Value of PV Input Scale (SL1).	—		—
DP1 (DP1)	PV input decimal point position (shown when in voltage-input mode)	Set the position of the decimal point of voltage-mode PV input. 0 to 4 0: No decimal place, 1: One decimal place 2 to 4: Two, three, or four decimal places	Depends on the PV input type.		—
SH1 (SH1)	Max. value of PV input scale (shown when in voltage-input mode)	Set the read-out scale of voltage-mode PV input. -19999 to 30000, where SL1 < SH1, SH1 - SL1 = 30000	Depends on the PV input type.		—
SL1 (SL1)	Min. value of PV input scale (shown when in voltage-input mode)		—		—
BO1 (BO1)	Selection of PV input burnout action	Allows the PV input value to be determined as shown below in case of PV input burnout. • 105% of PV input range if set to "Upscale" • -5.0% of PV input range if set to "Downscale" OFF: Disable UP: Upscale DOWN: Downscale	Depends on the PV input type.		—
RJC (RJC)	Presence/absence of PV input reference junction compensation	Allows input compensation to be applied to thermocouple input. OFF: Absent ON: Present	ON		—
IN3 (IN3)	Remote input type (INPUT 3 terminals) Terminals ④ and ⑤	Specify the type of remote input as a range code. 40, 41, 50, 51 See "Instrument Input Range Codes" in the INITIAL SETTINGS User's Manual .	41		Ref.1.2(1)
UN3 (UN3)	Remote input unit	Select the unit of remote input. %: Percent °F: Fahrenheit °C: Degree Celsius -: No unit	%		Same as above
RH3 (RH3)	Maximum value of remote input range	Set the range of a voltage signal. (RL3 < RH3)	5,000		Same as above
RL3 (RL3)	Minimum value of remote input range		1,000		Same as above
DP3 (DP3)	Remote input decimal point position	Set the position of the decimal point for remote input. 0 to 4 0: No decimal place, 1: One decimal place 2 to 4: Two, three, or four decimal places	Same as the position of the PV input's decimal point		Same as above
SH3 (SH3)	Max. value of remote input scale	Set the remote input read-out scale. -19999 to 30000, where SL3 < SH3, SH3 - SL3 = 30000 Under normal operation, set the values of these parameters as shown below. - When PV input is temperature - Maximum and minimum values of PV input range - When PV input is voltage - Maximum and minimum values of PV input scale	Maximum value of PV input scale		Same as above
SL3 (SL3)	Min. value of remote input scale		Minimum value of PV input scale		Same as above
BO3 (BO3)	Remote input burnout action selection	Allows the remote input value to be determined as shown below in case of remote input burnout. • 105% of remote input scale if set to "Upscale" • -5.0% of remote input scale if set to "Downscale" OFF: Disable UP: Upscale DOWN: Downscale	OFF		—

PV1 (PV1)	PV unit	Set the unit of PV. %: Percent °F: Fahrenheit °C: Degree Celsius -: No unit	Same as the unit of PV input		Ref.1.1(6)
PD1 (PD1)	PV decimal point position	Under normal operation, set the same value as in the PV Input Decimal Point Position (DP1) parameter. To shift the decimal point for temperature input, use this parameter. For example, set as "PD1 = 0" to change a temperature reading of one decimal place to that of no decimal places. This involves reconfiguring the PH1 and PL1 parameters.	-		same as above
PH1 (PH1)	Maximum value of PV range	Under normal operation, keep the values of these parameters between the maximum and minimum values of the PV input range. -19999 to 30000 PL1 < PH1, where PH1-PL1 = 30000	Maximum value of PV input range or scale		same as above
PL1 (PL1)	Minimum value of PV range		Minimum value of PV input range or scale		same as above

Output-related Parameters

Located in: Main menu = **UTMD** (UTMD) ; Submenu = **OUT** (OUT)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
OT1 (OT1)	Control output type	0 Time proportional PID relay contact output (terminals ①-②-③) 1 Time proportional PID voltage pulse output (terminals ④-⑤) 2 Current output (terminals ⑥-⑦) 3 ON/OFF control relay contact output (terminals ①-②-③) The following 4 to 12 are displayed only for heating/cooling type controllers. 4 Heating-side relay output (terminals ①-②-③), cooling-side relay output (terminals ④-⑤) 5 Heating-side pulse output (terminals ⑥-⑦), cooling-side relay output (terminals ⑧-⑨) 6 Heating-side current output (terminals ⑩-⑪), cooling-side relay output (terminals ⑫-⑬) 7 Heating-side relay output (terminals ①-②-③), cooling-side pulse output (terminals ④-⑤) 8 Heating-side pulse output (terminals ⑥-⑦), cooling-side pulse output (terminals ⑧-⑨) 9 Heating-side current output (terminals ⑩-⑪), cooling-side pulse output (terminals ⑫-⑬) 10 Heating-side relay output (terminals ①-②-③), cooling-side current output (terminals ④-⑤) 11 Heating-side pulse output (terminals ⑥-⑦), cooling-side current output (terminals ⑧-⑨) 12 Heating-side current output (terminals ⑩-⑪), cooling-side current output (terminals ⑫-⑬)	0 Heating/cooling type: 4		Ref.3.3(4)
CT (CT)	Control output cycle time Heating-side control output cycle time in heating/cooling control	1 to 1000 second  Relay's Behavior when Cycle Time = 10 sec. 	30 second		Ref.3.3(4)
CTC (CTC)	Cooling-side control output cycle time	1 to 1000 second	30 second		Ref.3.3(4)
AO1 (AO1)	Analog output-1 type (OUTPUT 1: Terminals ⑭ and ⑮)	Allows control output or retransmission output to be presented as one of the following current signals.	0		Ref.2.1(7)
AO2 (AO2)	Analog output-2 type (OUTPUT 2: Terminals ⑯ and ⑰)	0: 4 to 20 mA 1: 0 to 20 mA 2: 20 to 4 mA 3: 20 to 0 mA	0		same as above
AO3 (AO3)	Analog output-3 type (OUTPUT 3: Terminals ⑱ and ⑲)	0	0		same as above
A1H (A1H)	Analog output-1 100% segmental point	Set the values of segmental points for the 0% and 100% output levels at which the values are presented via OUTPUT-1 (terminals ⑭ and ⑮). See Performing Split Computations below.	100.0 %		same as above
A1L (A1L)	Analog output-1 0% segmental point	-5.0% to 105.0%, where A1L < A1H	0.0 %		same as above
A2H (A2H)	Analog output-2 100% segmental point	Set the values of segmental points for the 0% and 100% output levels at which the values are presented via OUTPUT-2 (terminals ⑯ and ⑰). See Performing Split Computations below.	100.0 %		same as above
A2L (A2L)	Analog output-2 0% segmental point	-5.0% to 105.0%, where A2L < A2H	0.0 %		same as above
A3H (A3H)	Analog output-3 100% segmental point	Set the values of segmental points for the 0% and 100% output levels at which the values are presented via OUTPUT-3 (terminals ⑱ and ⑲). See Performing Split Computations below.	100.0 %		same as above
A3L (A3L)	Analog output-3 0% segmental point	-5.0% to 105.0%, where A3L < A3H	0.0 %		same as above

Performing Split Computations

V-mode Output

The following explains an example of letting "Analog OUTPUT-1 (terminals ⑭ and ⑮)" and "Analog OUTPUT-3 (terminals ⑱ and ⑲)" present the V-mode characteristics of split computation.

[1] Set the Control Output Type (OT1) parameter to "2".
This sets the control output to "current output."

[2] Set the Retransmission Output 1 (RT1) parameter to "3".
This sets the retransmission output to "control output retransmission."

[3] Set the Analog Output-1 100% Segmental Point (A1H) parameter to "100%".

[4] Set the Analog Output-1 0% Segmental Point (A1L) parameter to "25%".

[5] Set the Analog Output-3 100% Segmental Point (A3H) parameter to "0%".

[6] Set the Analog Output-3 0% Segmental Point (A3L) parameter to "75%".

The figure on the right shows an example where both analog outputs-1 and 3 are set to the current signal of 4 to 20 mA DC. The type of output signal can be determined separately for each of the analog outputs listed above, using the following three parameters.

Analog output-1: Analog output-1 type (AO1)

Analog output-2: Analog output-2 type (AO2)

Analog output-3: Analog output-3 type (AO3)

Parallel-mode Output

The following explains an example of letting "Analog OUTPUT-1 (terminals ⑭ and ⑮)" and "Analog OUTPUT-3 (terminals ⑱ and ⑲)" present the parallel-mode characteristics of split computation.

[1] Set the Control Output Type (OT1) parameter to "2".
This sets the control output to "current output."

[2] Set the Retransmission Output 1 (RT1) parameter to "3".
This sets the retransmission output to "control output retransmission."

[3] Set the Analog Output-1 100% Segmental Point (A1H) parameter to "100%".

[4] Set the Analog Output-1 0% Segmental Point (A1L) parameter to "25%".

[5] Set the Analog Output-3 100% Segmental Point (A3H) parameter to "0%".

[6] Set the Analog Output-3 0% Segmental Point (A3L) parameter to "0%".

The figure on the right shows an example where both analog outputs-1 and 3 are set to the current signal of 20 to 0 mA DC. The type of output signal can be determined separately for each of the analog outputs listed above, using the following three parameters.

Analog output-1: Analog output-1 type (AO1)

Analog output-2: Analog output-2 type (AO2)

Analog output-3: Analog output-3 type (AO3)

Communication Parameters

Located in: Main menu = **UTMD** (UTMD) ; Submenu = **R485** (R485)

Parameter Symbol	Name of Parameter	Setting Range and Description	Initial Value	User Setting	Target Item in CD-ROM
PSL (PSL)	Protocol selection	0: PC link communication 1: PC link communication (with sum check) 2: Ladder communication 3: Coordinated master station 4: Coordinated slave station 7: MODBUS (ASCII) 8: MODBUS (RTU) 10: Coordinated slave station (loop-1 mode) 11: Coordinated slave station (loop-2 mode)	0		—
bPS (BPS)	Baud rate	600, 1200, 2400, 4800, 9600 (bps)	9600		—
Pr1 (PR1)	Parity	NONE: None EVEN: Even ODD: Odd	EVEN		Communication functions