

# GPR-Analyzers

## Addendum to the User Manual

For GPR-1100, 1200, 1500 (GB), 1800 (A)IS, 2500 (GB), 2800 (A)IS, 2000, 3500 MOVR, 7100, 7500 (A)IS



## 1 Additional Features

The features in this addendum have been added with **firmware versions 1.09** and **1.10**; they are applicable to the following analyzers.

- GPR range of portable oxygen analyzers (GPR-1000, GPR-1100, GPR-1200, GPR-2000, GPR-3500 MOVR)
- GPR-x500 (GPR-1500, GPR-1500 GB, GPR-2500, GPR-2500 GB)
- GPR-x800 (A)IS (GPR-1800 IS, GPR-1800 AIS, GPR-2800 IS, GPR-2800 AIS)
- H2S analyzers (GPR-7100, GPR-7500 IS, GPR-7500 AIS)

Before using your analyzer, carefully read both this document and the user manual (which provides instructions for firmware version 1.08).

### 1.1 Firmware Version 1.09











- The **Range Scale** menu is now user-configurable within your sensor's range, with typing enabled so that users can type in required values instead of scaling by factor.
- **Restart Analyzer** has been added to the System menu for online analyzers (not applicable to portable)
- During **Span/Zero** cal, High or Low will flash on the display to let you know if output is too high or low to pass calibration


#### 1.1.1 Change your Range Scale

When editing ranges, please note the following:




- A 25 % range on a ppm analyzer cannot be edited - the 0...25 % is used only for air calibration.
- Your analyzer's lowest range cannot be exceeded.
- Your analyzer's highest range cannot be exceeded.
- A range cannot be greater than half of the next ascending range
- A range cannot be less than twice the next descending range.

In the **System** menu:

1. Use  and  to move the cursor to **Edit Ranges** and press .  
A list of the ranges appears.
2. Select the range that you want to edit by using  and , then press .
3. To edit the range, use  and  to increase or decrease the digit, and use  to move to the next digit of the number. Once complete, press  to confirm new range.

NOTE: Pressing  before confirming your new range scale will cancel the action. Your new range scale will not be saved.

### 1.1.2 Restart your Online Analyzer (online models only)

In the **System** menu, use  and  to move the cursor to **Restart Analyzer** and press .

The message “Restarting...” will appear on your display before the analyzer restarts.

### 1.1.3 Span or Zero Calibrate your Analyzer

NOTE: Zero calibration should always be carried out before a span calibration.




To Span or Zero calibrate your analyzer, please follow the procedure in the user manual. During calibration, **High** or **Low** will flash on the display if output is too high or too low.

## 1.2 Firmware Version 1.10

### 1.2.1 Analog Range Lock

This function allows you to assign the analog output to a fixed range.

For portable units, the range is 0...1 V and for online units, it is 4...20 mA.

In the **System** menu, use  and  to move the cursor to **0-1V Range** (portable) or **4-20mA Range** (online) then press .

The analog output can be configured independently of the oxygen concentration displayed:

- If the selected range is **Displayed Range**, the analog output will be based on the range shown on the Home screen for fixed or auto ranging.
- If the selected analog range is specific, the analog output will be based on that range, regardless of the range of the Home screen (for auto ranging only).
- If the ranging mode is fixed (not auto), the analog output will follow the range shown on the Home screen regardless of the selected analog range.



[ProcessSensing.com](https://ProcessSensing.com)

Analytical Industries Incorporated (Aii) is part of the Process Sensing Technologies Group Ltd. (PST)

© 2024 Process Sensing Technologies

---