


Pressure Calibrator



PC6-AV

operating
manual



SI Pressure Instruments, Druck Ltd., Fir tree Lane, Groby, Leicester, LE6 0FH. UK. Tel: +44 (0)116 231 7500 Fax: +44 (0)116 231 7102 sales@si-pressure.com

Part No: 31-0353 Iss.3.



CONTENTS

<i>Welcome</i>	i
<i>Safety Warning</i>	ii
<i>Quick Reference</i>	iii
<i>Manufacturer's Specifications</i>	iv

Description

1.0 Introduction	1
1.1 General	1
1.2 Keypad	1
1.3 LCD	2
1.4 Connection Panel	2
1.4.1 Quick connect coupling	2
1.4.2 RS232	2
1.4.3 Charger	2
<i>Arrangement of PC6</i>	3
<i>Functions (menu 1)</i>	4
<i>Functions (menu 2)</i>	5
<i>Functions (menu 3)</i>	6

Operating Instructions

<i>Connections:</i>	
1.5 Switch test	7
1.6 RS232	7
1.6.1 Charger	7
1.7 <i>Messages & Parameters:</i>	
1.7.1 Retained parameters on switch of	8
1.7.2 Battery low state	8
1.7.3 Tare Value	8
1.7.4 Maximum / Minimum	8
1.7.5 Void leak test	8
1.7.6 Switch Off	8
1.7.7 Auto Switch Off	8
1.7.8 Pressure Overload	8

1.7.9 Low Battery Detect	8
1.7.10 Pressure Switch State Change	8
1.7.11 Printer Busy	9
1.7.12 Outside User Set Alarm Value	9
1.7.13 Display Hold	9
1.7.14 RS232 Output Format	9
1.7.15 Alarm Flag.....	9
1.7.16 Symbols	9
1.7.17 Alt (height) warning	9
1.7.18 Knots (limits)	9

How to Select Functions (menu 1)

1.8 Units	10
1.9 Alt (ft)	10
1.9.1 Alt (m)	10
2.0 OFF	10
2.1 Max, Min, Date & Time, %	10
2.1.1 Tare	10
2.1.2 Knots (absolute)	10
2.2 Leak Test	11
2.3 File (logged files)	12

Set-menu (menu 2)

2.4 Alt - Datum, ISA	14
2.5 OFF - height, Temperature	14
2.6 Alarm Settings - High / Low	14
2.7 Display light,	15
2.8 Resolution	15
2.9 Event	15
3.0 Log	16
3.1 RS232	18
3.2 Date & Time	19
3.3 Zero	19
3.4 Language.....	20
3.5 Power off.....	20

Cal-menu (menu 3)

3.6 Span	22
3.7 History (overload, zero/span)	23
3.8 Language.....	23
3.9 Units.....	23

Flowcharts

<i>Menu 1, Menu 2, Menu 3</i> .	24
<i>Menu 1</i> Alt(ft),Alt(m),OFF, Max, Min,%Tare, Switch, TempC, Date & Time,	24
Units, Leak Test	25
File	26
<i>Menu 2</i> Alt, Datum, ISA	27
OFF - Height, Temp	27
High & Low	28
Display light, Resolution	29
Event, RS232	30
Log	31
Date & Time, language,Zero.....	32
Port,Power Off.....	33
<i>Menu 3</i> Span.....	34
History	35
Language.....	36
Units.....	37

Operating Instructions for Pneumatic	34
Test Pump TP1	
Operating Instructions for Low Pressure	37
Hand Pump LTP1	
<i>Index</i>	40

WELCOME

This detailed operating manual will help you to become familiar with the many features of the PC6-AV Calibrator, the simple step by step instructions will quickly guide you through the procedures for using the calibrator and other items needed for accurately testing and calibrating numerous types of instruments. Please take time to carefully read the whole manual before you begin to use the PC6-AV.

© 2003

SI Pressure Instruments


SAFETY WARNING!

HIGH PRESSURE:

Uncontrolled release of high pressure is hazardous to personnel and may cause damage to equipment. Before connection of any pressure component to the Pc6 ensure that the component(s) is/are isolated from the pressure supply and any internal pressure is released slowly.

RECHARGEABLE Ni-MH BATTERIES

Rechargeable Ni-MH batteries must be recycled or disposed of properly.
May explode if damaged or disposed of in fire. DO NOT short-circuit.
CAUTION: Use charger supplied by SI Pressure Instruments only.



QUICK REFERENCE

Keys



Press to turn unit on and off



Press to access the menus



Press to accept functions or settings



Press to move cursor up/left or increase values



Press to move cursor down/right or decrease values



Press to print/log/start event depending on previous setting

Activating Functions



Select menu



position cursor under function




press the Enter key

Exit

To exit out of any menu select 'Exit' option, or press key.

Menu Selection


Pressure Display



1st Press for Menu 1

2nd Press for Menu 2

3rd Press back to Pressure Display



Data Entry

Press or to position cursor and press to select required alphanumeric. Press key to release cursor.

For next data entry, repeat the above procedures then press once all data is entered

Note: To quickly scroll through alphanumeric lists hold down the or key.

MANUFACTURER'S SPECIFICATIONS

Model	Pressure Range (FS)	Overload Pressure (FS)	Accuracy (FS) Better than	Resolution (FS) Better than
PC6-0002A-I-1-P-AV	0 to 2 bar (+60 inHg) absolute 0 to 600 knots*	10%	0.025%	0.01%

Pressure Units	mbar, inHg, knots, kPa, MPa, psi, kg/cm ² , atm, inH ₂ O, mH ₂ O, mmH ₂ O, bar, mmHg, unit, unit2
Overload Warning	Flashing display and audible tone at 110% of FS
Resolution	6 digits
Temperature Display	Temperature of pressure sensor module
Operating Temperature	-20 to 70°C
Calibration Temperature	20°C ± 2°C
Storage Temperature	-40°C to 70°C
Temperature Effects	0.001% of reading/°C between 10-40°C
RS232 Parameters	baud rate 1200, 2400, 4800, 9600, stop bits 1 or 2, status ON/OFF
Zero Reset	Manual keyboard operation
Data Capacity	436 records into a maximum of 20 files, 32k memory additional 585 records, (32k memory option available)
Display	Backlit LCD, 16 character x 2 line alpha numeric
Humidity	5 to 95% Relative Humidity non condensing
Resolution Select	Increase or decrease by a factor of 10
Power Supply	6V Ni-MH rechargeable battery pack (see warning page ii)/ mains operation via charger (supplied).
Battery Life	Fully charged - 10 hours
Recharge Time	14-16 hours for full charge

Low Battery

Dimensions

Weight

Microprocessor

Recommended Recalibration Period 1 Year

Electrical Connections

Battery

RS232

Pressure Media

Pressure Connections

Pressure Switch Input

Software (optional)

System requirements:

Continuous check, audio and visual warning

92 x 110 x 59mm

850 grams (Calibrator head only)

H8/2138

2 pole miniature round connector

8 pole miniature round connector

Non-corrosive gases

(for other media, contact SI)

3/8" BSP Quick-fit.

8mm O/D hose connector

Standard 2mm sockets

The 'SiCal PRO' software will present downloaded data in various graphical forms such as gauges or a scrolling bar & remotely control the PC6-PRO via the RS232 cable linked to a PC. The downloaded data can be stored in a variety of file types compatible with most analysis database and word processing programs.

Cal. procedures can be uploaded to the PC6-PRO.

486 with maths coprocessor.

Windows® 95 or higher is required.

knots

Pressure to airspeed conversion for the range 0 to 600 knots using 'British Standard 2G 199 :1984'

DESCRIPTION

1.0 Introduction

The unit is a microprocessor controlled, precision instrument powered by an internal 6V rechargeable battery pack. It is portable and capable of accurate pressure measurement. This section describes the equipment from an external viewpoint, allowing the user to become familiar with the various controls and connections provided.


1.1 General

The PC6 is housed in a three part anodised aluminium case with a liquid crystal display unit at the front and a six button membrane keyboard. The main body contains the circuitry, connections, internal transducer and battery pack.

1.2 Keypad


The Keypad is a non-tactile membrane keyboard with six buttons. The keyboard layout is shown below.

Note: An audible bleep accompanies every key operation.



1.3 Liquid Crystal Display (LCD)


The LCD is a 16 character x 2 line alphanumeric LED backlit display which is capable of displaying special characters.



1.4 Connection Panel (See Page 3, Fig 2)

The connection panel is located at the top of the case and provides input / output connections as detailed in Fig.2

1.4.1 A 3/8" BSP 'Quick-fit' coupling to accommodate the hand pump. 8mm O/D hose fitting on pump to connect to item under test.



1.4.2 An 8 way circular miniature connector is used for communication with RS232 standard communication protocols/equipment. The user software 'SiCalPro' (optional) can be used to remotely monitor or download data from the PC6 via this connector. (Optional RS232 cable - Part No. 01-0625)




1.4.3 The 2 way circular miniature connector is used for the battery charger (provided).



ARRANGEMENT OF PC6-AV


Front View: LCD & keypad

Fig 1



Top View: connection panel

Fig 2



FUNCTIONS (MENU 1)

PRESSURE DISPLAY - Allows the user to operate the PC6 for pressure measurements. (Display Functions)

Menu 1


	UNITS	Selection of pressure unit.	
	mbar	millibar	
	inHg	Inches of Mercury (at 4°C)	
	knots	knots (for absolute units see item 2.12, page 10)	
	kPa	kiloPascals	
	Mpa	Mega pascals	
	psi	pound force per square inch	
	kg/cm2	Kilogrammes force per square centimeter	
	atm	atmospheres	
	inH ₂ O	inches of Water (at 4°C)	
	mH ₂ O	meters of water (at 4°C)	
	mmH ₂ O	millimeters of water (at 4°C)	
	bar	bar	
	mmHg	mm of Mercury (at 0°C)	
	Unit1	First user defined unit	} Please see 3.6 page 23
	Unit2	second user defined unit	
	Exit	Returns to menu 1	
	ALT (ft)	Altitude in feet	} Refer to item 2.12, page 10 when using 'knots'.
	ALT (m)	Altitude in metres	
	QFF	Airfield barometric pressure at sea level.	
	MAX	Displays the maximum pressure measured since the last reset.	
	MIN	Displays the minimum pressure measured since the last reset.	
	%	Displays the pressure as a percentage between user pre-set high and low alarm values.	
	TARE	Displays the pressure at the time of tare.	
	Switch	Indicates the status of the pressure switch (OPEN/CLOSED)	
	Leak	Allows the PC6 to measure pressure changes over time.	
	Start	Starts the leak test.	
	Set-Time	Sets the leak test time.	
	Exit	Reverts back to pressure display mode.	
	Temp °C	Allows the user to monitor the temperature around the selected pressure transducer in pressure display mode.	
	Date & Time	Allows the user to monitor the date & time of the on board real time clock in pressure display mode.	
	File	Allows the user to view or manipulate a file previously stored in the filing system.	
	View	Allows the user to see stored file.	
	Export	Outputs a stored file.	
	Import	Imports a file from Sicalpro	
	Delete	Deletes a stored file.	
	Exit	Reverts back to pressure display mode.	
	Exit	Returns to Pressure Display mode. (<i>SHORTCUT: To abort any menu level, simply press the MENU key.</i>)	

FUNCTIONS (MENU 2)

SETTING MENU - To set user specific functions. (*Set Functions*)

Menu 2

ALT	<ul style="list-style-type: none"> Datum View Set 	<p>Configure altitude settings</p> <p>User defined setting</p> <p>Allows user to view current datum</p> <p>Allows user to define current datum</p>
OFF	<ul style="list-style-type: none"> ISA Exit Height Temp Exit 	<p>Displays 'International Standard Pressure'.</p> <p>Reverts back to pressure display mode.</p> <p>Configure QFF mode</p> <p>Sets Local height</p> <p>Sets local temperature</p> <p>Reverts back to pressure display mode.</p>
High		Allows the user to set a High Pressure Alarm Limit.
Low		(by using the increase/decrease facility above which an alarm sounds.)
Display Light		Allows the user to set a Low Pressure Alarm Limit.
Resolution		(by using the increase/decrease facility below which an alarm sounds.)
Event		Switches ON or OFF the LED back light.
		Selects high, normal or low resolution.
		Sets up the event status for RS232 output and for logging functions.
	<ul style="list-style-type: none"> Key Timed Exit 	Sets key driven output.
		Sets timed output defined by the user.
		Reverts back to pressure display mode.
Log		Allows the user to setup, amend and view files for logging.
	<ul style="list-style-type: none"> Log View Delete Status Export Import 	To select a log file and start logging.
		To look at a file.
		Deletes a file.
		To enable or disable logging.
		To export logged files.
		To import files from a PC. (see 'SiCalpro' software instructions for exporting files to the PC6)
RS2332		Settings for RS232 communications.
	<ul style="list-style-type: none"> Status Baud-rate Stop-bits Exit 	To enable RS232 communication.
		To select the baud rate.
		To select the number of stop bits.
		Reverts back to pressure display mode.
Date/Time		Sets up Date & Time parameters
	<ul style="list-style-type: none"> Set View Exit 	Sets the date & time.
		To look at date & time.
		Reverts back to pressure display mode
Language		Allows user to change language



Will reset pressure reading to Zero. (This will remove Zero offset permanently / NOT available for absolute units).

Selects current pressure modules (P1,P2,DPM)

Allows the user to set Power_Off time or to switch the function on or off.

Switches the auto-power function off.

Allows the user to set the auto-power off time in minutes.


Reverts back to Pressure Display.

Reverts back to pressure display mode.

FUNCTIONS (MENU 3)

CAL MENU

Menu 3




OPERATING INSTRUCTIONS

1.5 Switch Test Activate 'Switch' function in menu 1. The switching pressure of a pressure switch can now be monitored by connecting the contacts of the pressure switch between the INPUT 'GND' and 'SWITCH' sockets on the connection panel and pressurizing the pressure switch.

1.6 RS232

If the RS232 facility is to be used then connections to the 8-way socket must be made to the specifications given in the table below. Alternatively an RS232 communication cable can be purchased from SI suitable for most RS232 applications as shown below.



RS232 Connections Table

PIN No.	INPUT/OUTPUT	SIGNAL	STATE
1	Output	Data Terminal Ready (DTR)	Held High
2	Output	Transmit Data (TxD)	
3	Input	Receive Data (RxD)	
4	Output	Request To Send (RTS)	
5	Input	Clear To Send (CTS)	Active High
6	Output	Do not use	
7	Common	Ground	
8	Input	Do not use	

Note: 1. Pin 6 and pin 8 should not be used.

RS232 Output

Connect the PC6 to a printer or computer using a suitable cable (not supplied) as detailed above and set the parameters as detailed in Para. 2.9 & 3.1. The output can now

be obtained as 'single shot' or 'timed' as follows:

Single Shot - This output is always available in Display mode when RS232 status & Log status are OFF. The output is obtained each time the **PRINT LOG** key is pressed (provided any previous output is complete).

Warning: The PC6-PRO must be switched off prior to connecting or disconnecting the RS232 cable.

Timed - This output is available in Display mode when RS232 status is ON & Log status is OFF. The output cycle is initiated by pressing the **PRINT LOG** key. Pressing the **MENU** key cancels the output. Once initiated, the output is repeated at the selected time interval (see 'Event' function, page 26) until the **MENU** key is pressed.

1.6.1 Charger The internal battery pack may be recharged (when indicated by the battery low message) by plugging the charger (supplied) into the 'CHARGER' socket of the PC6.

CAUTION: When recharging internal batteries, only the charging unit supplied with the PC6 should be used.

1.7 Messages & Parameters

The PC6 registers pressure input at switch on after the initial start-up message. The pressure reading is displayed in the top left hand corner of the LCD (Fig.3 Page 2). Pressure values are monitored, alarm values are compared, alarm warnings and other information messages displayed until the PC6 is switched off.

Memory Errors:

Any read / write errors to memory detected at switch on will be reported as: Memory Error 'Error No.:'

Error Numbers:-

0 - Onboard eeprom; 8 - RTC; 9 - 2nd Onboard eeprom.

Errors with Pressure Modules will be indicated by the message: "No P1 (or P2 or DPM) Module" preceded by "PM EEPROM ERROR" at power on.


1.7.1 When switched on, the PC6 registers the same state as when last switched off. The display mode (Operating/Set), units of measurement, function and parameter settings, alarm limits and RS232 output control, logged parameters are all retained at switch off, with the exception of the following conditions :

1.7.2 A battery low state occurring prior to the switch off. When switched on, the PC6 registers the latest retained set of parameters.

1.7.3 Any TARE value set during use is not retained and therefore should be set, if required, each time the PC6 is switched on.

1.7.4 Maximum and Minimum values are not retained. Current values reflect pressure monitored from the start of the pressure input.

1.7.5 If the PC6 is switched off during a LEAK test then the test will be void. When switched on again the PC6 will start up in LEAK test mode.


1.7.6 *Switch off* When the  key is pressed the 'switch off' message is displayed for five seconds accompanied by an audible bleep. Normal operation may be resumed by pressing any key during switch off.

1.7.7 *Auto Switch off* The PC6-PRO will automatically turn itself off after a set period (See Page 20 for instructions)


1.7.8 *Pressure Overload* (Bleep rate 4 Hz) 'OVERLOAD' occurs when input pressure exceeds overload pressure level.

1.7.9 *Low Battery Detect* (Bleep rate 1 Hz). 'Low Battery' occurs when internal battery pack drops below 5.5V. Message flashes for 4 seconds, after a further 30 seconds, low battery detection is re-enabled.

1.7.10 *Pressure Switch State Change* (Bleep rate 2 Hz)

Occurs in pressure mode with the pressure switch state display being selected. When the connected pressure switch changes state, the pressure value (upper line) is frozen and the pressure switch state (lower line) display is flashed at 1 Hz unless a log file is open. Normal display update resumes when the  key is pressed.


1.7.11 Printer Busy (Bleep rate 1 Hz)

If the receiving device is not ready for input (e.g. device not connected or handshake LOW), 10 seconds after starting an output cycle (single shot or timed output) the message 'Printer Busy' is flashed on the display, together with an audible warning. If the device does not accept input within the next 5 seconds then the output cycle is canceled and output is stopped until the  key is pressed again.

1.7.12 Outside User Set Alarm Values (Bleep rate 2 Hz)

Occurs when measured pressure is lower than the user set Low alarm value or greater than the user set High alarm value and the 'outside limits' message is flashed. Indication ceases when pressure is equal to either alarm value or between the values.

1.7.13 Display Hold (Bleep rate 2 Hz)

Occurs in pressure mode. If the  key is pressed once (less than 1 second) the pressure value (upper line) is frozen and the lower line is flashed with the 'Display Hold' message at 1 Hz. Normal display update resumes when any top row key is pressed.

1.7.14 RS232 Output Format

The output format is as follows:
LF
Time & date 23:13:30 220997 +LF
display top line (16 characters) + LF
display lower line (16 characters) + LF
alarm flag (1 character) + LF
Null terminator (0)


1.7.15 Alarm Flags

A single character is output to indicate

the various pressure alarm conditions as given below:

- * overload pressure level exceeded (pressure warnings, 1.7.8 & 1.7.12)
- > pressure exceeds user set high limit
- < pressure below user set low limit
- " " a space if no alarms apply.

1.7.16 Display Symbols



Note: If two (or more) conditions occur which require a message display, the highest priority condition in the above list will be displayed. The sequence of messages given above set the priority except 'Switch Off' which comes last.

1.7.17 Alt (height) warning

An "Out of Range" message is displayed if the height exceeds 105,000 ft or is less than -3000 ft (32004m, -914.4m)





1.7.18 Knots (limits)

An "Outside limits" message is displayed if the reading exceeds 600 knots.

HOW TO SELECT FUNCTIONS (MENU 1)

1.8 Units

To change the units of pressure, proceed as follows:

- Press the  key once, then press  key to choose the units sub-menu
- Select required unit by pressing the  key and then press  key.

The display will indicate the pressure in the selected unit and the pre-selected 2nd line function.

1.9 Alt (ft) *(when using 'knots' on absolute units, refer to item 2.12)*

To display altitude in feet:

- Press the  key once. Use the  key to select 'Alt (ft)' option and then press the  key to accept.




1.91 Alt (m) *(when using 'knots' on absolute units, refer to item 2.12)*

To display altitude in metres:

- Press the  key once. Use the  key to select 'Alt (m)' option and then press the  key to accept.

2.0 QFF *(when using 'knots' on absolute units, refer to item 2.12)*





This mode measures the sea level pressure using local height and temperature correction. To set the local values refer to item 2.5 on page 14. To display 'QFF' correction:

- Switch the unit on 
- Press the  key once and select 'QFF' using the  key

and press the  key to accept.



2.1 Max, Min, Temp°C, Date & Time, %, Switch


To display one of these functions, proceed as follows:

- Press the  key once and then scroll to the required function using the  or  key and then press  key to select it.

The LCD will show the pressure on the top line and the 2nd line will display the function that has now been selected.

2.11 Tare:

The Tare value can be displayed on the bottom line by selecting 'Tare' from the menu using the  key and pressing the  key.




To activate Tare function: hold down the  key for 4 seconds while in the pressure display mode. The unit will beep after two seconds when the Max. and Min. values reset. At four seconds another beep will sound as the displayed pressure now resets to zero. This is a temporary function and will be cancelled when the unit is switched off.

2.12 Knots (absolute units)

When using the 'knots' unit on an absolute PC6, use the tare function as described above before proceeding. Selecting 'Alt (ft)', 'Alt (m)' or 'QFF' whilst measuring knots, the second line of the display will default to 'Max' mode.

2.2 Leak Test

To carry out leak tests, proceed as follows:

- Press the  key once and scroll to the 'Leak' function using the  key. Press  key to select.

Presented with the leak test sub menu, the options 'Start' and 'Set Time' are given as shown below.



```
Leak: Start
Set-Time Exit
```





Leak Sub-menu


'Set Time' To set the duration of the leak test.

Scroll using the  key to select 'Set Time' and press the  key.





```
Leak: Start
Set-Time Exit
```

With the first digit now flashing, press  and then select the number required using the   keys and press  key. (e.g. time set to 999 min.)





```
Leaktest:
Duration 900Sec
```

With the second digit flashing, press  and again select the number required and press  key.






```
Leaktest:
Duration 990Sec
```


Repeat procedure for third number and press  key.




```
Leaktest:
Duration 999Sec
```

Now select the units of time measurement (e.g. seconds, minutes, hours, days, etc.) Scroll through the units with the

  keys and press .



```
Leaktest:
Duration 999Min
```




Once the leak test time has been set press the  key to return to the leak test sub-menu.

- Select 'Start' using the   keys and press  to start the leak test.



```
0.0000 inHg
0.0000 999Min
```



The top line shows 0.0000 pressure and the bottom line shows the current pressure.

- Start the leak test by pressing the  key.
- The top line displays the difference in pressure while the bottom line shows the start pressure and the time counting down.
- When the leak test has finished, to start the leak test again press the  key once to reset the time and again to start the test.
 - If no other leak test is to be carried out, press the  key to return to the leak test sub-menu.

2.3 File







This function allows the user to view, export, Import and delete previously stored files.


To use the filing system proceed as follows:



- Switch the unit on.
- Press the  key once and scroll to 'File' using the  key and press .





2.3.1 To view a file, proceed as follows:

- Select 'View' using  key and press .
- The latest filename is shown in the bottom left hand side of the display. The record count is shown in the bottom right hand side. To select this file press . If another file is required then scroll through the filenames using the   keys and then press .



- To move through the record now selected, press the  key or the  key. This will first show the 'IPM / EPM' serial number from which data was read.




- To view the following records in the selected file use the  or  key to advance to the next screen.


Date & Time →



Pressure Data →




2nd line function →







One Complete Reading

Next reading →




Time & Date →

Pressing the  or  key will enable the user to go through the records. Once the last record has been viewed an ****END**** message is displayed.






The records then 'wrap around' so the user can move to the first or last file record using the   keys.

Note: At the time of logging, if the pressure is above or below the set limits then a 'High' or 'Low' message will appear after the Pressure Data screen.



2.3 File (continued)

2.3.2 To *Export* a file, proceed as follows:




- Scroll the cursor using the  key and select 'Export' and press the  key.
- Select a file to export using the   keys and press the  key

For export to SicalPro, please do not press the Enter key after selecting the file.





```
File: Export:
Abc 0010 N
```

2.3.3 To *Import* files, proceed as follows:

- Scroll to 'Import' using the  key. Once you finished a calibration procedure in 'SiCalPro', click on 'Export', press the  key on the Pc6 to download. The message "downloading Cal" will be displayed. Once SiCalPro gives "All done" message, press the  key. Choose 'Yes' when prompted to 'Stop?'






2.3.4 To *Delete* files, proceed as follows:


- Scroll the cursor using the  key and select 'Delete' and press the  key.

The following options are available:





```
Delete: File All
Exit
```

- If you want to delete a particular file then select 'File' using the  key and then press the  key.
- Select a file to delete using the   keys and press the  key.






```
Delete: File:
Abc 0010 N
```

The  will then display:






```
Delete: Sure?
Yes No
```


If you are sure that the file is to be deleted then the 'Yes' option should be selected using the  key and then entered using the  key.

Once the operation  is completed the display will return to the 'File' sub-menu.


If another file is to be deleted then repeat the procedure.

If no more files are to be deleted then press the  key to return to the pressure display.


Note: Pressing the  key once at any time during the procedure will take you  back to the 'File' sub-menu.

If all the files in the PC6-PRO are to be deleted then select 'ALL' in the Delete sub-menu and press the  key.

The following message is displayed:





```
Delete: Sure?
Yes No
```

Select 'Yes' or 'No' and press the  key.












SET- MENU (MENU 2)

2.4 Alt

To set or view a user defined datum or use the standard pressure setting (ISA) proceed as follows:

- Press the  key twice to enter the 'Set' menu.
- Select 'Alt' and press the  key.

Datum:

- Select Datum using the   keys and press the  key to accept.
- Select 'View' and press the  key. This function displays the last defined datum and sets this as the current datum.
- Select 'Set' and press the  key. This function allows the user to input a new datum.
- Select the digits to be changed by moving the cursor with the   keys and pressing the  key.
- Change to the required value using either arrow key and press the  key to accept. Pressing the  key again will move the cursor to the next digit.
- When complete, press the  key to return to pressure display.




ISA:







To set datum to the 'International Standard Atmosphere' (1013.25mbar):

- Press the  key twice. Select 'Alt' and press the  key.
- Select 'ISA' and press the  key to accept

2.5 QFF

This is the meteorological presentation of barometric pressure at mean sea level and is a calculated value based on the local height above sea level and the local temperature.

- Press the  key twice and select 'QFF' using the  key.
- Press the  key to accept.

- Select 'height' and press the  key.
- Using the   keys and the  key, change the local height value as required. Press the  or  key to accept.
- Repeat the above procedure to set the temperature.

The local barometric pressure (QFE) should be measured in mbar. The correction term (QFF_{cor}), in mbar, to be added to the QFE, is calculated as follows:

$$QFF_{cor} = p(10^{m-1})$$

$$\text{where } m = \frac{h}{18429.1 + (67.53 \times t) + (0.003 \times h)}$$

p = pressure (QFE) in mbar










h = height of instrument above mean sea level (metres)

t = the local air temperature °C


2.6 Alarm settings 'High', 'Low'

Note: Not available when reading 'knots'

To set High or Low pressure warning limits proceed as follows:

- Select the 'Set' menu by pressing the  key twice.
- Select 'High' or 'Low' using the  key and then press the  key.
- Select the digits to be set by moving the cursor with the   keys and pressing the  key.
- Set the number to the required value using the   keys and then press the  key.
- Repeat the previous two steps to change other digits for the alarm value.









- Once finished setting the alarm limit value press the  key to return to the pressure display.


A beeping warning (2 Hz) and the 'Outside Limits' message will signal that the measured pressure is lower than the user set low alarm value or greater than the user set high alarm value. The beeping ceases when the pressure is read between the two values.

Note: The PC6 will not allow pressure values to be entered greater than 5% above the maximum working range.

2.7 Display Light




This function may be selected as follows:

- Press the  key twice to select the Set menu.
- Select 'Display-Light' using the   keys and then press the  key.
- Select 'ON' or 'OFF' using the  key and then press the  key.

Note: The display light can also be set On or Off by holding down the  key for more than 2 seconds. The back light is turned off when the PC6 is switched off.

2.8 Resolution

To change the resolution proceed as follows:




- Press the  key twice to select the Set menu.
- Select 'Resolution' using the   keys and


press the  key.

- Select the required resolution (High, Low or Normal) using the   keys and then press the  key.

Note: Resolution will change by a factor of 10.

2.9 Event

- Press the  key twice to select the Set menu.
- Select 'Event' using the  key and then press the  key. The Event menu is shown below:



Key:

This results in RS232 output / data storage triggered by key press.





- Select 'Key' using the  key and then press the  key.

Timed:




This results in RS232 output / data storage at fixed time intervals set by the user.

- Select 'Timed' using the  key and then press the  key.





- Select the digit to be modified using the  key and press the  key. Use the   keys to change


the value and press the  key.

- Repeat for next digit and press the  key.
- Change the time measurement units in the same way and press the  key.
- Press the  key to return to pressure display mode.



3.0 Log

- Switch on PC6.
- Press the  key twice, scroll to and select 'Log' and press .

The display gives the option to log a file, view a file or change the log status as shown below:



Log:

- Select 'Log' using the  key and then press the  key.
- Presented with the sub-menu, enter a filename and record count if no files are present, or select a file to log into.






'N' = Normal Log
'C' = Calibration procedure log (requires 'SiCalPro' software)




filename


record count


To enter a filename: (max. 8 characters)

- Using the   keys, move to the filename position

and press the  key.






- Select the characters/numbers to be used to name the file by scrolling up or down at each position and press the  key when completed.
- Press the  key to move on to the record count.
- As with the filename, define the record count and then press the  key when completed.
- If a file has already been set up with the same name then the 'Overwrite' option screen will be displayed.





- Start logging by pressing the  key. (see 2.6 'Event' on page 26).


The  symbol will appear to show file is open.




View:

- Select 'View' from the log menu using the  key and then press the  key.
- Select the file to view using the   keys and then press the  key.

3.0 Log continued





- With the file now selected, use the  or  key to show the file contents in the sequence shown below.



Note: Use the  or  key to scroll the other way. The direction in which the scrolling moves when using the  key depends on the last key pressed.





Delete:


To delete a logged file, proceed as follows:

- Select 'Delete' from the log menu using the  key and then press the  key.
- Select 'File', 'All' or 'Exit' using the  key and then press the  key.






File:

- Using the   keys, select a file and then press the  key.
- A confirmation to delete file prompt is given. Select 'Yes' or 'No' and then press the  key.





All:

- Select the 'All' option using the  key and then press the  key.
- A confirmation to delete all prompt is given. Select 'Yes' or 'No' and then press the  key.



All Files stored on the PC6 will be deleted.

Exit:


- Select the 'Exit' option using the  key and then press the  key.

Status:

Use this option to enable or disable logging function.


- Select 'Status' from the log menu using the  key and then press the  key.





- Select 'On' or 'Off' and then press the  key.
- The display returns to the log menu.

Once a file has been set using the instructions given, the logging process is shown as active with a disc shaped icon in the top left hand corner of the display.

If you should press the  key whilst logging is in progress then the following screen appears:



Select 'Yes' or 'No' and then press the  key.




Note: Pressing the  key allows direct access to the log menu. This is only possible if the log status icon is flashing in the top left hand corner of the display.

Export:

See '2.1 File on page 14. For export procedure.

3.1 RS232

RS232 standard communication protocol is available on the PC6. Select the RS232 functions as follows:






- Connect the PC to a printer or computer as described in paragraph 1.6 on page 7.
- Switch on PC6.
- Select the Set menu by pressing the  key twice.
- Select 'RS232' option using the  key, then press the  key. The RS232 menu is displayed as below:








Status:

- Select 'Status' using the  key. Choose 'On' or 'Off' option with the  key and then press the  key. The display returns to the RS232 menu.

Baud Rate:




- Select 'Baud-rate' using the  key and then press the  key. Select the required baud rate (1200, 2400, 4800 or 9600) using the   keys and then press the  key.

Stop Bits:

- Select the 'Stop bits' using the  key and then press the  key. Select either 1 or 2 bits with the   keys and then press the  key.

3.2 Date & Time

To select Date & Time proceed as follows:







- Switch on PC6.
- Press the  key twice to select Set menu.
- Select 'Date & Time' option using the  key and then press the  key.




To set the time:

- Select 'Set' using the  key, then press the  key.



- Select the digit you want to change using the  key and press  key. Use the   keys to change the value and then press  key.
- Repeat the above step to change the other digits to set time and proceed to the next set of digits to change the date.
- Press the  key to return to the 'Date & Time' menu.




To View date & time:

- Select 'View' using the  key and then press the  key.
- Press the  key to return to the Date & Time menu.

3.3 Zero (not available on absolute units)

Note: Unlike the 'Tare' function (page 15), 'Zero' reset is a permanent setting.

To reset pressure reading to zero:

- Press the  key twice to select the Set menu.
- Select 'Zero' option using the  key and then press the  key.





- Press the  key as instructed.


The Pressure Display will now show the pressure value as zero. If however the pressure reading is not within 5% Full Scale the following message will be displayed and the zero reset will not be possible.



3.4 Language

- Press the  key twice.
- Scroll to 'Language' using either arrow key and press the  key to select.










- Select the desired language from the options provided and press the  key.

Note: To download different languages, see 3.7 on page 23.

3.5 Power_Off

The PC6 has an auto-power off function. The time after which the unit automatically switches off is adjustable from 1 to 999 minutes. However, the auto-power off will not operate under the following conditions:-

- If a key has been pressed during the auto-power off time period.
- If a leak test is running.
- If the RS232 Status is On.
- If the Log Status is On.
- If the unit is online with Sical Pro

- Press the  key twice.
- Scroll to 'Power_Off' function using the  key and press the  key.
- Select 'Key' to turn the auto-power function off.
- Select 'Timed' to set the auto-power off time (in minutes) and press the  key. This automatically turns the auto-power function on.
- Set to desired time using the   keys and press the  key.

CAL-MENU (MENU 3)

Important note:


Should you wish to change zero or span settings at any time, the original calibration made at time of manufacture by **SI Pressure Instruments** will no longer apply. We therefore take no responsibility for any false or inaccurate readings that occur after any changes to span have been made. If the temperature of the pressure sensor is outside the range of 15 to 25°C it will not be possible to perform the span operation.

Calibration Procedure:

If necessary then the span calibration should be made using a deadweight tester with an accuracy of 0.01% of reading or better, and carried out in a temperature controlled environment at 20°C ±2°.

To maintain the accuracy of the calibrator, do not increase the value of 'tol-ppm' above 50 (see flow charts).

For full calibration which includes Temperature Compensation between 0-50°C the PC6 should be sent back to **SI Pressure Instruments**.

To access the Cal Menu, press all four top row buttons at the same time. A beep will accompany this action. Press the  key three times. The functions available are as follows:



Note: Password


To gain access to the ‘Span’ and ‘Units’ functions, you will be asked to enter a password. Enter the four-digit serial number located on the label on the rear panel of the unit.








3.6 Span:

Note: The pressure value at which span is carried out is adjustable up to $\pm 5\%$ of the unit’s full scale range.

To set span:




- Select ‘Span’ using the  key and press the  key
- A ‘Warming up...’ message will be displayed and after several seconds you will be prompted to release pressure and then press ‘ENTER’ to continue.
- The following screen will then be displayed asking you to set a tolerance.




- If you want to change the tolerance value displayed then press the  key to select the first digit.
- Using the   keys, change the first value and then press the  key to enter it. The next digit will then be selected. Press the  key and change the digit as described above.
- Do the same for the third digit if required and then finish by pressing the  key once more.
- If however the value shown does not need to be changed then press the  key to continue.
- The following message is then displayed:





Example Value


- After pressing the  key twice and waiting for the fifty readings to be taken, you will be prompted to input pressure up to the maximum value of the sensor in that particular unit. Press the  key.
- The unit will now take another fifty readings.
- Provided the readings are within tolerance and 5% of Full Scale you will receive the ‘COMPLETED’ message.
- Press the  key to finish and return to the ‘Cal menu’.

Notes: If at any time during the procedure you wish to exit and return to the ‘Cal menu’ then press the  key. The message: ‘Sure ? No Yes’ appears. Select ‘Yes’ to exit or ‘No’ to continue with the zero calibration.

Absolute: For absolute units you will be presented with the following screen. It displays the current pressure reading on the top line and on the second line you set the corrected value.




Set the required value and press the  key. Select ‘Yes’ or ‘No’ at the next screen and press the  key.






The pressure display will now show the new value.

3.7 History:


- Press the  key to view the sub-menus.


Overload:







- To view the overload history move the cursor to 'overload' and press the  key. The display will show the cumulative time since the unit was last calibrated as in the example below:
- Press the  key to return to the 'cal menu'.




Span:

- To view the last zero calibration date move the cursor to 'zero/span' and press the  key.




- As shown above, the last calibration date is displayed first.
- Pressing the  or  key takes you to the next screen showing the 'last span set' date.
- Pressing the  or  key again the display shows the range of the unit and the overload setting.
- Press the  key to finish.
- Press the  key to exit to pressure display mode.

PC6 Serial Number:


- To view the unit's serial number move the cursor to 'PC6S/No' and press the  key.

Pressure Module Serial Number:

- To view the serial number of the selected pressure module, move the cursor to PM_S/No and press the  key. The accuracy of the sensor will be displayed on the lower line.

3.8 Language: (separate pc software utility needed -contact supplier)

To download different languages:-






- Connect PC6 to PC via the RS232 cable.
- Scroll to 'Language' and press the  key to select.
- The PC6 will display a 'DOWNLOADING' message until language download is complete.

3.9 Units User-defined unit conversion factors and the text associated with them:-

View:

- Select 'Units' using the  key and press the  key.
- Select 'View' by pressing the  key.
The first user-defined unit will now be displayed with the text on the upper line and the conversion factor on the bottom line. Pressing any key will display the next user-defined unit.

Alter: (to modify the user-defined units)


- Select 'Alter' using the  key and press the  key.
- The text for the user-defined unit is modified first using the  and  key.
- Press the  key when finished.
- Now modify the conversion factor as above. The conversion factor is the number of user-defined units per bar.

Repeat process if required for the second user-defined unit.


- **Note:** To prevent confusion, it will not be possible to enter text for a user-defined unit that is identical to a factory-set unit in the PC6. Additionally, the maximum value for the conversion factor is 100,000.

FLOWCHARTS


*Menu 1
display menu*





*Menu 2
set menu*





*Menu 3
cal menu*





Menu 1 sub-menu unit & Leak



Menu 2 Alt & QFF




Menu 2 High & Low




* Once finished editing press the **MENU** Key to go back to Pressure Display


Menu 2 Display light & Resolution



Menu 2 Event & RS232






Menu 2 sub-menu Log





* ENTER_ZERO not necessary for file export to 'SiCal PRO'.


Menu 2 Date&time, Language, Zero, Port, Power off




Menu 2 *Date&time, Language, Zero, Port, Power off*




Menu 3 cal-menu Span




Menu 3 cal-menu History



Menu 3 cal-menu Language



Menu 3 cal-menu Units




PRESSURE GENERATION

OPERATING INSTRUCTIONS FOR THE HAND HELD PRESSURE TEST SYSTEM - TP1

KEY:

1. Pressure port - 3/8" BSP Parallel female connection to take master instruments e.g. digital or analogue gauge, PC6 Calibrator.
2. Fine adjustment valve.
3. Pressure release valve.
4. Pressure / Vacuum selector
5. Adjustable stroke for varying maximum pressure output (over pressure protection).
6. Nylon seals (see seal kit provided) **DO NOT use 'PTFE' tape for sealing with parallel threads**
7. Pressure port - 8mm



The system is a portable dual source of vacuum and pressure. Each system incorporates a vacuum / pressure selector, a volume control for fine adjustment and adjustable stroke to provide over pressure protection.

RELEASE VALVE (3)

This can be used to reduce or release the pressure in the system. The rate of pressure reduction is dependent upon the degree of rotation when opening the valve. Minimal force is required to seal the system.

VOLUME CONTROL (2)

The pressure generated can be finely adjusted by turning the fine adjustment valve (2) either clockwise or anticlockwise to increase or decrease pressure accordingly.

OVER PRESSURE PROTECTION (5)

To adjust the maximum output pressure of the system turn the nuts (5) to increase or decrease the stroke length.

IMPORTANT

Under no circumstances should the fine adjustment valve (2) be wound back beyond the red line indicator on the body. Should this occur, then the pressure must be released from the system before attempting to re-engage the fine adjustment valve.

PRESSURE/VACUUM SELECTION (4)

Press the selector (4) as indicated on the label to engage the desired mode. Ensure that the release valve (3) is fully closed (clockwise motion) prior to pumping.


NOTE

The system should only be used for pressurising small volumes due to its small displacement.

If the system has not been used for a period of time, it could be difficult to operate on the first stroke.

The cylinder has been lightly greased on assembly but, if additional lubrication should ever be required, then apply a minimal amount to the inside of the cylinder.

Access is via the three retaining screws located under the black collar.



Guidelines for use:

1. Connect item under test to pressure port (7)
2. Screw fine adjustment valve (2) fully clockwise.
3. Screw fine adjustment valve (2) 4 - 6 full turns anticlockwise.
4. Screw pressure release valve (3) fully clockwise, tightening to ensure good seal.
5. Operate handles until the pressure is close to that finally required. **Ensure handles are fully squeezed together on each stroke to achieve maximum pressure output.**
6. Wind the fine adjustment valve (2) clockwise to increase pressure or anticlockwise to decrease pressure until required pressure is reached.

Note: The pressure may take up to 1 minute to settle after increasing pressure due to thermodynamic effects, settling of seals, etc.

Caution: NEVER screw the fine adjustment valve (2) beyond the red line indicator.

7. Reductions in pressure can also be achieved by careful use of the pressure release valve (3).
8. Vacuum is achieved using the above procedure and having the changeover valve (4) pushed completely towards the vacuum position.

Fault Investigation.

In the event that the system appears to lose pressure then the procedure above should be repeated ensuring new seals are used, adaptors are tightened sufficiently and the pressure release valve (3) is tightened firmly.

Note: The connections to the hand held test system are sealed with 'o' ring or bonded seals and should not leak. The pipe to body connection can be checked but tightened no more than 2 Nm.


DO NOT attempt to tighten the other fittings to the test system as this could lead to damage of sealed joints. When testing for leaks it may be noticed that air is drawn in or expelled from around the changeover valve. This is normal and should cause no concern.

OPERATING INSTRUCTIONS FOR THE LOW PRESSURE HAND PUMP - LTP1

Key:

1. Pressure release valve.
2. Fine adjustment control.
3. Pressure / Vacuum selector.
4. Two push-fit connectors to take 4mm OD hoses to item under test and master instrument.
5. Two flexible hoses with 1/4" BSP female adaptors to item under test and master instrument.
6. Pump Handle.
7. Nylon seals (see seal kit provided) **DO NOT use 'PTFE' tape for sealing with parallel threads.**
8. Pressure Relief Valve.

The pump is a portable dual source of vacuum and pressure. Each pump incorporates a vacuum / pressure selector and fine adjustment control.



RELEASE VALVE (1)

This can be used to reduce or release the pressure in the system. The rate of pressure Reduction is dependent upon the degree of rotation when opening the valve. Minimal force is required to seal the system.

FINE ADJUSTMENT CONTROL (2)

The pressure generated can be finely adjusted by turning the fine adjustment control (2) in or out to increase or decrease pressure accordingly.

IMPORTANT

Do not wind the fine adjustment control (2) any further when the top of the pump body is visible.

PRESSURE/VACUUM SELECTION (3)

Press the selector (3) as indicated on the label to engage the desired mode. Ensure that the release valve (1) is fully closed (clockwise motion) prior to pumping.

PRESSURE PORTS (4)

The hoses (5) are fitted by simply pushing them into the connectors (4) until resistance is felt. To remove the hoses, press the collar in on the connector while pulling on the hose.


PRESSURE RELIEF VALVE (8)

The maximum output pressure can be set using the pressure relief valve located inside the main piston, accessed via the handle retaining screw.

NOTE

The pump should only be used for pressurising small volumes due to its small displacement. If the pump has not been used for a period of time, it could be difficult to operate on the first stroke.

For seal replacement, refer to service kit LTPK1 instructions.



WARNING: DO NOT CONNECT LTP1 TO EXTERNAL PRESSURE SOURCE.

Guidelines for use:

1. Calibration / Comparison against Analogue gauge

- 1.1 Connect a Test Gauge to pressure port at the end of one of the flexible hoses (5).
- 1.2 Connect item under test to the pressure port at the end of the second flexible hose (5) choosing correct adaptors and seals.
Note: Ensure seals are fitted and adaptors tightened to a maximum torque of 15 Nm.
- 1.3 Screw fine adjustment control (2) in fully and then out 4 - 6 full turns.
- 1.4 Screw pressure release valve (1) in fully, tightening to ensure good seal.
- 1.5 Using a small screwdriver, adjust the pressure relief valve (8) to set the desired maximum output pressure. Turn the grub screw located in the main piston clockwise to increase or anti-clockwise to decrease the pressure setting.
- 1.6 Operate handle (6) until the pressure is close to that finally required.

1.7 Wind the fine adjustment control (2) in to increase pressure or out to decrease pressure until required pressure is reached.
Note: The pressure may settle for up to 30 seconds after increasing pressure due to thermodynamic effects, settling of seals and expansion of the flexible hose.

Caution: STOP unscrewing the fine adjustment control (2) when the top of the pump body becomes visible.

1.8 Reductions in pressure can also be achieved by careful use of the pressure release valve (1).

1.9 Vacuum is achieved using the above procedure and having the pressure / vacuum selector (3) pushed completely towards the vacuum position.

2. Use With High Resolution Pressure Calibrators

When used with instruments such as the PC3 and PC6 Calibrators the connections and use are as for gauges above, however the higher resolution available will amplify the visibility of the thermodynamic effects as mentioned in paragraph 1.7. These will settle to useable values within one minute of pressurisation.

Note: On very high resolutions such as 1 mbar or 0.1 inches of water, small movements of the pipe may result in noticeable pressure changes.

3. Fault Investigation.

In the event that the pump appears to lose pressure then the procedure above should be repeated ensuring new seals are used, adaptors are tightened sufficiently and the pressure release valve (1) is tightened firmly.

Note: The connections to the hand held test system are sealed with 'o' ring or bonded seals and should not leak.

DO NOT attempt to tighten the other fittings to the pump as this could lead to damage of sealed joints.

When testing for leaks it may be noticed that air is drawn in or expelled from around the pressure / vacuum selector. This is normal and should cause no concern.

INDEX

A

accuracy..... iv
 activate a function..... iii
 alarm..... 14
 Alt4,5,10
 arrangement..... 3
 auto switch off..... 8

B

battery..... iv, 7
 baud-rate..... iv, 7

C

cal menu..... 20, 22
 charger..... 7
 connection panel..... 2
 coupling..... 2, 3

D

data entry..... iii
 date & time..... 19
 datum 5, 14
 display (LCD)..... 2
 display light..... 15
 display hold..... 9

E

enter..... iii
 Event..... 15

F

file 12
 flowcharts..... 22
 functions..... 4

H

hand pump..... 33
 high..... 14, 25
 history21, 32

I

input..... 2
 ISA 5, 14

K

keypad..... 1
 knots iv,9,10

L

LCD..... 2
 leak..... 11
 log..... 16, 28
 low..... 14, 25

M

maximum (Max)..... 10
 menu selection..... iii
 messages & parameters.... 8
 microprocessor..... iv
 minimum (Min) 10

O

overload..... iv, 8
 over range..... 9

P

password20, 31
 pressure generation 33
 pressure range..... iv
 print..... 7

Q

QFF4,5,10
 quick reference..... iii
 quick connect coupling.... 3

R

resolution..... 15
 RS232 7, 18

S

safety warning..... ii
 set menu..... 14, 22
 software..... 2

span 20
 specifications..... iv

T

tare..... 10
 temperature.....10
 test..... 10

U

units..... 10

W

warning..... ii

Z

Zero.....19, 20
 zero calibration 20