


EA003

OPTICAL TACHOMETER CALIBRATION ADAPTER



OPERATION MANUAL

EA003

Optical Tachometer Calibration Adapter

Operation Manual

Guarantee and service

Transmille Ltd. guarantees this instrument to be free from defects under normal use and service for a period of 1 years from purchase. This guarantee applies only to the original purchaser and does not cover fuses, or any instrument which, in Transmille's opinion, has been modified, misused or subjected to abnormal handling or operating conditions.

Transmille's obligation under this guarantee is limited to replacement or repair of an instrument which is returned to Transmille within the warranty period. If Transmille determines that the fault has been caused by the purchaser, Transmille will contact the purchaser before proceeding with any repair.

To obtain repair under this guarantee the purchaser must send the instrument in its original packaging (carriage prepaid) and a description of the fault to Transmille at the address shown below. The instrument will be repaired at the factory and returned to the purchaser, carriage prepaid.

Note :

TRANSMILLE ASSUMES NO RESPONSIBILITY FOR DAMAGE IN TRANSIT

THIS GUARANTEE IS THE PURCHASER'S SOLE AND EXCLUSIVE GUARANTEE AND IS IN LEIU OF ANY OTHER GUARANTEE, EXPRESSED OR IMPLIED.

TRANSMILLE SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES OR LOSS.



Transmille Ltd.
Unit 4, Select Business Centre
Lodge Road
Staplehurst
Kent
TN12 0QW
United Kingdom

Tel : +44 0 1580 890700

Fax : +44 0 1580 890711

E-Mail : sales@transmille.com

Web : www.transmille.com

TABLE OF CONTENTS

GUARANTEE AND SERVICE	2
EA003 OPTICAL TACHOMETER CALIBRATION ADAPTER	4
INTEGRATED RPM MODE FOR DIRECT CONTROL.....	4
EXTERNAL ADAPTER TO PROVIDE OPTICAL TRIGGERING OF TACHOMETER INSTRUMENTS	4
OPTICAL TACHOMETER CALIBRATION ADAPTER - OPERATION.....	5
<i>Optical Tachometer Calibration Adapter Connection.....</i>	<i>5</i>
<i>Starting the Optical Tachometer Calibration Option</i>	<i>5</i>
<i>Optical Tachometer Calibration Option Operation.....</i>	<i>6</i>
CARE & MAINTENANCE.....	8
<i>Cleaning the Adapter</i>	<i>8</i>
<i>Handling Precautions</i>	<i>8</i>
<i>Servicing Information</i>	<i>8</i>
Appendix A : Specifications	


EA003 Optical Tachometer Calibration Adapter



- Complete solution calibrates optical tachometers up to 60,000 RPM
- Complete with adapter unit incorporating high intensity LED
- Easy to use
- Works with ProCal & 3000 Series Virtual Front Panel Software

Simply connect the adapter to the feature connector on the 3000 series calibrator, select the RPM mode and value and point the tachometer at the high intensity LED to perform accurate and repeatable calibration, removing the need for ad-hoc setups and de-skilling calibration of these instrument types.

Integrated RPM Mode for direct control



The 3000 Series calibrators incorporate a dedicated RPM mode to control the optical tachometer adapter

External Adapter to provide optical triggering of tachometer instruments




Connects directly to the adapter interface connector on the 3000 series calibrator. Incorporates high intensity LED.

Optical Tachometer Calibration Adapter - Operation


Optical Tachometer Calibration Adapter Connection

Using the supplied adapter connection lead (9 way 'D' type to 9 way 'D' type), connect the optical tachometer calibration adapter to the feature connection on the front panel of the 3000 series calibrator.



Starting the Optical Tachometer Calibration Option

To start the oscilloscope calibration option, press the softkey below the menu item




Thermocouple simulation
mode softkey



TIP : If the menu item is not displayed, press the softkey to go to the next menu level.

Optical Tachometer Calibration Option Operation

The optical tachometer calibration option allows the user to enter a value *directly in RPM* and use the calibrator to control the optical tachometer adapter. The integrated LED is pulsed at the required frequency to simulate the RPM value entered.




1. Use the calibrator keypad to key in the required RPM, for example 3500 :

3 5 0 0 ENTER




Note : Valid RPM settings are from 240 RPM to 60,000 RPM

Ensure the calibrator output is turned ON by pressing the  key.



Note : The LED in the top left hand corner of the Output ON key will illuminate and the display will indicate **ON** in the left hand corner.

2. The optical tachometer should be pointed at the LED on the adapter with no more than 20° angle to ensure consistent detection by the tachometer. Distance from the LED should also be restricted to within 5cm, again, for consistent detection.



Optical tachometer calibration times can be significantly reduced by using the ProCal calibration software available from Transmille which allows a pre-defined sequence of tests (known as a procedure) to be set up. This allows the computer to automatically step through these tests, control the calibrator, set the correct outputs and record the amount of deviation in relation to the instrument's specifications.

Care & Maintenance

The only maintenance instructions for the adapter is periodic cleaning.
See below for details on the cleaning procedure and precautions for handling.

Cleaning the Adapter

To keep the external enclosure of the adapter in good condition, clean the outer case with a soft cloth. Do not use any liquids in cleaning the enclosure – removal of surface dust is all that is recommended.



CAUTION

Do not use cleaning fluids or solvents for cleaning as these may damage the enclosure and affect the plastic materials used in the adapter.

Handling Precautions

The adapter is designed for mechanical stability, but should not be subjected to excessive shock or be dropped. Transportation is recommended using the original packaging with avoidance of extreme changes of temperature.

Servicing Information

The adapter is provided certified from the factory, and uses precision components and are not user repairable. If the adapter is damaged it should be returned to the factory for repair and recalibration.

EA003

Optical Tachometer Calibration Adapter

Appendix A Specifications

EA003 Optical Tachometer Adapter Specifications

General Specifications	
Adaptor connection	Connects to male 'D' type adapter interface connector on 3000 Series front panel
Indicators	Incorporates red 8mm 20° Spread Ultra bright LED mounted in the adaptor case
Brightness	1000mcd (wavelength 660nm)
Duty cycle	20% (5:1)
Adaptor Dimensions	12.5cm x 6.5cm x 2.5cm
Connections	1 x 9 way male 'D' type connector
Connection to Calibrator	Via supplied 9 Way male to female serial lead (straight through connection)

Optical Tachometer Adaptor Accuracy				
Range	Resolution	180 Day Rel. %	1 Year Rel. %	2 Year Rel. %
240 to 60,000 RPM	6 RPM	0.0029	0.0030	0.0036

Frequency Input	RPM Simulation
40	240
100	600
200	1200
400	2400
600	3600
800	4800
1000	6000
2000	12000
4000	24000
8000	32000
10000	60000

Specifications apply between 17°C and 27°C.

Outside this range an allowance of 0.18 x 1 Year Spec. per °C should be added.

Due to continuous development specifications may be subject to change.