



6. Terminal Wiring Diagrams

NOTE
Do not use unassigned terminals as relay terminals.

UP750 Single-loop Control (Model UP750-0□ or UP750-5□)



UP750 Single-loop Heating/Cooling Control (Model UP750-0□ or UP750-5□)



Correspondence between parameters OT1 and heating side output types/cooling side output types								
OT1=4	OT1=5	OT1=6	OT1=7	OT1=8	OT1=9	OT1=10	OT1=11	OT1=12
Heating side: Relay output (terminals ①, ② and ③) Cooling side: Relay output (terminals ④ and ⑦)	Heating side: Voltage pulse output (terminals ⑤ and ⑧) Cooling side: Relay output (terminals ④ and ⑦)	Heating side: Current output (terminals ⑥ and ⑨) Cooling side: Relay output (terminals ④ and ⑦)	Heating side: Relay output (terminals ①, ② and ③) Cooling side: Transistor output (terminals ④ and ⑦)	Heating side: Voltage pulse output (terminals ⑤ and ⑧) Cooling side: Transistor output (terminals ④ and ⑦)	Heating side: Current output (terminals ⑥ and ⑨) Cooling side: Transistor output (terminals ④ and ⑦)	Heating side: Relay output (terminals ①, ② and ③) Cooling side: Current output (terminals ④ and ⑦)	Heating side: Voltage pulse output (terminals ⑤ and ⑧) Cooling side: Current output (terminals ④ and ⑦)	Heating side: Current output (terminals ⑥ and ⑨) Cooling side: Current output (terminals ④ and ⑦)


The types of control output, "relay output" and "voltage pulse output" shown in the table above refer to those of time proportional control.
To change to a relay output for on-off control, select "Relay Terminals" and change the setpoint of the proportional band to "0."

This manual describes examples of setting PV input types, control output types. Carrying out settings described herein allows you to perform basic control. Refer to examples of various settings to understand how to set parameters required. Refer to **Parameter Map User's Manual** for an easy to understand explanation of setting various parameters. If you cannot remember how to carry out an operation during setting, press the **DISP** key no more than four times. This brings you to the display (operating display) that appears at power-on. After carrying out the setting describes here, create programs in **Programming User's Manual**.

Contents

- Names and Functions of Front Panel Parts
- Setting PV Input Type (Setting First at Power-on)
- Changing PV Input Type
- Setting Control Output Type
- Initializing Parameters


1. Names and Functions of Front Panel Parts



Name of Part	Function
1. Indicator lamp for PV2 display	Is lit when Loop2 PV is displayed in PV display. Not used in single-loop control.
2. Program monitor lamps	Is lit (in green) when a program setpoint is increasing. Is lit (in green) when a program setpoint is constant. Is lit (in green) when a program setpoint is decreasing.
3. Event indicator lamps	Show the statuses of PV events, time events and instrument alarms in orange. PVE1 and PVE2 lamps: Come on when PV event 1 and PV event 2 turn on. TME1 to TME4 lamps: Come on when time event 1 to time event 4 turn on. AL1 lamp: Comes on when instrument alarm 1 turns on.
4. Status indicator lamps	Is lit (in green) to indicate the status of operation or control. PRG: Is lit when in program mode. RST: Is lit when in reset mode. HLD: Is lit when in hold mode. LOC: Is lit when in local mode. MAN1: Is lit when in manual mode. MAN2: Not used in single-loop control. CAS: Not used in single-loop control.
5. Light-loader interface	Interface for an adapter cable used when setting and storing parameters from a PC. This requires an optional parameter setting tool.
6. Process variable (PV) display	Displays PV. Displays an error code (in red) if an error occurs.
7. Setpoint display (LCD)	Displays the name and value of a program setpoint (SP), output (OUT), deviation trend, or a parameter. Displays an error code if an error occurs.
8. Instrument alarm indicator lamp	The AL1 lamp comes on in orange if instrument alarm 1 occurs.
9. SET/ENT key	Used to switch or register a parameter. Pressing the key for more than 3 seconds allows you to switch between the operating display and the main menu for operating parameter setting display alternately.
10. MODE key	Presents a display for switching between the hold, advance, local, AUTO and MAN modes.
11. DISP key	Used to switch between displays. Pressing this key while any operating display is shown lets you switch to another prearranged operating display. Pressing this key while any display other than an operating display is shown lets you go one display back. (One to four presses (maximum) of this key lets you return to the current operating display, though the number of presses depends on the operating status.)
12. ∇ and ∆ keys	Used to change numerical values. On setting displays for various parameters, you can change target setpoints, parameters, and output values (in manual operation). Pressing the ∇ key decreases a numerical value, while pressing the ∆ key causes it to increase. You can hold down a key to gradually increase the speed of change. These keys also switch between menu displays when a main menu or submenu of parameter setting display is shown.
13. PT.No key	Use this key when the controller is at a reset to select a program pattern number on an operating display.
14. RUN key	Pressing this key for more than 2 seconds while an operating display is shown starts the controller.
15. RESET key	Pressing this key for more than 2 seconds while an operating display is shown stops the controller.

Setting of Main Parameters at the Factory before Shipment


Item	Factory-set defaults for single-loop type/dual-loop type controllers
Control output	Time proportional PID relay output (variable)
Control action	Reverse action (variable)
PID parameter	P = 5.0%, I = 240 seconds, D = 60 seconds.



2. Setting PV Input Type (Setting First at Power-on)


NOTE

- The controller displays an operating display when the power is turned on. The submenu "IN" appears at this point if the type of PV input has not been defined yet. In this case, first press the **DISP** key once to display the parameter "IN1" for the PV input type, and use the **∆** key to display the input range code to use, then press the **SET** key to register it. Then, set the maximum value (RH1) and minimum value (SL1) of the PV input range (for voltage input, set the maximum value (SH1) and minimum value (SL1) of the PV input scale). See the operating procedure below for more details.
- The controller is configured to the default of each parameter at the factory before shipment. First check these defaults listed in **Parameters User's Manual** and change their values if necessary.



How to return to a menu
 Press the **DISP** key once during parameter setting. This lets you return to the parameter menu.

The following operating procedure describes an example of setting a K-type thermocouple (-200.0 to 500.0°C) and a measurement range of 0.0 to 200.0°C.



Instrument Input Range Codes

Input	Type	Instrument Input Range Code	Instrument Input Range	Measurement Accuracy	
Unspecified		OFF	Set the data item PV Input Type "IN1" to the OFF option to leave the PV input type undefined.		
Thermocouple	K	type K1	-270.0 to 1370.0°C -450.0 to 2500.0°F	±0.1% of instrument range ±1 digit at 0°C or more ±0.2% ±1 digit for temperatures below 0°C, where the accuracy is: ±2% of instrument range ±1 digit for temperatures below -200.0°C for a type-K thermocouple, or ±1% of instrument range ±1 digit for temperatures below -200.0°C for a type-T thermocouple.	
		type K2	-270.0 to 1000.0°C -450.0 to 2300.0°F		
		type K3	-200.0 to 500.0°C -200.0 to 1000.0°F		
	J	type J	-200.0 to 1200.0°C -300.0 to 2300.0°F		
	T	type T1	-270.0 to 400.0°C -450.0 to 750.0°F		
		type T2	0.0 to 400.0°C -200.0 to 750.0°F		
	B	type B	0.0 to 1800.0°C 32 to 3300°F		±0.15% of instrument range ±1 digit at 400°C or more ±5% of instrument range ±1 digit at less than 400°C
	S	type S	0.0 to 1700.0°C 32 to 3100°F		±0.15% of instrument range ±1 digit
	R	type R	0.0 to 1700.0°C 32 to 3100°F		
	RTD	N	type N		-200.0 to 1300.0°C -300.0 to 2400.0°F
E		type E	-270.0 to 1000.0°C -450.0 to 1800.0°F	±0.1% of instrument range ±1 digit at 0°C or more ±0.2% ±1 digit for temperatures below 0°C, where the accuracy is: ±1.5% of instrument range ±1 digit for temperatures below -200.0°C for a type-E thermocouple.	
L(DIN)		type L	-200.0 to 900.0°C -300.0 to 1600.0°F		
U(DIN)		type U1	-200.0 to 400.0°C -300.0 to 750.0°F	±0.2% of instrument range ±1 digit	
		type U2	0.0 to 400.0°C -200.0 to 1000.0°F		
W		type W	0.0 to 2300.0°C 32 to 4200°F	±0.2% of instrument range ±1 digit	
Platini 2		Plati 2	0.0 to 1390.0°C 32 to 2500.0°F	±0.1% of instrument range ±1 digit	
PR20-40		PR2040	0.0 to 1900.0°C 32 to 3400°F	±0.5% of instrument range ±1 digit at 800°C or more No accuracy is guaranteed at less than 800°C	
W97Re3-W75Re25		W97Re3	0.0 to 2000.0°C 32 to 3600°F	±0.2% of instrument range ±1 digit	
Standard signal		JPt100	JPt1	-200.0 to 500.0°C -300.0 to 1000.0°F	±0.1% of instrument range ±1 digit (Note1) (Note2)
	JPt2		-150.0 to 150.00°C -200.0 to 300.0°F	±0.2% of instrument range ±1 digit (Note1)	
	Pt100	Pt1	-200.0 to 850.0°C -300.0 to 1560.0°F	±0.1% of instrument range ±1 digit (Note1) (Note2)	
		Pt2	-200.0 to 500.0°C -300.0 to 1000.0°F	±0.2% of instrument range ±1 digit (Note1)	
DC voltage	0.4 to 2 V	0.400 to 2.000 V	±0.1% of instrument range ±1 digit Display range is scalable in a range of -19999 to 30000. Display span is 30000 or less.		
		1.000 to 5.000 V			
	0 to 2 V	0.000 to 2.000 V			
		0.000 to 10.000 V			
0.0 to 1.2 V (Note3)	mV1	-10.00 to 20.00 mV			
	mV2	0.0 to 100.0 mV			

* Performance in the standard operating conditions (at 23±2°C, 55±10%RH, and 50/60 Hz power frequency)
 Note1: The accuracy is ±0.3°C of instrument range ±1 digit for a temperature range from 0°C to 100°C.
 Note2: The accuracy is ±0.5°C of instrument range ±1 digit for a temperature range from -100°C to 200°C.
 Note3: Not used in single-loop control.
 * To receive a 4-20 mA DC signal, select a standard signal of 1 to 5 V DC and connect it to a 250Ω resistor. This resistor is optional.
 Model: X010-250-2 (resistor with M3.5 crimp-on terminal lugs)

NOTE
 The controller may automatically initialize the registered operating parameter setpoints if any change is made to the data item PV Input Type (IN1), Maximum Value of PV Input Range (RH1), Minimum Value of PV Input Range (RL1), PV Input Decimal Point Position (SDP1), Maximum Value of PV Input Scale (SH1) or Minimum Value of PV Input Scale (SL1). After a change has been made to any of these data items, be sure to verify the registered operating parameter setpoints to ensure that they are correct. If any data item has been changed to its default, set it to a required value.

Ranges Selectable for PV Input

Thermocouple	typeK1, K2, K3, J, T1, T2, B, S, R, N, E, L, U1, U2, W, Plati2, PR2040
RTD	JPt1, JPt2, Pt1, Pt2, Pt3, Pt4
DC voltage(mV,V)	0.4 to 2 V, 1 to 5 V, 0 to 2 V, 0 to 10 V, mV1, mV2

3. Changing PV Input Type

The following operating procedure describes an example of changing the setting of K-type thermocouple (-200.0 to 500.0°C) to RTD Pt100 (-200.0 to 500.0°C) and a measurement range of 0.0 to 200.0°C.

PV input terminal
Thermocouple/m/V input..... ①-③
RTD input..... ①-②-⑤

- Bring the operating display into view (display appears at power-on).
- Press the **[F1]** key for more than 3 seconds to call up the main menu "PROG".
- Press the **[F2]** key once to display the main menu "STUP".
- Press the **[F1]** key once to display the main menu "PARA".
- Press the **[F2]** key once to display the main menu "UPMD".
- Press the **[F3]** key once to display the submenu "MD".
- Press the **[F4]** key once to display the submenu "IN".
- Press the **[F1]** key once to display the parameter "IN1" (PV input type).
- Press the **[F2]** or **[F3]** key to display the required setpoint. The figure below shows an example of setting the PV input type to a Pt100 resistance temperature detector (-200.0°C to 500.0°C).
- Press the **[F1]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

In steps 2 and later, illustrations of the LCD are cited to explain the procedure.

4. Setting Control Output Type

The following operating procedure describes an example of changing time proportional PID relay output (0: factory-set default) to current output (2).

Control output terminal Values in parentheses are setpoints
Time proportional PID relay (0)/on-off(3) output..... ①-②-③
Current (2)/time proportional PID voltage pulse (1) output..... ⑥-⑦
For details on the output terminals for heating/cooling control, see 6. Terminal Wiring Diagrams in **Installation User's Manual**.

- Bring the operating display into view (display appears at power-on).
- Press the **[F1]** key for more than 3 seconds to call up the main menu "PROG".
- Press the **[F2]** key once to display the main menu "STUP".
- Press the **[F1]** key once to display the main menu "PARA".
- Press the **[F2]** key once to display the main menu "UPMD".
- Press the **[F3]** key once to display the submenu "MD".
- Press the **[F4]** key once to display the parameter "OT1" (control output type).
- Press the **[F2]** or **[F3]** key to display the required setpoint. The figure below shows an example of setting to current output (4 to 20 mA DC).
- Press the **[F1]** key once to register the setpoint.
- Press the **[F1]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

In steps 2 and later, illustrations of the LCD are cited to explain the procedure.

List of Control Output Types

Parameter Symbol	Name of Parameter	Setpoint	Control Output Types
OT1	Control output type	0	Time proportional PID relay contact output (terminals ①-②-③)
		1	Time proportional PID voltage pulse output (terminals ⑥-⑦)
		2	Current output (terminals ⑥-⑦)
		3	On/off control relay contact output (terminals ①-②-③)
		4	Heating-side relay output (terminals ①-②-③), cooling-side relay output (terminals ④-⑤)
		5	Heating-side pulse output (terminals ⑥-⑦), cooling-side relay output (terminals ④-⑤)
		6	Heating-side current output (terminals ⑥-⑦), cooling-side relay output (terminals ④-⑤)
		7	Heating-side relay output (terminals ①-②-③), cooling-side transistor output (terminals ④-⑤)
		8	Heating-side pulse output (terminals ⑥-⑦), cooling-side transistor output (terminals ④-⑤)
		9	Heating-side current output (terminals ⑥-⑦), cooling-side transistor output (terminals ④-⑤)
		10	Heating-side relay output (terminals ①-②-③), cooling-side current output (terminals ④-⑤)
		11	Heating-side pulse output (terminals ⑥-⑦), cooling-side current output (terminals ④-⑤)
12	Heating-side current output (terminals ⑥-⑦), cooling-side current output (terminals ④-⑤)		

5. Initializing Parameters

Be sure to follow the steps below after a change of setting has been made to the data item PV Input Type, PV Input Range or PV Input Scale.

- Bring the operating display into view (display appears at power-on).
- Press the **[F1]** key for more than 3 seconds to call up the main menu "PROG".
- Press the **[F2]** key once to display the main menu "STUP".
- Press the **[F1]** key once to display the main menu "PARA".
- Press the **[F2]** key once to display the main menu "UPMD".
- Press the **[F3]** key once to display the submenu "MD".
- Press the **[F4]** key twice to display the submenu "INIT".
- Press the **[F1]** key once to display the parameter "INI".
- Press the **[F2]** key to display "ON".
- Press the **[F1]** key once. The display momentarily becomes blank (which is normal), indicating the parameters have been initialized.
- Press the **[F1]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

In steps 2 and later, illustrations of the LCD are cited to explain the procedure.

This manual explains how to create programs by citing specific examples. Create user programs by referring to the given programming examples. Use the parameter map included in "2. Program Parameter Map," in **Program Parameters User's Manual**, in order to further familiarize yourself with the required operations. Be sure to carry out the settings instructed in **Initial Settings User's Manual** before beginning any of the tasks discussed in this manual.


Contents

1. Overview of Program Patterns
2. Example of Program Pattern Setup Charts
3. Creating Program Patterns
4. Changing Program Patterns

1. Overview of Program Patterns

- Programming Overview**
- The programming example given here demonstrates how to do the tasks outlined below.
1. Program the controller to start program operation at 25°C and raise the temperature up to 80°C in 20 minutes.
 2. When the temperature reaches 80°C, keep it at this level for 80 minutes.
 3. Finally, lower the temperature to 0°C in 10 minutes.

- Event output**
- Set a deviation of 5°C on both the positive and negative sides of a program setpoint to allow the controller to output an event signal if the temperature goes beyond the deviation range.
 - Let the controller output an event signal when the temperature stabilizes to 80°C.



2. Example of Program Pattern Setup Charts

Complete the following setup chart before setting programs in the controller. Filling in the chart makes it easier for you to input program data into the controller. See "1. Program Pattern Setup Charts," in **Program Parameters User's Manual**. In the following chart, fill in the fields with bold-face borders.

1. Maximum value of PV input range: Setpoint of the "Maximum Value of PV Input Range (RH1)" setup parameter
2. Minimum value of PV input range: Setpoint of the "Minimum Value of PV Input Range (RL1)" setup parameter
3. PV input unit: Setpoint of the "PV Input Unit (UNI)" setup parameter
4. Program time unit: Setpoint of the "Program Time Unit (TMU)" setup parameter
5. Segment setting method: Setpoint of the "Segment Setting Method (SEG.T)" setup parameter
6. Starting target setpoint: Setpoint of the "Starting Target Setpoint (SSP1)" program parameter
7. Start code: Setpoint of the "Start Code (STC)" program parameter
8. Final target setpoint, Segment time, Events (PV event and Time event) and Junction code: setpoint of each program parameter
9. Draw the program pattern.


Example of Chart Entries

Starting target setpoint 1 (SSP1)	6	25°C
Starting target setpoint 2 (SSP2)		
Start code (STC)	7	0
1st group of wait zones (1.WZ1)		
1st group of wait times (1.WTM)		
2nd group of wait zones (2.WZ1)		
2nd group of wait times (2.WTM)		
3rd group of wait zones (3.WZ1)		
3rd group of wait times (3.WTM)		
4th group of wait zones (4.WZ1)		
4th group of wait times (4.WTM)		
5th group of wait zones (5.WZ1)		
5th group of wait times (5.WTM)		
Number of repetitions (RCY)		
Start-of-repetition segment number (RST)		
End-of-repetition segment number (REN)		

Define this parameter when using the controller as a program pattern generator. See User's Manual (Reference) (CD-ROM version) for more information.

See User's Manual (Reference) (CD-ROM version) for more information.

Program time unit (TMU)	4	Hour, minute
Segment setting method (SEG.T)	5	Time setting



3. Creating Program Patterns

The following operating procedure describes an example of creating the program discussed in "1. Overview of Program Patterns."

- NOTE**
- Before creating the program, reverify the Maximum Value of PV Input Range (RH1), Minimum Value of PV Input Range (RL1), Program Time Unit (TMU), and Segment Setting Method (SEG.T) parameters. If the setting of the setup parameter "SEG.T" is changed, the program patterns created and stored so far will be all cleared (initialized) !! Be careful.

- The programming example given in this manual includes the following steps.
- Step 5 selects the program pattern number (PTN).
 - Steps 7 to 9 configure the parameter Starting Target Setpoint (SSP1) (so that the program starts from 25°C).
 - Steps 11 to 13 configure the Final Target Setpoint (TSP1) parameter for segment 1.
 - Steps 14 to 16 configure the Segment Time (TIME) parameter for segment 1.
 - Steps 17 to 25 configure the PV Event parameters (EV1, TY1 and PE1).
 - Step 28 configures the Final Target Setpoint (TSP1) parameter for segment 2 (not changed in this example).
 - Steps 29 to 31 configure the Segment Time (TIME) parameter for segment 2.
 - Steps 32 to 40 configure the Time Event parameters (EV1, ON1 and OFF1).
 - Steps 43 to 45 configure the Final Target Setpoint (TSP1) parameter for segment 3.
 - Steps 46 to 48 configure the Segment Time (TIME) parameter for segment 3.

1. Bring the operating display into view (appears at power-on).
2. Press the **PROG** key for more than 3 seconds to call up the main menu "PROG".
3. Press the **LOC** key once to display the submenu "LOC".
4. Press the **PRG** key once to display the submenu "PRG".
5. Press the **PTN** key once to display the Pattern Number parameter "PTN". At this point, the PV display shows "001.00" (the first three digits denote the pattern number and the last two digits the segment number).
6. Press the **SEG** key once to display the Segment Number parameter "SEG".
7. Press the **SSP** key once to display the Starting Target Setpoint parameter "SSP1".
8. Press the **SP** key once to display the required setpoint.
9. Press the **SSP** key once to register the setpoint.
10. Press the **STC** key once to display the Start Code parameter "STC".
11. Press the **TSP** key once to display the Target Setpoint parameter "TSP1" for segment 1. At this point, the PV display shows "001.01" (the first three digits denote the pattern number and the last two digits the segment number).
12. Press the **TIME** key once to display the required setpoint.
13. Press the **SEG** key once to register the setpoint.
14. Press the **TIME** key once to display the Segment Time parameter "TIME" for segment 1.
15. Press the **TIME** key once to display the required setpoint.
16. Press the **TIME** key once to register the setpoint.
17. Press the **EV** key once to display the Event Number parameter "EV1".
18. Press the **EV** key once to display the required setpoint.
19. Press the **EV** key once to register the setpoint.
20. Press the **TY** key once to display the PV Event Type parameter "TY1".
21. Press the **TY** key once to display the required setpoint.
22. Press the **EV** key once to register the setpoint.
23. Press the **PE** key once to display the PV Event Setpoint parameter "PE1".
24. Press the **PE** key once to display the required setpoint.
25. Press the **EV** key once to register the setpoint.
26. Press the **EV** key once to display the Event Number parameter "EV2".
27. Press the **JC** key once to display the Junction Code parameter "JC" for segment 1. The setpoint of this parameter is not changed in this example.
28. Press the **TSP** key once to display the Target Setpoint parameter "TSP1" for segment 2. The setpoint of this parameter is not changed in this example. At this point, the PV display shows "001.02" (the first three digits denote the pattern number and the last two digits the segment number).
29. Press the **TIME** key once to display the Segment Time parameter "TIME" for segment 2.
30. Press the **TIME** key once to display the required setpoint.
31. Press the **EV** key once to register the setpoint.
32. Press the **EV** key once to display the Event Number parameter "EV1".
33. Press the **TIME** key once to display the required setpoint.
34. Press the **EV** key once to register the setpoint.
35. Press the **ON** key once to display the On Time of Time Event parameter "ON1".
36. Press the **ON** key once to display the required setpoint.
37. Press the **EV** key once to register the setpoint.

38. Press the **[F1]** key once to display the Off Time of Time Event parameter "OFF1".

44. Press the **[F2]** or **[F3]** key to display the required setpoint.

The figure below shows an example of setting the parameter to "0.0°C".

39. Press the **[F2]** or **[F3]** key to display the required setpoint.

The figure below shows an example of setting the parameter to "1 hr. and 20 min. (setpoint 1h20)".

40. Press the **[F2]** key once to register the setpoint.

41. Press the **[F1]** key once to display the Event Number parameter "EV2".

42. Press the **[F2]** key once to display the Junction Code parameter "JC" for segment 2. The setpoint of this parameter is not changed in this example.

43. Press the **[F2]** key once to display the Target Setpoint parameter for segment 3. At this point, the PV display shows "001.03" (the first three digits denote the pattern number and the last two digits the segment number).

49. Programming is now complete. Press the **[F2]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

45. Press the **[F1]** key once to register the setpoint.

46. Press the **[F2]** key once to display the Segment Time parameter "TIME" for segment 3.


47. Press the **[F2]** or **[F3]** key to display the required setpoint.

The figure below shows an example of setting the parameter to "10 min (setpoint 0h10)".

48. Press the **[F2]** key once to register the setpoint.

4. Changing Program Patterns

The following operating procedure describes an example of changing the program pattern created in "3. Creating Program Patterns" to the program pattern shown in the figure below.



Details of the Change

Before change: Program operation begins with the starting target setpoint (SSP1).
After change: Program operation begins with the current PV value. The time setpoints of segment 1 precede others.

Change the setpoint of the Start Code (STC) program parameter to "2".

Before change: The Target Setpoint (TSP1) program parameter for segment 2 was set to "80.0°C".
After change: The Target Setpoint (TSP1) program parameter for segment 2 is set to "90.0°C".

Change the setpoint of the Target Setpoint (TSP1) program parameter for segment 2 to "90.0°C".

1. Bring the operating display into view (appears at power-on).

2. Press the **[F2]** key for more than 3 seconds to show the main menu "PROG".

3. Press the **[F1]** key once to display the submenu "LOC".

4. Press the **[F2]** key once to display the submenu "PRG".

5. Press the **[F2]** key once to display the Pattern Number parameter "PTN".

6. Press the **[F2]** key once to display the Segment Number parameter "SEG".

7. Press the **[F2]** key twice to display the Start Code parameter "STC".

8. Press the **[F2]** or **[F3]** key to display the required setpoint.

The figure below shows an example of setting the parameter to "90.0°C".

9. Press the **[F2]** key once to register the setpoint.

10. Press the **[F2]** key once to display the Target Setpoint parameter "TSP1" for segment 1.

11. Press the **[F2]** key seven times to display the Target Setpoint parameter "TSP1" for segment 2. At this point, the PV display shows "001.02" (the first three digits denote the pattern number and the last two digits the segment number).

12. Press the **[F2]** or **[F3]** key to display the required setpoint.

The figure below shows an example of setting the parameter to "90.0°C".

13. Press the **[F2]** key once to register the setpoint.

14. Changing the program is now complete. Press the **[F2]** key for more than 3 seconds. This returns you to the display shown at power-on (figure below).

Error Indication at Program Pattern Creation and Editing

Error code	Error information	Cause of error
0	No error	Normal end
01	Pattern creation or editing is disable during program operation.	Adding, deleting, or copying of the program pattern, segment, or event was executed during program or local operation.
02	Pattern number error Only when using communication (The error code is stored in register B0005.)	The specified pattern number does not exist. Pattern numbers : 1 to 300
03	Segment number error Only when using communication (The error code is stored in register B0105.)	The specified segment number does not exist. Segment numbers : 1 to 99
11	Pattern information read error Only when using communication (The error code is stored in register B0005.)	Pattern read was attempted during pattern read. Pattern read was executed when the parameters in "PRG" and "EDIT" program parameter submenus are displayed on the LCD.
12	Pattern information write error Only when using communication (The error code is stored in register B0005.)	Pattern write was attempted during pattern write. Pattern write was executed when the parameters in "PRG" and "EDIT" program parameter submenus are displayed on the LCD.
21	Segment read error Only when using communication (The error code is stored in register B0105.)	Segment read was attempted during pattern read. Segment read was executed when the parameters in the "PRG" and "EDIT" program parameter submenus are displayed on the LCD.
22	Segment write error Only when using communication (The error code is stored in register B0105.)	The total number of segments exceeded 3000.
23	Segment insert error	During program operation, the total number of segments exceeded 300 or numbers in a pattern exceeded 99, and therefore a new segment cannot be register or added. The specified segment is missing.
24	Segment delete error	Any segment cannot be deleted during program operation. The specified segment is missing.
25	Exceeded segment count error	The number of segments exceeded 3000.
31	Pattern copy error Only when using communication (The error code is stored in register B0065.)	No pattern is present at the source or patterns already exist at the destination.
32	Pattern source specification error	No pattern is present at the source or program operation is being executed when the source of pattern copy is specified.
33	Pattern destination specification error	Patterns already exist at the destination.
41	Pattern delete error	At pattern delete operation, specified pattern does not exist or program operation is being executed.
51	Event write error Only when using communication (The error code is stored in register B0105.)	The number of events exceeded 4000. Or the number of remaining events is less than 8. (Write is disabled when remaining settable events are less than 8)

Operation Modes


The UP750 has the following four types of operation modes:

- RUN (program operation start) mode
- HOLD (program operation hold) mode
- LOCAL (local operation) mode
- RESET (program operation stop) mode

The operation modes switching function and the control state for each mode are described below.

Operation Modes Switching Function

Operation modes RUN, HOLD, LOCAL, and RESET can be switched as described below.



RUN (program operation start) mode

The controller executes the control operation using the program pattern.

Pressing the **[RUN]** key on the controller's front panel starts a control operation using the selected program pattern, which can also be started by means of an external contact input or communication. The PRG indicator lamp on the front panel is lit in RUN mode.

Auto-tuning Function


The auto-tuning function is used to have the controller measure process characteristics and automatically set the most appropriate PID constant. This function cannot be used for on/off control. As the function is started, control outputs are temporarily varied in steps and the responses are used for computing the proper PID constant - this is called a limited-cycle method.

The auto-tuning function should not be applied to the following processes:

- Control processes with quick response such as flow control or pressure control
- Processes where even temporary output on/off results in inconvenience
- Processes where a large output change at control element results in inconvenience
- Processes where variations in PV may exceed an allowable range, adversely affecting product quality.

Operating parameter AT

Description	Setpoint	TIP
Disable auto-tuning	OFF	Factory-set default
Perform auto-tuning on the specified PID group	1 to 8	When PID setpoint is switched using segment-PID, setpoints 1 to 8 are not effective.
Perform auto-tuning to all PID groups	9	Only available for zone-PID



Auto-tuning in Segment-PID Control

When auto-tuning is performed for segment-PID, the most proper PID constant can be obtained for the current target setpoint. The obtained PID constant is saved to the set PID constant parameter. When PID number 2 is set for segment 1 and AT=1 is executed, for example, obtained PID constant is saved as PID number 2.

The auto-tuning parameter (AT) setpoints, its corresponding tuning point, and the tuned PID group number for "segment-PID" control (zone-PID selection parameter ZON is set at "0") are:

AT setpoint	Tuning point (SP at which auto-tuning is performed)	Tuned PID group number
1	Current target setpoint (SP) at the starting of auto-tuning	PID number assigned for the segment being used.
2		
3		
4		
5		
6		
7		
8		

HOLD (program operation hold) mode

The controller temporarily interrupts the program operation.

Pressing the **[MODE]** key on the front panel temporarily interrupts the program operation, which can also be interrupted by means of an external contact input or communication. The HLD indicator lamp on the front panel is lit in Hold mode.

RESET (program operation stop) mode

The controller stops the program operation.

Pressing the **[RESET]** key on the front panel stops the program operation, which can also be stopped by means of an external contact input or communication. The RST indicator lamp on the front panel is lit in RESET mode, and all event functions are turned off.

LOCAL (local operation) mode

The controller executes the local control operation.

Selecting the LOCAL operation using the **[MODE]** key on the front panel starts the local control operation, which can also be started by means of an external contact input or communication. The LOC indicator lamp on the front panel is lit in LOCAL mode.

Control Status

The control status of each operation mode for UP750 is described below.

Operation mode	Target setpoint	Control output	Applicable key operation
RESET	0%	Preset output.	<ul style="list-style-type: none"> • Program pattern selection. • Program operation starting. • Local operation starting
LOCAL	Setpoint for local-mode operation (LSP)	AUTO: Result of control computation. MAN: Manipulated output.	<ul style="list-style-type: none"> • LSP modification • Output value modification (in MAN mode) • RESET of operation • Program operation starting
RUN	Target setpoint for each segment	AUTO: Result of control computation. MAN: Manipulated output.	<ul style="list-style-type: none"> • Output value modification (in MAN mode) • RESET of operation • LOCAL operation starting • HOLD mode
HOLD	Setpoint when the mode is changed to HOLD, or setpoint in HOLD mode modified by key operation in the case of soak segment.	AUTO: Result of control computation. MAN: Manipulated output.	<ul style="list-style-type: none"> • Output value modification (in MAN mode) • Segment remaining time modification (in the case of soak segments). • RESET of operation • LOCAL operation starting • Program operation starting

Auto-tuning in Zone-PID Control

When auto-tuning is performed for zone-PID with the parameter AT set between 1 and 8, the optimum PID constants are obtained by using the current target setpoint value at the start of auto-tuning as a tuning point. The obtained PID values are saved as PID parameters for the PID number of the specified auto-tuning number. For example, if AT=2 is executed in zone 1, which is controlled with 1.PID parameters, the obtained PID constants will be saved as 2.PID parameters.

On the other hand, when auto-tuning is performed with parameter AT=9, the optimum PID constants for all the group numbers in use are obtained automatically, using the median value of each set reference point as tuning point.

- For example, the following points will be the tuning points.
- Median value of "the minimum value of PV input range" and "reference point 1"
 - Median value of "reference point 1" and "reference point 2"
 - Median value of "reference point 2" and "the maximum value of PV input range"


Since auto-tuning is performed progressively by processing to successive reference points, reference points 2 to 6 should be set so that the temperature during auto-tuning does not rise above the maximum limit for the controlled process. If there are any unused reference points, set them at the same value as the maximum value of the PV input range.

In heating/cooling control, when a certain zone is set for on/off control (proportional band parameter, n.P or n.Pc, is set at "0") however, auto-tuning skips that zone and proceeds to the next zone.

When controlling equipment such as heating furnaces, the PV input range must be set at a proper value (for example, setting room-temperature as the minimum value) when:

- The gap between reference point 1 and the minimum value of PV input range is large.
- The gap between the top reference point and the maximum value of the PV input range is large.

The figure below is the example of setting two reference points.



Auto-tuning in Zone-PID Control (when AT=9)

The auto-tuning parameter (AT) setpoints, corresponding tuning points and tuned PID group numbers for "zone-PID" control (zone-PID selection parameter ZON is set at "1") are:

AT setpoint	Tuning point (SP at which auto-tuning is performed)	Tuned PID group number
1	Current target setpoint (SP) at the starting of auto-tuning	1
2	Current target setpoint (SP) at the starting of auto-tuning	2
3	Current target setpoint (SP) at the starting of auto-tuning	3
4	Current target setpoint (SP) at the starting of auto-tuning	4
5	Current target setpoint (SP) at the starting of auto-tuning	5
6	Current target setpoint (SP) at the starting of auto-tuning	6
7	Current target setpoint (SP) at the starting of auto-tuning	7
8	Current target setpoint (SP) at the starting of auto-tuning	8
9 (AUTO)	Median of each zone	1 to 8



This manual briefly explains the functions of program parameters. In addition, it contains a program pattern setup chart. Completely fill in the chart before you set a program in the UP750 program controller.

Contents

1. Program Pattern Setup Charts
2. Program Parameter Map
3. Lists of Program Parameters
4. Explanation of Program Functions

1. Program Pattern Setup Charts

For details on how to use the program pattern setup chart, see "1. Overview of Program Patterns," and "2. Example of Program Pattern Setup Charts," in Programming User's Manual. You can register as many as 300 program patterns with the UP750 controller. Create as many copies of the chart as necessary. First fill in the fields with bold-face borders in the order from number 1 to number 9. Then, input the data into the controller.

1. Maximum value of PV input range: Setpoint of the "Maximum Value of PV Input Range (RH1)" setup parameter
2. Minimum value of PV input range: Setpoint of the "Minimum Value of PV Input Range (RL1)" setup parameter
3. PV input unit: Setpoint of the "PV Input Unit (UNI1)" setup parameter
4. Program time unit: Setpoint of the "Program Time Unit (TMU)" setup parameter
5. Segment setting method: Setpoint of the "Segment Setting Method (SEG.T)" setup parameter
6. Starting target setpoint: Setpoint of the "Starting Target Setpoint (SSP1)" program parameter
7. Start code: Setpoint of the "Start Code (STC)" program parameter
8. Final target setpoint, Segment time, Events (PV event and Time event), and Junction code: Setpoint of each program parameter
9. Draw the program pattern.

Starting target setpoint 1 (SSP1)	6
Starting target setpoint 2 (SSP2)	
Start code (STC)	7
1st group of wait zones (1.WZ1)	
1st group of wait times (1.WTM)	
2nd group of wait zones (2.WZ1)	
2nd group of wait times (2.WTM)	
3rd group of wait zones (3.WZ1)	
3rd group of wait times (3.WTM)	
4th group of wait zones (4.WZ1)	
4th group of wait times (4.WTM)	
5th group of wait zones (5.WZ1)	
5th group of wait times (5.WTM)	
Number of repetitions (RCY)	
Start-of-repetition segment number (RST)	
End-of-repetition segment number (REN)	

Define this parameter when using the controller as a program pattern generator.
See User's Manual (Reference) (CD-ROM version) for more information.

See User's Manual (Reference) (CD-ROM version) for more information.

System name		Program time unit (TMU)	4
Program No.		Segment setting method (SEG.T)	5
Program name			
Model	UP750 -		
Serial No.			


Unit	3																			
Maximum value of PV input range (RH1)	1																			
Minimum value of PV input range (RL1)	2																			
Segment No. →	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
Final target setpoint 1 (TSP1)																				
Final target setpoint 2 (TSP2)																				
Segment time (TIME/TM.RT)																				
PID number (PID)																				
Event number (EV1)																				
PV event type (TY1)/on time of time event (ON1)																				
PV event setpoint (PE1)/off time of time event (OFF1)																				
Event number (EV2)																				
PV event type (TY2)/on time of time event (ON2)																				
PV event setpoint (PE2)/off time of time event (OFF2)																				
Event number (EV3)																				
PV event type (TY3)/on time of time event (ON3)																				
PV event setpoint (PE3)/off time of time event (OFF3)																				
Event number (EV4)																				
PV event type (TY4)/on time of time event (ON4)																				
PV event setpoint (PE4)/off time of time event (OFF4)																				
Event number (EV5)																				
PV event type (TY5)/on time of time event (ON5)																				
PV event setpoint (PE5)/off time of time event (OFF5)																				
Event number (EV6)																				
PV event type (TY6)/on time of time event (ON6)																				
PV event setpoint (PE6)/off time of time event (OFF6)																				
Event number (EV7)																				
PV event type (TY7)/on time of time event (ON7)																				
PV event setpoint (PE7)/off time of time event (OFF7)																				
Event number (EV8)																				
PV event type (TY8)/on time of time event (ON8)																				
PV event setpoint (PE8)/off time of time event (OFF8)																				
Junction code (JC)																				

Define this parameter when using the controller as a program pattern generator. See User's Manual (Reference) (CD-ROM version) for more information.

Time setting (TIME) when the Segment Setting Method (SEG.T) parameter is set as SEG.T = 0; ramp setting (TM.RT) when the parameter is set as SEG.T = 1
Factory-set to Time setting (TIME).

Shown for segment PID parameters when the setup parameter "ZON" is set to 0.

2. Program Parameter Map



Pressing the [key] once during programming returns to the display marked (A).

This manual describes key entries for operating the controller. For operations using external contact inputs, see "6. Terminal Wiring Diagrams" in **Installation User's Manual**. If you cannot remember how to carry out an operation during setting, press the **[DISP]** key no more than four times. This brings you to the display (operating display) that appears at power-on.

Contents

- Monitoring-purpose Operating Displays Available during Operation
- Performing/Canceling Auto-tuning
- Setting PID Manually
- Selecting Program Pattern Number (PT.No)
- Switching between RUN and RESET Modes
- Switching between AUTO and MAN
- Manipulating Control Output during Manual Operation
- Enabling/Disabling Hold Mode of Program Operation
- Changing Program Setpoints when in Hold Mode
- Executing "Advance" Function
- Switching to Local-mode (LOCAL) Operation
- Changing Setpoints during Local-mode Operation
- Troubleshooting


For description of Operation Mode, see the back of **Programming User's Manual**.

1. Monitoring-purpose Operating Displays Available during Operation

The monitoring-purpose operating displays available during operation include those for single-loop control and those for single-loop heating/cooling control. The Process Variable (PV) display always displays the value of PV input.

Operating Displays for Single-loop Control


- SP Display**
On the Setpoint display (LCD), the controller displays the current setpoint (SP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment for which operation is in progress, the current number of repetitions (RCY), and the total sum of repetitions.
- Target SP Display**
On the Setpoint display (LCD), the controller displays the current setpoint (SP) and final target setpoint (TSP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the program pattern name (only displayed when setting the program pattern name using an optional parameter setting tool (model: LL100-E10)).
- OUT Display**
On the Setpoint display (LCD), the controller displays the current target setpoint (SP), the PID number (PID) being used, the program pattern number (PTNO), the segment number (SEGNO) for which operation is in progress, and the number of segments included in the selected program pattern, and the control output value (OUT).
- Deviation Trend Display**
On the Setpoint display (LCD), the controller displays the deviation trend.
- Pattern Display**
On the Setpoint display (LCD), the controller displays the selected program pattern.
- Event Display**
On the Setpoint display (LCD), the controller displays the event number for which an event has occurred.



Operating Displays for Single-loop Heating/cooling Control

- SP Display**
On the Setpoint display (LCD), the controller displays the current target setpoint (SP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the remaining time of the segment (TM) for which operation is in progress, the current number of repetitions (RCY), and the total sum of repetitions.
- Target SP Display**
On the Setpoint display (LCD), the controller displays the current target setpoint (SP) and final target setpoint (TSP), the program pattern number (PTNO) selected, the segment number (SEGNO) for which operation is in progress, the number of segments included in the selected program pattern, the program pattern name (only displayed when setting the program pattern name using an optional parameter setting tool (model: LL100-E10)).


- Heating/Cooling OUT Display**
On the Setpoint display (LCD), the controller displays the current target setpoint (SP), the PID number (PID) being used, and the heating-side (HEAT) and cooling-side (COOL) control output values.
- Deviation Trend Display**
On the Setpoint display (LCD), the controller displays the deviation trend.
- Pattern Display**
On the Setpoint display (LCD), the controller displays the selected program pattern.
- Event Display**
On the Setpoint display (LCD), the controller displays the event number for which an event has occurred.



2. Performing/Canceling Auto-tuning


Perform auto-tuning when you have finished creating program patterns. Make sure the controller is in program (RUN) mode and in automatic (AUTO) mode before carrying out auto-tuning. See "5. Switching between RUN and RESET Modes" to change to RUN or "6. Switching between AUTO and MAN" to change to AUTO. PID constants are obtained by using the current program setpoint value at the start of auto-tuning. See the back of **Programming User's Manual** for more information.

NOTE
 When on-off control is being used, auto-tuning cannot be carried out. Moreover, do not perform auto-tuning when controlling any of the following processes:
 • Control processes with quick response such as flow control or pressure control
 • Processes where even temporary output on/off results in inconvenience
 • Processes where a large output change at control element results in inconvenience
 • Processes where variations in PV may exceed an allowable range, adversely affecting product quality



3. Setting PID Manually


If you know the values to be set or if suitable PID constants cannot be obtained by auto-tuning, follow the procedure below to set values.



4. Selecting Program Pattern Number (PT.No)


The following operating procedure selects program pattern 1. A program pattern number can only be selected when the controller is in a RESET mode.

NOTE
 If contact input, which is used to select between program pattern numbers, is on, any program pattern number cannot be selected by key operation.



5. Switching between RUN and RESET Modes

The following operating procedure switches the RUN mode and the RESET mode.




When in the RESET mode, the controller provides the following input/output values.

PV input	Value of process variable
Control output	Preset output value (factory-set to 0%)
Event output	OFF, if there is any event.

6. Switching between AUTO and MAN


NOTE
 If AUTO and MAN have been switched using contact input, when the contact input is ON, switching between AUTO and MAN cannot be achieved by keystroke.



7. Manipulating Control Output during Manual Operation


NOTE
 Control output cannot be changed if the controller is in the RESET mode. In this case, the preset output value (operating parameter PO) will be output.

A control output value is linked with a display value changed using the [F5] or [F6] key. Note that the control output changes as displayed without requiring the [F1] key.




Manipulating the Control Output during Heating/Cooling Control

Showing the Heating/Cooling OUT display.




Controller behavior and control output manipulation when the dead band is positive

The following is an example when the DB parameter is set at 12.4%. If you hold down the [F5] key with the heating-side output under manipulation (i.e., cooling-side output C = 0.0%), the heating-side output (H) decreases. Consequently, both the heating-side and cooling-side outputs change to 0.0%. If you keep the [F5] key held down longer, you enter the state of manipulating the cooling-side output, and its value begins to increase. Inversely, if you hold down the [F6] key with the cooling-side output under manipulation (i.e., heating-side output H = 0.0%), the cooling-side output (C) decreases. Consequently, both the heating-side and cooling-side outputs go to 0.0%. If you keep the [F6] key held down longer, you enter the state of manipulating the heating-side output, and its value begins to increase.



● Controller behavior and control output manipulation when the dead band is negative
 The following is an example when the DB parameter is set at -12.4%.
 If you hold down the **[H]** key with the heating-side output under manipulation (i.e., cooling-side output C = 0.0%), the heating-side output (H =) decreases. If the output H falls below 24.8%, the cooling-side output C begins to increase from 0.0%. If you keep the **[H]** key held down longer and the output C rises above 24.8%, the output H goes to 0.0% and you enter the state of manipulating the cooling-side output.



8. Enabling/Disabling Hold Mode of Program Operation

Enabling/disabling the hold mode of program operation should be done when the controller is in operation. The following operating procedure is an example of setting program operation in the hold mode.

- Bring the operating display into view (appears at power-on).
- To enable the hold mode of program operation
 Press the **[HOLD]** key once to display the HOLD:ON mode parameter.
 To disable the hold mode of program operation
 Press the **[HOLD]** key once to display the HOLD:OFF mode parameter.
 The figure below is an example of enabling the hold mode of program operation.
- Press the **[HOLD]** key once. The controller switches to either hold mode or non-hold mode.

* Other operating procedures for disabling the hold mode:

- Press the **[HOLD]** key for two seconds during hold-mode operation. In this case, the controller resumes program operation.
- Execute the "advance" function during hold-mode operation. In this case, the segment is advanced.

9. Changing Program Setpoints when in Hold Mode

The following operating procedure changes program setpoints when program operation (in soak segment) is put in the hold mode.

When you have finished changing the setpoints, disable the hold mode of program operation as instructed in "8. Enabling/Disabling Hold Mode of Program Operation." The controller resumes program operation when the hold mode is disabled.

- Set program operation in the hold mode. To do this, see "8. Enabling/Disabling Hold Mode of Program Operation."
- Press the **[HOLD]** key once to display the symbol "▶▶".
- Press the **[▲]** or **[▼]** key to change the setpoint.
- Press the **[HOLD]** key once to register the setpoint.

How to Change the Target Setpoint in the Segment being in Operation

- Set the program operation in the hold mode.
- Change the target setpoint of the corresponding segment of operation program on the program parameter setting display.
- When the hold mode of program operation is disabled, the controller resumes the control toward the changed target setpoint.

Note: To perform the above, specify "programming by setting segment times" for segment setting method (SEG.T setpoint parameter), and do not change the hold SP and hold time on the operating display in HOLD mode.

10. Executing "Advance" Function

The following operating procedure advances the controller from segment 1 to segment 2. If you execute the "advance" function during hold-mode operation, the hold mode is disabled.

- Bring the current operating display for program operation into view.
- Press the **[HOLD]** key twice to display the ADV:ON mode parameter.
- Press the **[HOLD]** key once. The controller resumes operation from the target setpoint of segment 1.

11. Switching to Local-mode (LOCAL) Operation

The controller can be switched to local-mode operation when it is in program operation or in a RESET mode. The following operating procedure switches the controller to local-mode operation during program operation.

- Bring the current display for program operation into view.
- Press the **[HOLD]** key several times to display the LOC:ON mode parameter.
- Press the **[HOLD]** key once. The controller begins running with a local setpoint (L.SP).
 The figure below shows an example of setting the controller with the local setpoint of 50.0°C.

12. Changing Setpoints during Local-mode Operation


The following operating procedure changes setpoints during local-mode operation.

- Change the controller to local-mode operation. To do this, see "11. Switching to Local-mode (LOCAL) Operation."
- Press the **[▲]** or **[▼]** key to change the local setpoint.
- Press the **[HOLD]** key once to register the setpoint.

13. Troubleshooting

Troubleshooting Flow

If the operation display does not appear after turning on the controller's power, follow the measures in the procedure below. If a problem appears complicated, contact our sales representative.



IMPORTANT

Take note of the parameter settings when asking the vendor for repair.

Errors at Power On

The following table shows errors that may be detected by the fault diagnosis function when the power is turned on.

Display position	Error indication (on PV display unit)	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy
PV indicating LED	E000	Faulty RAM	None	0% or less or OFF	OFF	0% or less	Stopped	Faulty Contact us for repair.
	E001	Faulty ROM	None	0% or less or OFF	OFF	0% or less	Stopped	
	E002	System data error	Undefined	Undefined	Undefined	Undefined	Stopped	
PV decimal point blinks		Faulty calibration value	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal action (out of accuracy)	Normal operation	Check and set the initialized parameter.
LCD	Error code (Note) (See description below.)	Parameter error	Normal action	0% or less or OFF	Normal action	Normal action	Normal operation	Check and set the initialized parameter.


An error code is displayed in the event of an error, according to its type.

An error code is a two-digit figure in which a combination of 6 bits of on and off is converted into a decimal number. The following shows the relationship between each bit and parameter to be checked for abnormality.

Bit No.	6	5	4	3	2	1	0
Parameter to be checked	Operation mode/output	Operating parameters	Setup parameters	Range data	UP mode	Custom computing data	Calibration data

For example, if an error occurs with the operating parameter and calibration data, the error code will be as follows:

Bit No.	6	5	4	3	2	1	0
Error Code	-	2 ²	2 ¹	2 ⁰	2 ³	2 ²	2 ⁰



Possible Errors during Operation

The following shows possible errors occurring during operations.

Display position (Note)	Error indication (on PV display unit)	Description of error	PV	Control output	Alarm output	Retransmission output	Communication	Remedy
3	Displays "RJC" and PV alternately	RJC error	Measured with RJC=OFF	Normal action				Faulty Contact us for repair.
	E300	ADC error	105%	In AUTO: Preset value output In MAN: Normal action				
	B.OUT	PV burnout error	Dependent on the BSL parameter Up-scale: 105% Down-scale: -5%	Normal action	Normal action	Normal action	Normal action	Check wires and sensor.
	OVER or -OVER	Excessive PV Out of -5 to 105%	-5% or 105%	Normal action	Normal action	Normal action	Normal action	Check process.
2	E200	Auto-tuning failure (Time-out)		Action with PID existing before auto-tuning				Check process. Press any key to erase error indication.
		Feedback resistor burnout	Normal action	Stopped		Stopped		Check the feedback resistor.
1	Blinking dot in the most left on LCD	Faulty communication line		Normal action		Normal action		Check wires and communication parameters, and make resetting. Recovery at normal receipt.
	Decimal point at right end lights.	Runaway (due to defective power or noise)	Undefined	0% or less or OFF	OFF	0% or less	Stopped	Faulty if power off/on does not reset start the unit. Contact us for repair.
-	All indications off	Power off	None					Check for abnormal power.

Note: 1: PV indicating LED display
 2: LCD
 3: Display showing the PV of the loop in which the error has been caused.

Remedies if Power Failure Occurs during Operations

The operation status and remedies after a power failure differ with the length of power failure time:

- Instantaneous power failure of 20 ms or less
 A power failure is not detected. Normal operation continues.
- Power failure of about 2 seconds or less
 The following show effects caused in "settings" and "operation status."

Alarm action	Continues. Alarm with standby function will enter standby status.
Setting parameter	Set contents of each parameter are retained.
Auto-tuning	Cancelled.
Control action	Action before power failure continues.

- Power failure of more than about 2 seconds
 The following show effects caused in "settings" and "operation status."

Alarm action	Continues. Alarm with standby function will enter standby status.
Setting parameter	Set contents of each parameter are retained.
Auto-tuning	Cancelled.
Control action	Differs with setting of setup parameter "R.MD"(restart mode). R.MD setting Control action after recovery from power failure CONT Continues action before power failure. (Factory-set default) MAN Outputs preset output value (PO) as control output and continues action set before power failure in MAN mode. For heating/cooling control, starts action from heating-side output value and cooling-side output value of 50% of control computation output. RESET Outputs preset output value (PO) as control output and continues action set before power failure in AUTO mode. For heating/cooling control, starts action from heating-side output value and cooling-side output value of 50% of control computation output.

Troubleshooting When the Controller Fails to Operate Correctly

If your control tasks are not successful, check the preset parameters and controller wiring before concluding the controller to be defective. The following show some examples of troubleshooting you should refer to in order to avoid the possibility of other problems.

- The controller does not show the correct measured input (PV).

The UP750 controllers have a universal input.
 The type of PV input can be set/changed using the parameter "IN1". At this point, the controller must be wired correctly according to the selected type of PV input. Check the wiring first if the controller fails to show the correct PV value. To do this, refer to "Initial Settings User's Manual".
 With the parameters "RH1", "RL1", "SDP1", "SH1" and "SL1", it is possible to scale the input signal and change its number of decimal places. Also check that these parameters are configured correctly.

- The controller does not provide any control output or the control output does not change at all.

The UP750 controllers have a universal output.
 The type of control output can be set/changed using the parameter "OT1".
 At this point, the controller must be wired correctly according to the selected type of control output. Check the wiring first if the controller provides no control output. To do this, refer to "6. Terminal Wiring Diagrams," in "Installation User's Manual".
 With the parameters "OH" and "OL", it is possible to set/change the high and low limits of control output. The control output may not change at all, however, because of restrictions on these parameters. Also check the restrictions on these parameters.
 The control output can only be changed when the controller is in the MAN mode.
 If the MAN lamp is off (i.e., the controller is in the AUTO mode), you cannot change the control output using key operation.

- The control output does not change soon after the target setpoint (SP) has been changed.

If this happens, check the setpoint of the parameter "MOD1". In cases where fixed-point control is selected as the PID control mode (MOD1 = 1), tracking based on the I-term works to prevent the control output from changing suddenly even if the target setpoint (SP) is varied.
 The control output therefore may appear to be working incorrectly at first; however it gradually adapts itself to the new target setpoint.




This manual contains a parameter map as a guideline for setting parameters.

If you are unsure of the key operation sequence, press the [F] key no more than four times. This displays a screen as shown (i.e., operating display).

Basic Key Operation Sequence


- 1. Setting display can be switched (moved) using the [F] key.
2. A numerical value is changed by (1) Using the [V] or [A] key to change a displayed value... (2) Pressing the [F] key to register it.
3. Pressing the [F] key on an operating display (for more than 3 seconds) brings you to the operating parameter setting display.
4. Pressing the [F] key on the operating parameter setting display (for more than 3 seconds) returns you to the operating display.
5. Pressing the [F] key on the setup parameter setting display (for more than 3 seconds) returns you to the setup parameter menu display, press the [F] key.

Determine PV input type first. Settings herein are described in "2. Setting PV Input Type (Setting First at Power-on)", in Initial Settings User's Manual.



After PV input type (IN1), input/output parameters such as PV input unit (UN1), maximum value of PV input range (RH1), and minimum value of PV input range (RL1) will be displayed.

Operating Display



Operating Display for Heating/Cooling Control




Table with 4 columns: Key (HOLD, ADV, LOC, AM1, SST) and Description (Pause of program operation, Advance of segment, Local-mode operation, AUTOMAN switching, Start-of-program segment number).

Operating Parameter Setting Display




Table listing parameters: A1-A4 (Instrument alarm setpoint), AT (Auto-tuning), SC (SUPER function), BS (PV input bias), FL (PV input filter), ORB (ON/OFF rate detection band), ORH (ON/OFF rate high limit), ORL (ON/OFF rate low limit), S.TM (Starting time of program pattern operation).

Table listing PID parameters 1.P to 1.Oc: 1.P (Proportional band), 1.I (Integral time), 1.D (Derivative time), 1.OH (Output high limit), 1.OL (Output low limit), 1.MR (Manual reset), 1.H (ON/OFF control hysteresis), 1.DR (Direct/reverse action switching), 1.Pc (Cooling-side proportional band), 1.Ic (Cooling-side integral time), 1.Dc (Cooling-side derivative time), 1.Hc (Cooling-side ON/OFF control hysteresis), 1.DB (Dead band), 1.PO (Preset output), 1.Oc (Cooling-side preset output).

Table listing PID parameters 2.P to 2.Oc: 2.P (Proportional band), 2.I (Integral time), 2.D (Derivative time), 2.OH (Output high limit), 2.OL (Output low limit), 2.MR (Manual reset), 2.H (ON/OFF control hysteresis), 2.DR (Direct/reverse action switching), 2.Pc (Cooling-side proportional band), 2.Ic (Cooling-side integral time), 2.Dc (Cooling-side derivative time), 2.Hc (Cooling-side ON/OFF control hysteresis), 2.DB (Dead band), 2.PO (Preset output), 2.Oc (Cooling-side preset output).

Table listing PID parameters 3.P to 3.Oc: 3.P (Proportional band), 3.I (Integral time), 3.D (Derivative time), 3.OH (Output high limit), 3.OL (Output low limit), 3.MR (Manual reset), 3.H (ON/OFF control hysteresis), 3.DR (Direct/reverse action switching), 3.Pc (Cooling-side proportional band), 3.Ic (Cooling-side integral time), 3.Dc (Cooling-side derivative time), 3.Hc (Cooling-side ON/OFF control hysteresis), 3.DB (Dead band), 3.PO (Preset output), 3.Oc (Cooling-side preset output).


Table listing PID parameters 4.P to 4.Oc: 4.P (Proportional band), 4.I (Integral time), 4.D (Derivative time), 4.OH (Output high limit), 4.OL (Output low limit), 4.MR (Manual reset), 4.H (ON/OFF control hysteresis), 4.DR (Direct/reverse action switching), 4.Pc (Cooling-side proportional band), 4.Ic (Cooling-side integral time), 4.Dc (Cooling-side derivative time), 4.Hc (Cooling-side ON/OFF control hysteresis), 4.DB (Dead band), 4.PO (Preset output), 4.Oc (Cooling-side preset output).

Table listing PID parameters 5.P to 5.Oc: 5.P (Proportional band), 5.I (Integral time), 5.D (Derivative time), 5.OH (Output high limit), 5.OL (Output low limit), 5.MR (Manual reset), 5.H (ON/OFF control hysteresis), 5.DR (Direct/reverse action switching), 5.Pc (Cooling-side proportional band), 5.Ic (Cooling-side integral time), 5.Dc (Cooling-side derivative time), 5.Hc (Cooling-side ON/OFF control hysteresis), 5.DB (Dead band), 5.PO (Preset output), 5.Oc (Cooling-side preset output).

Table listing PID parameters 6.P to 6.Oc: 6.P (Proportional band), 6.I (Integral time), 6.D (Derivative time), 6.OH (Output high limit), 6.OL (Output low limit), 6.MR (Manual reset), 6.H (ON/OFF control hysteresis), 6.DR (Direct/reverse action switching), 6.Pc (Cooling-side proportional band), 6.Ic (Cooling-side integral time), 6.Dc (Cooling-side derivative time), 6.Hc (Cooling-side ON/OFF control hysteresis), 6.DB (Dead band), 6.PO (Preset output), 6.Oc (Cooling-side preset output).

Table listing PID parameters 7.P to 7.Oc: 7.P (Proportional band), 7.I (Integral time), 7.D (Derivative time), 7.OH (Output high limit), 7.OL (Output low limit), 7.MR (Manual reset), 7.H (ON/OFF control hysteresis), 7.DR (Direct/reverse action switching), 7.Pc (Cooling-side proportional band), 7.Ic (Cooling-side integral time), 7.Dc (Cooling-side derivative time), 7.Hc (Cooling-side ON/OFF control hysteresis), 7.DB (Dead band), 7.PO (Preset output), 7.Oc (Cooling-side preset output).

Table listing PID parameters 8.P to 8.Oc: 8.P (Proportional band), 8.I (Integral time), 8.D (Derivative time), 8.OH (Output high limit), 8.OL (Output low limit), 8.MR (Manual reset), 8.H (ON/OFF control hysteresis), 8.DR (Direct/reverse action switching), 8.Pc (Cooling-side proportional band), 8.Ic (Cooling-side integral time), 8.Dc (Cooling-side derivative time), 8.Hc (Cooling-side ON/OFF control hysteresis), 8.DB (Dead band), 8.PO (Preset output), 8.Oc (Cooling-side preset output).



NOTE

Changing the registered value of a setup parameter may cause the registered value of an operating parameter to be initialized automatically. Thus, when you have changed a setup parameter, always check that the registered value of the operating parameter is appropriate. If it is initialized to default, reset it to the required value.



List of PV Event Types, Local Event Types, and Instrument Alarm Types

The table below shows the types and actions of PV event, Local event and Instrument alarm. In the table, codes 1 to 10 are not provided with stand-by actions, while codes 11 to 20 (available for Instrument Alarm only) are provided with stand-by actions.

Alarm type	Alarm action	Alarm type code		Alarm type	Alarm action	Alarm type code	
		Contact closes if alarm occurs	Contact opens if alarm occurs			Contact closes if alarm occurs	Contact opens if alarm occurs
No alarm			OFF				
PV high limit	Hysteresis Open (unlit) / Closed (lit) PV Alarm setpoint	1		De-energized on deviation low limit alarm	Hysteresis Open (lit) / Closed (unlit) Deviation setpoint / Target SP		6
PV low limit	Hysteresis Closed (lit) / Open (unlit) Alarm setpoint / PV	2		Deviation high and low limits	Hysteresis Closed (unlit) / Open (lit) Deviation setpoint / Target SP		7
Deviation high limit	Hysteresis Open (unlit) / Closed (lit) PV / Target SP	3		Deviation within high and low limits	Hysteresis Open (unlit) / Open (unlit) Deviation setpoint / Target SP		8
Deviation low limit	Hysteresis Closed (lit) / Open (unlit) Deviation setpoint / Target SP	4		De-energized on PV high limit	Hysteresis Closed (unlit) / Open (lit) PV Alarm setpoint		9
De-energized on deviation high limit alarm	Hysteresis Closed (unlit) / Open (lit) PV / Target SP	5		De-energized on PV low limit	Hysteresis Open (lit) / Closed (unlit) Alarm setpoint / PV		10
SP high limit	Hysteresis Open (unlit) / Closed (lit) SP Alarm setpoint	28		Output high limit	Hysteresis Open (unlit) / Closed (lit) Output value / Alarm setpoint		30
SP low limit	Hysteresis Closed (lit) / Open (unlit) Alarm setpoint / SP	29		Output low limit	Hysteresis Closed (lit) / Open (unlit) Alarm setpoint / Output value		31

The following alarm type are used only for "Instrument Alarm."

Stand-by Action



This manual describes the functions of parameters briefly. In addition, each parameter table has a "User Setting" column, where you can record your setpoints when setting them in the controller.

* Parameters relating to PV or program setpoints should all be set in real numbers. For example, use temperature values to define program setpoints and PV event setpoints for temperature input.

Operation Mode Parameters

Located in: MODE key (MODE key on the instrument's front panel)

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include HOLD, ADV, LOC, A/M1, SST.

Operating Parameters

Instrument Alarm Setting Parameters

Located in: Main menu = AL

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include A1, A2, A3, A4.

Operation-related Parameters

Located in: Main menu = LP1; Submenu = PAR

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include AT, SC, BS, FL, ORB, ORH, ORL, S.TM.

PID-related Parameters



Located in: Main menu = LP1; Submenu = 1.PID

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include 1.P, 1.I, 1.D, 1.OH, 1.OL, 1.MR.

* The User Setting column in the table below is provided for the customer to record setpoints.

* The column Target Item in CD-ROM in the table below provides references from User's Manual (Reference) (CD-ROM Version) which describes items in more detail and items that are not contained in this manual.

Main parameter table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include 1.H, 1.DR, 1.Pc, 1.Ic, 1.Dc, 1.Hc, 1.DB, 1.PO, 1.Oc.



If you are using two or more groups of PID parameters, use the following table to record their values.

Table with 9 columns: Parameter, n=2, n=3, n=4, n=5, n=6, n=7, n=8. Rows include n.P, n.I, n.D, n.OH, n.OL, n.MR, n.H, n.DR, n.Pc, n.Ic, n.Dc, n.Hc, n.DB, n.PO, n.Oc.

Ten-segment Linearizer 1 Parameters

Located in: Main menu = PYS1




Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include 1.a1, 1.b1, 1.a2, 1.b2, 1.a3, 1.b3, 1.a4, 1.b4, 1.a5, 1.b5, 1.a6, 1.b6, 1.a7, 1.b7.

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include 1.a8, 1.b8, 1.a9, 1.b9, 1.a10, 1.b10, 1.a11, 1.b11, 1.PMD.

Setup Parameters

Program Setpoint-related Parameters

Located in: Main menu = PARA; Submenu = SP

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include SPT, TMU, SEG.T, PT2.G, PNC, SPH1, SPL1, SPH2, SPL2.

Alarm-related Parameters

Located in: Main menu = PARA; Submenu = ALM


Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include PEH1-8, AL1-4, HY1-4, AMD.

Control Action-related Parameters

Located in: Main menu = PARA; Submenu = CTL

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include OPR1, MOD1, AR1, ZON, R.MD.

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include R.TM, GRP, 1.RP1-6, RHY1, RDV1.



Analog Input Computation Parameters

Located in: Main menu = CMLP; Submenu = AIN

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include A.BS1, A.FL1, A.SR1, A.LC1, A.BS2, A.FL2, A.SR2, A.LC2, A.BS3, A.FL3, A.SR3, A.LC3.

Retransmission Output Parameters

Located in: Main menu = CMLP; Submenu = RET

Table with 6 columns: Parameter Symbol, Name of Parameter, Setting Range and Description, Initial Value, User Setting, Target Item in CD-ROM. Rows include RET1, RTH1, RTL1, RET2, RTH2, RTL2.

