

Operator's Manual



Optris GmbH Ferdinand-Buisson-Str. 14 13127 Berlin Germany

Tel.: +49 30 500 197-0 Fax: +49 30 500 197-10

E-mail: info@optris.global Internet: www.optris.global



Table of contents

T	able of contents3					
1	General Notes					
	1.1	Intended use	7			
	1.2	Warranty	8			
	1.3	Scope of delivery	9			
	1.4	Maintenance	9			
	1.4.	1 Cleaning	9			
	1.5	Model overview	.10			
2	Тес	hnical Data	.11			
	2.1	General specifications	.11			
	2.2	Electrical specifications	.15			

+optris

٨	EI2	octrica		51	
	3.5	5.4	Outdoor protective housing	.50	
	3.5	5.3	Laminar air purge for CoolingJacket	.49	
	3.5	5.2	CoolingJacket Advanced	.45	
	3.5	5.1	CoolingJacket	.43	
	3.5	High	n temperature accessories	.43	
	3.4	Mou	Inting accessories (optional)	.42	
	3.3	Fixir	ng the focus of the lens (only for PI 05M/ 08M/ 1M)	.40	
	3.2	Cha	nging the lens	.39	
	3.1	Dim	ensions	.31	
3	Me	echani	cal Installation	.31	
	2.4	Opti	cal specifications	.21	
	2.3	Mea	Measurement specifications		

Table of contents

	4.1	1	Proc	ess interface	52
		4.1.1	I	PIN allocation	54
		4.1.2	2	Industrial Process Interface (optional)	56
	4.2	2	Exar	nple for a Fail-Safe monitoring of the PI with a PLC	59
	4.3	3	USB	cable extension	61
5	I	IRm	obile	Арр	63
6	;	Soft	ware	PIX Connect	65
	6.1	1	Insta	Illation and initial start-up	66
	6.2	2	Soft	ware window	68
	(6.2.1	I	Basis features of the software PIX Connect	70
7	I	Basi	ics o	f Infrared Thermometry	73
8	I	Emi	ssivi	ty	79
	8.1	1	Defir	nition	79

+optris

8.2	Determination of unknown emissivity	81		
8.3	Characteristic emissivity	83		
Appen	idix A – Table of emissivity for metals	84		
Appen	idix B – Table of emissivity for non-metals	86		
Appen	dix C – Quick start for serial communication	87		
Appen	Appendix D – Interprocess Communication (IPC)89			
Appen	dix E – PIX Connect Resource Translator	90		
Appen	dix F – Wiring diagrams PIF	91		
Appen	Appendix G – Declaration of Conformity95			

1 General Notes

1.1 Intended use

Thank you for choosing the **optris[®] PI** infrared camera.

The optris PI calculates the surface temperature based on the emitted infrared energy of objects [▶7 Basics of Infrared Thermometry]. The two-dimensional detector (FPA - focal plane array) allows a measurement of an area and will be shown as thermal image using standardized palettes. The radiometric processing of the picture data enables the user to do a comfortable detailed analysis with the software PIX Connect.

The PI is a precise instrument and contains an extremely sensitive infrared detector and a highquality lens.



The alignment of the camera to **intensive energy sources** (e.g. devices which emit laser radiation or reflections of such equipment) can cause an **irreparable defect of the infrared detector**. This is also valid if the camera is switched off.

Such kinds of damages are excluded from warranty.



Read the manual carefully before the initial start-up. The producer reserves the right to change the herein described specifications in case of technical advance of the product.

• Avoid abrupt changes of the ambient temperature.



- Avoid static electricity, arc welders, and induction heaters. Keep away from very strong EMF (electromagnetic fields).
- In case of problems or questions which may arise when you use the infrared camera, please contact our service department.



► All accessories can be ordered according to the referred part numbers in brackets [].

1.2 Warranty

Each single product passes through a quality process. Nevertheless, if failures occur contact the customer service at once. The warranty period covers 24 months starting on the delivery date. After the warranty is expired the manufacturer guarantees additional 6 months warranty for all repaired or substituted product components. Warranty does not apply to damages, which result from misuse or neglect. The warranty also expires if you open the product. The manufacturer is not liable for consequential damage or in case of a non-intended use of the product.

If a failure occurs during the warranty period the product will be replaced, calibrated or repaired without further charges. The freight costs will be paid by the sender. The manufacturer reserves the right to exchange components of the product instead of repairing it. If the failure results from misuse or neglect the user has to pay for the repair. In that case you may ask for a cost estimate beforehand.

General Notes

1.3 Scope of delivery

- PI 160, PI 200, PI 230, PI 400i, PI 450i, PI 450i G7, PI 640, PI 640 G7, PI 05M, PI 08M or PI 1M incl. 1 lens
- USB-cable: 1 m (standard scope of supply, no IP67 protection class)
 1 m, 3 m, 5 m, 10 m, 20 m (optional, for industrial applications, with IP67)
- Table tripod
- Process interface cable incl. terminal block (1 m)
- Software package PIX Connect
- Operators manual
- Aluminum case
- PI 640/ 640 G7 only: robust hard transport case (IP67)
- PI 200/ 230 only: focusing tool for VIS camera

1.4 Maintenance



Never use cleaning compounds which contain solvents (neither for the lens nor for the housing).

1.4.1 Cleaning

Blow off loose particles using clean compressed air. The lens surface can be cleaned with a soft, humid tissue (moistened with water) or a lens cleaner (e.g. Purosol or B+W Lens Cleaner).

1.5 Model overview

The cameras of the PI series are available in the following basic versions:

Model	Model code	Temperature range	Spectral range	Frame rate	Typical applications
PI 160	IR	-20 to 900 °C 200 to 1500 °C (optional)	7.5 - 13 µm	120 Hz	Surface measurements in industrial application
PI 200/ PI 230	BI-SPECTRAL	-20 to 900 °C 200 to 1500 °C (optional)	7.5 - 13 µm	128 Hz	Synchronous recording of VIS and IR videos and images
PI 400i/ PI 450i	IR	-20 to 900 °C 200 to 1500 °C (optional)	7.5 - 13 µm	80 Hz	Real-time thermographic images in high speed; Detection of smallest temperature differences (PI 450i)
PI 450i G7	IR	200 to 1500 °C 150 to 900 °C	7.9 µm	80 Hz/ 27 Hz	Measurement of glass (with Line-Scanning mode)
PI 640	IR	-20 to 900 °C 200 to 1500 °C (optional)	7.5 - 13 µm	32 Hz	Pin-sharp radiometric recordings in real time
PI 640 G7	IR	200 to 1500 °C 150 to 900 °C	7.9 µm	32 Hz	Measurement of glass (with Line-Scanning mode)
PI 05M	IR	900 to 2450 °C	500 – 540 nm	Up to 1 kHz	Measurement of metallic surfaces, graphite or ceramics with short wavelengths
PI 08M	IR	5751900 °C	780 – 820 nm	Bis 1 kHz	Measurement of metallic surfaces, graphite or ceramics with short wavelengths, especially for laser applications
PI 1M	IR	450 to 1800 °C	0.85 - 1.1 µm	Up to 1 kHz	Measurement of metallic surfaces, graphite or ceramics with short wavelengths

Table 1: Model overview

2.1 General specifications

Environmental rating:	IP67 (NEMA-4)
Ambient temperature:	050 °C [PI 160/ PI 200/ PI 230/ PI 400i/ PI 640/ PI 640 G7] 550 °C [PI 05M/ PI 08M/ PI 1M] 070 °C [PI 450i/ PI 450i G7]
Storage temperature:	-4070 °C (-4085 °C [PI 450i/ PI 450i G7])
Relative humidity:	1095 %, non-condensing
Material (housing):	Aluminum, anodized
Dimensions:	PI 160/ PI 200/ PI 230: 45 x 45 x 60 - 76 mm (depending on lens and focus position) PI 400i/ PI 450i (450i G7)/ PI 640 (640 G7): 46 x 56 x 76 - 100 mm (depending on lens and focus position) PI 640 microscope optics: 46 x 56 x 119 – 126 mm (depending on focus position) PI 05M/ PI 08M/ PI 1M: 46 x 56 x 88 - 129 mm (depending on lens and focus position)
Weight:	PI 160: 195 g PI 200/ PI 230: 215 g PI 400i/ PI 450i (450i G7)/ PI 640 (640 G7)/PI 05M/ PI 08M/ PI 1M: 320 g
Cable length (USB 2.0):	1 m (standard), 3 m, 5 m, 10 m, 20 m

Vibration ¹⁾ :	IEC 60068-2-6 (sinus shaped) IEC 60068-2-64 (broadband noise)
Shock ¹⁾ :	IEC 60068-2-27 (25 G and 50 G)

¹⁾ Used standards for vibration and shock:

IEC 60068-1:1988 + Corr. 1988 + A1	: 1992 DIN EN 60068-1 :1995-03
"Umweltprüfungen - Teil 1: Allgemein	nes und Leitfaden"
IEC 60068-2-6:2007	DIN EN 60068-2-6; VDE 0468-2-6:2008-10
"Umgebungseinflüsse - Teil 2-6: Prüf	iverfahren - Prüfung Fc: Schwingen (sinusförmig)"
IEC 60068-2-27:2008	DIN EN 60068-2-27; VDE 0468-2-27:2010-02
"Umgebungseinflüsse - Teil 2-27: Prü	ifverfahren - Prüfung Ea und Leitfaden: Schocken"
IEC 60068-2-47:2005 "Umgebungseinflüsse - Teil 2-47: Prü Schwing-, Stoß- und ähnliche dynam	DIN EN 60068-2-47:2006-03
IEC 60068-2-64:2008 "Umgebungseinflüsse - Teil 2-64: Prü (digital geregelt) und Leitfaden"	DIN EN 60068-2-64; VDE 0468-2-64:2009-04 ifverfahren - Prüfung Fh: Schwingen, Breitbandrauschen

Figure 1: Used standards

Stress program (camera in operation):

Shock, half sinus 25 G – testing Ea 25 G (acc. IEC 60068-2-27)				
Acceleration	245 m/s ²	(25 G)		

Pulse duration	11 ms			
Number of directions	6	(3 axes with 2 directions each)		
Duration	600 Shocks	(100 Shocks each direction)		
Shock, half sinus 50 G – testin	g Ea 50 G (acc. IEC 60068	3-2-27)		
Acceleration	490 m/s ²	(50 G)		
Pulse duration	11 ms			
Number of directions	6	(3 axes with two directions each)		
Duration	18 Shocks	(3 Shocks each direction)		
Vibration, sinus shaped – testing Fc (acc. IEC60068-2-6)				
Frequency range	10 - 500 Hz			
Acceleration	29.42 m/s ²	(3 G)		
Frequency change	1 Octave/ min			
Number of axes	3			

Duration	1:30 h	(3 x 0.30 h)	
Vibration, broadband noise – 1	esting Fh (acc. IEC60068	-2-64)	
Frequency range	10 - 2000 Hz		
Acceleration	39.3 m/s ²	(4.01 Grms))	
Frequency spectrum	10 - 106 Hz	0.9610 (m/s²)²/Hz	(0.010 G ² /Hz)
	106 - 150 Hz	+6 dB/ Octave	
	150 - 500 Hz	1.9230 (m/s²)²/Hz	(0.020 G ² /Hz)
	500 - 2000 Hz	-6 dB/ Octave	
	2000 Hz	0.1245 (m/s²)²/Hz	(0.00126 G ² /Hz)
Number of axes	3		
Duration	3 h	(3 x 1 h)	

2.2 Electrical specifications

Power Supply:	5 VDC (powered via USB 2.0 interface)
Current draw:	Max 500 mA
AO: Output Standard Process Interface (PIF out)	0 - 10 V (Main measure area, measure area, internal temperature, flag status, recording status, line scan status, alarm, frame sync, fail-safe, external communication) [► Appendix F – Wiring diagrams PIF]
Al: Input Standard Process Interface (PIF in)	0 - 10 V (Emissivity, ambient temperature, reference temperature, uncommitted value, flag control, triggered snapshots, triggered recording, triggered linescanner, triggered event grabber, reset peak-/value-hold, switch temperature range) [▶ Appendix F – Wiring diagrams PIF]
DI: Digital Input Standard Process Interface	Flag control, , triggered snapshots, triggered recording, triggered linescanner, triggered event grabber, reset peak-/value-hold, switch temperature range Papendix F – Wiring diagrams PIF]
Digital interface:	USB 2.0

2.3 Measurement specifications

	<u>PI 160</u>	<u>PI 200</u> 1)	<u>PI 230¹⁾</u>									
Temperature ranges	-20100 °C	-20100 °C; 0250 °C; (20) 150900 °C ²⁾ ; Option: 2001500 °C										
Spectral range		7.5 - 13 μm										
Detector	UFPA, 160 x 120 pixel @ 120 Hz	UF 160 x 120 pix 640 x 480 pixel	PA, tel @ 128 Hz³) (visual camera)									
Lenses (FOV)	6° x 5° (F=1	,6); 23° x 17° (F=0,8); 41° x 31° (F=1); 72	° x 52° (F=1)									
Optics (FOV) – visual camera	-	54° x 40°	30° x 23°									
System accuracy 4)		±2°C or ±2 %										
Thermal sensitivity (NETD):	40 m	K with 23°; 0,3 K with 6°; 0.1 K with 41° ar	nd 72°									
Warm-up time		10 min										
Emissivity		0.1001.100										
Software		PIX Connect										

¹⁾ For an ideal combination of IR and VIS image we recommend the 41° lens for PI 200 and the 23° lens for PI 230

²⁾ Accuracy statement effective from 150 °C

³⁾ The following options can be set: Option 1 (IR with 96 Hz at 160 x 120 px; VIS with 32 Hz at 640 x 480 px); Option 2 (IR with 128 Hz at 160 x 120 px; VIS with 32 Hz at 596 x 447 px)

⁴⁾ At ambient temperature 23±5 °C; whichever is greater

	<u>PI 400i</u>	<u>PI 450i</u>	<u>PI 450i G7</u>
Temperature ranges	-20100 °C; 0250 °C; (20) 150	2001500 °C 150900 °C	
Sighting range ²⁾		-	0250 °C
Spectral range	7.5 -	13 µm	7.9 µm
Detector	3	UFPA, 82 x 288 pixel @ 80 Hz (switchable to 27 H	z)
Lenses (FOV)	18° x 14° (F=1	,1), 29° x 22° (F=0,9), 53° x 38° (F=0,9); 80)° x 54° (F=0,9)
System accuracy 3)		±2°C or ±2 %	
Thermal sensitivity (NETD):	75 mK⁴) with 29°, 53° and 80°; 0.1 K⁴) with 18°	40 mK4) with 29°, 53° and 80°; 60 mK4) with 18°	130 mK (T _{obj} = 650 °C)
Warm-up time		10 min	
Emissivity		0.1001.100	
Software		PIX Connect	

¹⁾ Accuracy statement effective from 150 °C
 ²⁾ The sighting range is used to align the G7 cameras
 ³⁾ At ambient temperature 23±5 °C; whichever is greater
 ⁴⁾ Value is valid at 40 Hz and 25 °C room temperature

	<u>PI 640</u>	<u>PI 640 G7</u>
Temperature ranges	-20100 °C; 0250 °C; (20) 150900 °C ¹⁾ Option: 2001500 °C	2001500 °C 150900 °C
Sighting range ²⁾	-	0250 °C
Spectral range	7.5 - 13 μm	7,9 µm
Detector	UF 640 x 480 Pi 640 x 120 Pi	PA, ixel @ 32 Hz xel @ 125Hz
Lenses (FOV)	15° x 11° (F=1); 33° x 25° (F=0,8);	60° x 45° (F=0,8); 90° x 64° (F=0,8)
Microscope lens (FOV)	12° x 9° (F=1,1)	-
System accuracy 3)	±2°C c	r ±2 %
Thermal sensitivity (NETD):	75 mK with 33°, 60° and 90° 85 mK with 15°	130 mK (T _{obj} = 650 °C)
Warm-up time	10	min
Emissivity	0.100.	1.100
Software	PIX Co	onnect

 $^{1)}$ Accuracy statement effective from 150 °C $^{2)}$ The sighting range is used to align the G7 cameras $^{3)}$ At ambient temperature 23±5 °C; whichever is greater

Warm-up time

	<u>PI 05M</u>	<u>PI 08M</u>	<u>PI 1M</u>					
Temperature ranges	900 2450 °C (27 Hz mode)	5751900 °C (27 Hz mode)	450 ¹⁾ 1800 °C (27 Hz mode)					
	950 2450 °C (80 Hz and 32 Hz mode)	625 1900 °C (80 Hz- and 32 Hz-mode)	500 ¹⁾ 1800 °C (80 Hz and 32 Hz mode)					
	1100 2450 °C (1 kHz mode)	750 1900 °C (1 kHz mode)	600 ¹⁾ 1800 °C (1 kHz mode)					
Spectral range	500 - 540 nm	780 – 820 nm	0,85 - 1,1 µm					
Detector	72x56 pixel @ 1 kHz (1 764 x 8 Pixel @ 1 kHz (fast line scan	pixel (freely selectable)) V) from 8x8 pixel (freely selectable))						
Lenses (FOV) ²⁾	FOV@764x480 px FOV@382x28	:: 26°x 16° (F=1,4) 8 px : 13°x 10°	FOV@764x480 px: 9°x 5° (F=2,8), 13°x 8° (F=2,4), 26°x16° (F=1,4), 39°x 25° (F=1,4) FOV@382x288 px: 4°x 3°, 7°x 5°, 13°x 10°, 20°x 15°					
System accuracy 3)	For object temperature < 2000 °C:	For object temperature < 1500 °C:	For object temperature < 1400 °C:					
	±1 % of reading for 27/32/80 Hz	±1 % of reading for 27/32/80 Hz	±1 % of reading for 27/32/80 Hz					
	±1,5 % of reading for 1 kHz	±1,5 % of reading for 1 kHz	±1,5 % of reading for 1 kHz					
	For object temperature > 2000 °C:	For object temperature > 1500 °C:	For object temperature < 1600 °C:					
	±2 % of reading for 27/32/80 Hz	±2 % of reading for 27/32/80 Hz	±2 % of reading for 27/32/80 Hz					
	±2,5 % of reading for 1 kHz	±2,5 % of reading for 1 kHz	±2,5 % of reading for 1 kHz					
Thermal sensitivity (NETD) ⁴⁾ :	< 2 K (< 1400 °C)	< 2 K (< 1000 °C)	< 2 K (< 900 °C)					
	< 4 K (< 2100 °C)	< 4 K (< 1600 °C)	< 4 K (< 1400 °C)					

10 min

•	nt]
51		
-		

Emissivity	0.1001.100
Software	PIX Connect

 $^{1)}$ +75 °C start temperature for optics with focal length f= 50 mm, f= 75 mm $^{2)}$ An additionally purchased lens for the PI 05M/ 08M/ 1M camera comes with the corresponding protective tube $^{3)}$ At an ambient temperature of 25 ° C $^{4)}$ Specified NETD value applies to all frequencies

2.4 Optical specifications

- Make sure that the focus of thermal channel is adjusted correctly. If necessary, focus the thermal imaging camera with the optics (**Figure 2**). The turning out of the optics leads to the focus setting "near" and the turning in of the lens to the focus setting "infinity".
- The visual camera (PI 200/230 only) is adjusted with the supplied focusing tool (**Figure 4**). For this purpose, the focusing tool with the two pins is placed on the visual camera and is focused to "near" by a left turn and focused to "infinity" by a right rotation.



Figure 2: Focusing by turning the exterior lens ring of camera



Figure 3: PI 200/ 230 with visual camera

1 IR channel 2 VIS channel



Figure 4: Focusing tool for VIS camera



For the PI 05M, PI 08M and PI 1M camera, you must first unscrew the protective tube in order to be able to focus the camera (**Figure 5**).



Figure 5: PI 05M/ PI 08M / PI 1M

The variety of different lenses offers the possibility to precisely measure objects in different distances. We offer lenses for close, standard distances and large distances. Different parameters are important if using infrared cameras. They display the connection between the distance of the measured object and the size of the pixel (**Table 2**).

With the help of BI-SPECTRAL technology at PI 200/ 230, a visual image (VIS) can be combined with a thermal image (IR). Both can be finally captured time synchronously.



Figure 6: Measurement field of the infrared camera optris® PI representing the 23° x 17° lens

- **HFOV**: Horizontal enlargement of the total measuring at object level
- **VFOV**: Vertical enlargement of the total measuring at object level
- **IFOV**: Size at the single pixel at object level
- **DFOV**: Diagonal dimension of the total measuring field at object level
- MFOV: Recommended, smallest measured object size of 3 x 3 pixel

The following tables with examples showing what spot sizes and pixel sizes will be reached in which distance. For individual configuration there are different lenses available. Wide angle lenses have a radial distortion due to their large opening angle; the software PIX Connect has an algorithm which corrects this distortion. As an alternative to the tables below, the optics calculator can also be used on the optris website (https://www.optris.global/optics-calculator) or via the optris calculator app. The app can be downloaded for free from the Google Play Store (see QR Code).





Table 2:

	gth		ment	Distance to measurement object [m]												
PI 160 / 200 160 x 120 px	Focal ler [mm]	Angle	Minimum measure distance		0.02	0.1	0.2	0.3	0.5	1	2	4	6	10	30	100
O23	10	23°	0.2 m	HFOV [m]	0.012	0.043	0.08	0.12	0.21	0.41	0.81	1.62	2.44	4.1	12.2	40.6
Standard lens		17°		VFOV [m]	0.009	0.032	0.06	0.09	0.15	0.30	0.60	1.21	1.81	3.0	9.0	30.1
		29°		DFOV [m]	0.015	0.054	0.10	0.16	0.26	0.51	1.01	2.02	3.03	5.1	15.2	50.5
		2.48 mrad		IFOV [mm]	0.1	0.3	0.5	0.8	1.3	2.5	5.0	9.9	14.9	24.8	74.4	248.0
O6	35.5	6°	0.5 m	HFOV [m]					0.06	0.11	0.23	0.45	0.68	1.1	3.4	11.3
Telephoto lens		5°		VFOV [m]					0.04	0.09	0.17	0.34	0.51	0.8	2.5	8.5
		8°		DFOV [m]					0.07	0.14	0.28	0.57	0.85	1.4	4.2	14.2
		0.70 mrad		IFOV [mm]					0.4	0.7	1.4	2.8	4.2	7.0	21.1	70.4
O48	5.7	41°	0.2 m	HFOV [m]	0.022	0.082	0.16	0.23	0.38	0.76	1.51	3.00	4.50	7.5	22.5	74.9
Wide angle lens		31°		VFOV [m]	0.016	0.059	0.11	0.17	0.28	0.55	1.10	2.19	3.28	5.5	16.4	54.5
		51°		DFOV [m]	0.027	0.101	0.19	0.29	0.47	0.94	1.86	3.72	5.57	9.3	27.8	92.7
		4.39 mrad		IFOV [mm]	0.1	0.4	0.9	1.3	2.2	4.4	8.8	17.5	26.3	43.9	131.6	438.6
072	3.3	72°	0.2 m	HFOV [m]	0.039	0.152	0.29	0.43	0.72	1.42	2.84	5.66	8.49	14.1	42.4	141.4
Wide angle lens		52°		VFOV [m]	0.027	0.106	0.20	0.30	0.50	0.99	1.98	3.95	5.92	9.9	29.6	98.6
		89°		DFOV [m]	0.048	0.186	0.36	0.53	0.87	1.74	3.46	6.91	10.35	17.2	51.7	172.3
		7.51 mrad		IFOV [mm]	0.2	0.8	1.5	2.3	3.8	7.5	15.0	30.0	45.0	75.1	225.2	750.8

* Note: The accuracy of measurement can be outside of the specifications for distances below the defined minimum distance.

PI 400i / 450i	igth	ment		Distance to measurement object [m]												
PI 450i G7 382 x 288 px	Focal ler [mm]	Min imurr measure distance	Angle		0.02	0.1	0.2	0.3	0.5	1	2	4	6	10	30	100
O29 Standard lens	13	0.35 m	29° 22° 37°	HFOV [m] VFOV [m] DFOV [m]		0.057 0.042 0.071	0.111 0.081 0.137	0.16 0.12 0.20	0.27 0.20 0.34	0.53 0.40 0.67	1.06 0.80 1.32	2.1 1.6 2.6	3.2 2.4 4.0	5.3 4.0 6.6	15.7 11.9 19.7	52.5 39.6 65.7
O13 Telephoto lens	20	0.45 m	18° 14° 23° 0.9 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]		0.1	0.066 0.050 0.083 0.2	0.099 0.075 0.124 0.3	0.16 0.12 0.20 0.4	0.33 0.25 0.41 0.9	0.65 0.49 0.82 1.7	1.3 1.0 1.6 3.5	1.9 1.5 2.4 5.2	3.2 2.5 4.1 8.6	9.7 7.4 12.2 25.9	32.4 24.6 40.7 86.3
O53 Wide angle lens	8	0.25 m	53° 38° 66° 2.2 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]		0.103 0.073 0.127 0.2	0.20 0.14 0.25 0.4	0.30 0.21 0.37 0.7	0.50 0.35 0.61 1.1	1.0 0.70 1.22 2.2	2.0 1.4 2.4 4.4	4.0 2.8 4.8 8.8	5.9 4.1 7.2 13.2	9.9 6.9 12.0 21.9	29.6 20.7 36.1 65.8	98.6 68.9 120.3 219.4
O80 Super wide angle lens	6	0.2 m	80° 54° 96° 3.0 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]	0.087 0.056 0.103 0.2	0.17 0.11 0.20 0.3	0.33 0.21 0.39 0.6	0.49 0.31 0.58 0.9	0.82 0.51 0.97 1.5	1.7 1.0 2.0 3.0	3.3 2.0 3.9 6.0	6.7 4.1 7.8 12.0	10.0 6.1 11.7 18.1	16.6 10.2 19.5 30.1	49.9 30.6 58.5 90.3	166.4 101.9 195.1 300.9

* Note: The accuracy of measurement can be outside of the specifications for distances below the defined minimum distance.

PI 640	gth		ment				Distan	ce to m	easure	ment o	bject [r	n]			
PI 640 G 7 640 x 480 px	Focal len [mm]	Angle	Minimum measurer distance*		0.1	0.2	0.3	0.5	1	2	4	6	10	30	100
O33	18.7	33°	0.2 m	HFOV [m]	0.068	0.13	0.19	0.31	0.60	1.20	2.38	3.57	5.9	17.8	59.3
Standard lens		25°		VFOV [m]	0.051	0.09	0.14	0.23	0.45	0.89	1.77	2.65	4.4	13.2	44.2
		41°		DFOV [m]	0.085	0.16	0.23	0.38	0.75	1.49	2.97	4.45	7.4	22.2	74.0
		0.91 mrad		IFOV [mm]	0.1	0.2	0.3	0.5	0.9	1.8	3.6	5.5	9.1	27.3	90.9
O15	41.5	15°	0,5 m	HFOV [m]				0.13	0.26	0.52	1.05	1.57	2.6	7.8	26.1
Tele lens		11°		VFOV [m]				0.10	0.20	0.39	0.79	1.18	2.0	5.9	19.6
		19°		DFOV [m]				0.17	0.33	0.66	1.31	1.96	3.3	9.8	32.7
		0,41 mrad		IFOV [mm]				0.2	0.4	0.8	1.6	2.5	4.1	12.3	41.0
O60	10.5	60°	0.2 m	HFOV [m]	0.128	0.25	0.36	0.59	1.17	2.32	4.63	6.94	11.6	34.6	115.4
Wide angle lens		45°		VFOV [m]	0.091	0.18	0.26	0.42	0.83	1.66	3.31	4.96	8.3	24.7	82.4
		75°		DFOV [m]	0.157	0.30	0.44	0.72	1.43	2.85	5.69	8.52	14.2	42.6	141.8
		1.62 mrad		IFOV [mm]	0.2	0.3	0.5	0.8	1.6	3.2	6.5	9.7	16.2	48.6	161.9
O90	7.7	90°	0.2 m	HFOV [m]	0.220	0.43	0.63	1.03	2.03	4.04	8.06	12.07	20.1	60.3	200.8
Super wide		64°		VFOV [m]	0.138	0.27	0.39	0.64	1.27	2.53	5.05	7.57	12.6	37.8	125.9
angle lens		111°		DFOV [m]	0.260	0.50	0.73	1.21	2.39	4.76	9.50	14.24	23.7	71.1	237.0
		2.21 mrad		IFOV [mm]	0.2	0.4	0.7	1.1	2.2	4.4	8.8	13.2	22.1	66.2	220.8

* Note: The accuracy of measurement can be outside of the specifications for distances below the defined minimum distance.

optris

າຂ	
<i>_</i>	 n
	-

Microscope optics	£	ent		Distance c	to mea bject [I	isurem n]	ent
PI 640 640 x 480 px	Focal leng [mm]	Minimum measurem distance*	Angle		0.08	0.09	0.1
F44 Microscope lens	44.2	0.08 m	12° 9° 15°	HFOV [m] VFOV [m] DFOV [m]	0.018 0.014 0.023	0.021 0.016 0.026	0.023 0.017 0.029
			0.36 mrad	IFOV [mm]	0.028	0.032	0.036

* Note: The accuracy of measurement can be outside of the specifications for distances below the defined minimum distance.

PI 1M / PI 08M /	gth	nent	l (Distance to measurement object [m]										
PI 05M¹⁾ 764 x 480 px	Focal len [mm]	Minimum measurei distance [*]	Angle		0.1	0.2	0.3	0.5	1	2	4	6	10	30	100
OF16	16	0.2 m	39° 25° 46°	HFOV [m] VFOV [m] DFOV [m]		0.14 0.09 0.17	0.21 0.14 0.25	0.36 0.23 0.42	0.72 0.45 0.85	1.43 0.90 1.69	2.87 1.80 3.38	4.30 2.70 5.08	7.2 4.5 8.5	21.5 13.5 25.4	71.6 45.0 84.6
OF25	25	0.5 m	0.94 mrad 26° 16° 30° 0.60 mrad	HFOV [mm] HFOV [m] VFOV [m] DFOV [m] IFOV [mm]	0.046 0.029 0.054 0.1	0.2 0.09 0.06 0.11 0.1	0.3 0.14 0.09 0.16 0.2	0.5 0.23 0.14 0.27 0.3	0.9 0.46 0.29 0.54 0.6	1.9 0.92 0.58 1.08 1.2	3.8 1.83 1.15 2.17 2.4	5.6 2.75 1.73 3.25 3.6	9.4 4.6 2.9 5.4 6.0	28.1 13.8 8.6 16.2 18.0	93.8 45.8 28.8 54.1 60.0
OF50	50	1.5 m	13° 8° 15° 0.30 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]				0.11 0.07 0.14 0.2	0.23 0.14 0.27 0.3	0.46 0.29 0.54 0.6	0.92 0.58 1.08 1.2	1.38 0.86 1.62 1.8	2.3 1.4 2.7 3.0	6.9 4.3 8.1 9.0	22.9 14.4 27.1 30.0
OF75	75	2.0 m	9° 5° 10° 0.20 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]					0.15 0.10 0.18 0.2	0.31 0.19 0.36 0.4	0.61 0.38 0.72 0.8	0.92 0.58 1.08 1.2	1.5 1.0 1.8 2.0	4.6 2.9 5.4 6.0	15.3 9.6 18.0 20.0

* Note: The accuracy of measurement can be outside of the specifications for distances below the defined minimum distance.

¹⁾ PI 05M and PI 08M is only available with OF25 optics

PI 1M / PI 08M /	gth	ment	Angle	Distance to measurement object [m]											
PI 05M ¹⁾ E 382 x 288 px E	Focal len [mm]	Minimum measurei distance*			0.1	0.2	0.3	0.5	1	2	4	6	10	30	100
OF16	16	0.2 m	20° 15° 25° 0.94 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]		0.07 0.05 0.09 0.2	0.11 0.08 0.13 0.3	0.18 0.14 0.22 0.5	0.36 0.27 0.45 0.9	0.72 0.54 0.90 1.9	1.43 1.08 1.79 3.8	2.15 1.62 2.69 5.6	3.6 2.7 4.5 9.4	10.7 8.1 13.5 28.1	35.8 27.0 44.9 93.8
OF25	25	0.5 m	13° 10° 16° 0.60 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]	0.023 0.017 0.029 0.1	0.05 0.03 0.06 0.1	0.07 0.05 0.09 0.2	0.11 0.09 0.14 0.3	0.23 0.17 0.29 0.6	0.46 0.35 0.57 1.2	0.92 0.69 1.15 2.4	1.38 1.04 1.72 3.6	2.3 1.7 2.9 6.0	6.9 5.2 8.6 18.0	22.9 17.3 28.7 60.0
OF50	50	1.5 m	7° 5° 8° 0.30 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]				0.06 0.04 0.07 0.2	0.11 0.09 0.14 0.3	0.23 0.17 0.29 0.6	0.46 0.35 0.57 1.2	0.69 0.52 0.86 1.8	1.1 0.9 1.4 3.0	3.4 2.6 4.3 9.0	11.5 8.6 14.4 30.0
OF75	75	2.0 m	4° 3° 5° 0.20 mrad	HFOV [m] VFOV [m] DFOV [m] IFOV [mm]					0.08 0.06 0.10 0.2	0.15 0.12 0.19 0.4	0.31 0.23 0.38 0.8	0.46 0.35 0.57 1.2	0.8 0.6 1.0 2.0	2.3 1.7 2.9 6.0	7.6 5.8 9.6 20.0

* Note: The accuracy of measurement can be outside of the specifications for distances below the defined minimum distance.

¹⁾ PI 05M and PI 08M is only available with OF25 optics

3 Mechanical Installation

3.1 Dimensions

The PI is equipped with two metric M4 thread holes on the bottom side (6 mm depth) and can be installed either directly via these threads or with help of the tripod mount (also on bottom side).



The tightening torque of the M4 screws for mounting the PI camera should be between 1 ... 1.5 Nm and must not exceed 2 Nm.

+optris



Figure 7: PI 160/ PI 400i/ PI 450i/ PI 450i G7, dimensions [mm]

Mechanical Installation



Figure 8: PI 200/ PI 230, dimensions [mm]



Figure 9: PI 640/ PI 640 G7, optics 29°/33° & 53°/60°, dimensions [mm]



Figure 10: PI 640/ PI 640 G7, optics 13°/15°, dimensions [mm]



Figure 11: PI 640/ PI 640 G7, optics 80°/90°, dimensions [mm]
Mechanical Installation



Figure 12: PI 640, microscope optics 10°/12°, dimensions [mm]



Figure 13: PI 05M/ PI 08M/ PI 1M, dimensions [mm]

3.2 Changing the lens

The PI camera is offered with several different lenses¹⁾ (lenses depending on the camera variant). To change a lens, rotate it as shown below. For the PI 05M, PI 08M and PI 1M, the protective tube must first be turned off (see **Figure 5**).



Figure 14: Change lens for PI 160/ 2xx/ 4xxi/ 640



Figure 15: Change lens for PI 05M/ 08M/ 1M



Figure 16: Inserting the lens

To get the best possible measurements when inserting the lens into the camera body, make sure that the label on the lens is screwed in at the same height as the label from the housing (see **Figure 16**).

¹⁾ An additionally purchased lens for the PI 05M/ 08M/ 1M camera comes with the corresponding protective tube

3.3 Fixing the focus of the lens (only for PI 05M/ 08M/ 1M)

With the PI 05M, PI 08M and PI 1M, it is possible to fix the focus of the lens. To do this, unscrew the protective tube of the camera (see **Figure 5**). There are three small holes on the lens. Take the three screws that are included and attach them to the three holes. The focus of the lens is now fixed. Alternatively, the two knurled screws supplied can also be used.



Figure 17: Lens for PI 05M/ 08M/ 1M



Figure 18: Fixing the focus for PI 05M/ 08M/ 1M

Mechanical Installation



Figure 19: Focusing screws for focus ring

+optris

3.4 Mounting accessories (optional)



Figure 20: Mounting base, stainless steel, adjustable in 2 axes [Part No.: ACPIMB]



Figure 21: Protective housing, stainless steel, Incl. Mounting base [Part No.: ACPIPH]

3.5 High temperature accessories

3.5.1 CoolingJacket

•



- The IR camera can be used at ambient temperature up to 50 °C (up to 70 °C with PI 450i/
- PI 450i G7). For higher temperatures (up to 180 °C) the CoolingJacket is provided.
- For detailed information see installation manual.

+optris



Figure 22: CoolingJacket – Dimensions

44



Figure 23: CoolingJacket for PI [Part No.: ACPIxxxCJ]

Figure 24: CoolingJacket with mounting bracket

3.5.2 CoolingJacket Advanced

• The CoolingJacket Advanced is available as Standard Version and Extended Version.



- The IR camera can be used at ambient temperature up to 50 °C (up to 70 °C with PI 450i/ PI 450i G7). For higher temperatures (up to 315 °C) the CoolingJacket Advanced is provided.
- For detailed information see installation manual.



Standard Version



Figure 25: CoolingJacket Advanced [Part No.: ACPIxxxCJAS], Standard Version - Dimensions

Extended Version



The Extended Version is provided for applications of the PI series with the PI Netbox and industrial PIF or the USB Server Gigabit and industrial PIF. Both PI Netbox and industrial PIF or USB Server Gigabit and industrial PIF can be integrated in the CoolingJacket.



Figure 26: Cooling Jacket Advanced (Extended Version) with PI Netbox and industrial PIF



Figure 27:Cooling Jacket Advanced (Extended Version) with USB-Server and industrial PIF



Figure 28: CoolingJacket Advanced [Part No.: ACPIxxxCJAE], Extended Version – Dimensions

Mechanical Installation

3.5.3 Laminar air purge for CoolingJacket

Laminar air purge for front mounting of the CoolingJacket Advanced (Standard and Extended). Two different versions are available: One for standard IR camera applications [Part-No.: ACCJAAPLS] and the other for line scanning applications [Part-No.: ACCJAAPLL].

Those two versions are fitting to all focusing units with production date $\ge 01/2018$. A protective window (67 x 3 mm) has to be ordered separately. If you like to mount the air purge on an older CJ, the focusing unit should be exchanged to the current version.





3.5.4 Outdoor protective housing

- The infrared camera PI and the USB server can also be used for outdoor applications by using the outdoor protective housing.
- The outdoor protective housing can be used for any PI camera (lenses up to 90° FOV)
- In addition, the industrial PIF can be installed as an accessory without housing
- Also available for CSlaser LT or CTlaser LT
- For detailed information see installation manual.



Figure 29: Outdoor protective housing for PI camera, USB server and industrial PIF

50

4 Electrical Installation

At the back side of the PI there are the two connector plugs. The left plug is for the USB cable. The right connector plug is only used for the process interface.



Figure 30: Backside of the camera with connectors

- 1 Plug for USB cable
- 2 Plug for PIF cable

4.1 Process interface

The process interface (electronics within cable as well as industrial interface) must be powered separately (5-24 VDC). Before switching on the power the PIF cable must be connected to the camera.

The PI is equipped with a process interface (cable with integrated electronics and terminal block), which can be programmed via the software as an Analog Input (AI) and Digital Input (DI) in order to control the camera or as an Analog Output (AO) in order to control the process. The signal level is always 0-10 V (DI = 24 V).



The process interface can be activated choosing the following options:

Analog Input (AI):	Emissivity, ambient temperature, reference temperature, uncommitted value, flag control, triggered recording, triggered snapshots, triggered linescanner, triggered event grabber, reset peak-/value-hold, switch temperature range
Analog Output (AO):	Main measure area, measure area, internal temperature, flag status, recording status, line scan status, alarm, frame sync, fail-safe, external communication
Digital Input (DI):	Flag control, triggered snapshots, triggered recording, triggered linescanner, triggered event grabber, reset peak-/value-hold, switch temperature range



Figure 31: Configuration Standard Process Interface (PIF)

The standard process interface provides the following inputs and outputs:

<u>Name</u>	<u>Description</u>	max range ^{1)/} status
AI	Analog input	0-10 V ²⁾
DI	Digital input (active-low = 00,6 V)	24 V
AO	Analog output Alarm output	0-10 V 0/ 10 V

¹⁾ Depending on supply voltage; for 0-10 V on the AO the PIF has to be powered with min. 12 V. ²⁾ The AI is designed for max. 24 V, the voltage level above 10 V is not interpreted

4.1.1 PIN allocation



ISB	PIF
VCC	1 INT
GND	2 SDA (I ² C)
	3 SCL (I ² C)
D -	4 DGND
D +	5 3.3 V (Out)

Figure 32: Rear side of the camera

Electrical Installation

If the process interface of the camera is directly connected to external hardware¹⁾ (without using the supplied PIF cable) an activation of the field "Support proprietary PIF cable" in the menu Tools/ Configuration/ Device (PIF) in the PIX Connect software is necessary.

Support proprietary PIF cable

Figure 33: Support proprietary PIF cable



Consider that the input of the PIF is not protected if there is a direct PIF connection! A voltage > 3 V on the INT pin will destroy the device!

 $^{\prime\prime}$ We recommend using only a switching contact between INT and DGND as external hardware (button, relay).

4.1.2 Industrial Process Interface (optional)

For use in industrial environment the industrial process interface with 500 V AC_{RMS} isolation voltage between PI and process is available (connection box with IP65, 5 m, 10 m or 20 m standard or high temperature cable for camera connection, terminal for process integration). [► Appendix F – Wiring diagrams PIF]



Pin assignment PIF cable (industrial process interface)

Figure 34: Connections of the industrial Process Interface

Electrical Installation

<u>Name</u>	<u>Description</u>	max range ¹⁾ / status
A IN 1 / 2	Analog input 1 and 2	0-10 V ²⁾
D IN 1	Digital input (active-low = 00,6 V)	24 V
AO1 / 2 / 3	Analog output 1, 2 and 3 Alarm output 1, 2 and 3	0/4-20 mA
DO1 / 2/ 3	Relay output 1, 2 and 3 3)	open/ closed (red LED on) / 030 V, 400 mA
FS	Fail-safe relay	open/ closed (green LED on)/ 030 V, 400 mA

The industrial process interface provides the following inputs and outputs:

¹⁾ depending on supply voltage; for 0-20 mA on the AO the PIF has to be powered with min. 5V < (1.5 + working resistance * 0.021) < 24 V; Example: $R_{Load} = 500 \text{ ohm} \rightarrow U_{min} = 1.5 + 500 * 0.021 = 12 V$, $R_{Load} = 100 \text{ ohm} \rightarrow U_{min} = 1.5 + 100 * 0.021 = 3.6 V \rightarrow min. 5 V$ ²⁾ the AI is designed for max. 24 V, the voltage level above 10 V is not interpreted ³⁾ active if AO1, 2 or 3 is/ are programmed as alarm output



The alarm output can be configured as a threshold between **0-4 mA** for **no alarm** and between **10-20 mA** as **alarm**. For values outside the respective range, the relay does not switch on the DO.

The process interface has an integrated **fail-safe mode**. This allows to control conditions like interruption of cables, shut-down of the software etc. and to give out these conditions as an alarm. The time constant of the fail-safe is 1.5 seconds.

Controlled conditions on camera and software	Standard Process interface ACPIPIF	Industrial Process interface ACPIPIFMACBxx
Interruption USB cable to camera	\checkmark	\checkmark
Interruption data cable camera - PIF	\checkmark	\checkmark
Interruption power supply PIF	\checkmark	\checkmark
Shut-down of PIX Connect software	\checkmark	\checkmark
Crash of PIX Connect software	-	\checkmark
Fail-Safe-Output	0 V at analog output (AO)	open contact (fail-safe relay)/ green LED off

58

4.2 Example for a Fail-Safe monitoring of the PI with a PLC



Figure 35: Fail-Safe monitoring states

Fail-Safe monitoring states

- [1] Breakdown of PIF power supply
- [2] Cable break of fail-safe cable
- [3] Interruption of cable PI-PIF

- [4] Malfunction of PI
- [5] Breakdown of PI power supply/ Interruption of USB cable
- [6] Malfunction of PIX Connect software



Figure 36: Fail-Safe monitoring states

Fail-Safe monitoring states

- [1] Breakdown of PIF power supply
- [2] Cable break of fail-safe cable
- [3] Short circuit of fail-safe cable
- [4] Interruption of cable PI-PIF

- [5] Malfunction of PI
- [6] Breakdown of PI power supply/ Interruption of USB cable
- [7] Malfunction of PIX Connect software

4.3 USB cable extension

The maximum USB cable length is 20 m. For greater distances between PI and computer or for stand-alone solutions the optional PI NetBox or the USB Server Gigabit is provided:



Figure 37: Ethernet direct communication with PI Netbox



Figure 38: Ethernet network communication with PI Netbox



Figure 39: Stand-Alone operation with PI Netbox



Figure 40: USB Server Gigabit

5 IRmobile App

The PI imagers have a direct connection to an Android smartphone or tablet. All you have to do is download the IRmobile app for free in the Google Play Store. This can also be done via the QR code. An IRmobile app connector is recommended for connection to the device (**Part-No.: ACPIIAC**).





With IRmobile you can monitor and analyze your infrared temperature measurement directly on a connected smartphone or tablet. All you need is an Optris infrared camera. This app runs on most Android (5 or higher) devices with a micro USB port or USB-C port that supports USB OTG (On The Go). The app is easy to use: After you have connected your camera to the micro USB port or USB-C port of your smartphone or tablet,

the app launches automatically. The calibration files are automatically downloaded from the internet. The device is powered by your smartphone. A hotspot indicates the hottest pixel in the image and a coldspot the coldest pixel in the image.

IRmobile app features:

- > Live infrared image with automatic hot-/ and coldspot search
- > Changing the color palette, scaling and temperature range
- > Change of temperature unit: Celsius or Fahrenheit
- Setting of temperature range scaling (Manual, Min/Max, 3 sigma)
- Creating a snapshot
- Integrated simulator

IRmobile supported for:

- > Optris IR cameras: PI and Xi series
- Optris pyrometers: Compact series, high performance series and video thermometers
- For Android 5 (or higher) devices with a micro USB port or USB C port that supports USB OTG (On The Go)



6 Software PIX Connect

Minimum system requirements:

- Windows 7, Windows 8, Windows 10
- USB interface
- Hard disc with at least 30 MByte of free space
- At least 128 MByte RAM
- CD-ROM drive



A detailed description is provided in the software manual on the software CD. See also **Help** menu in the PIX Connect software (**Help** \rightarrow **Documentation**).

6.1 Installation and initial start-up

- All drivers are booted via Windows OS automatically. A driver installation is not necessary.
- By default the program starts automatically in the installed language.
- 1. Insert the installation CD into the according drive on your computer. If the **autorun** option is activated the installation wizard will start automatically.
- 2. Otherwise start **setup.exe** from the CD-ROM. Follow the instructions of the wizard until the installation is finished.

The installation wizard places a launch icon on the desktop and in the start menu: Start\Programs\Optris GmbH\PIX Connect

- 3. To connect the camera to the PC, plug the USB cable to the camera first. Afterwards connect it with the PC (to disconnect the camera and the computer remove the USB cable from the computer first and then disconnect it from the camera).
- 4. Start the software.

At the initial start the software asks for the calibrations files which are available via internet or on the CD.

5. Install the calibration files at first start of the software.

66



Figure 41: Calibration data transfer

After the calibration files have been installed the live image from the camera is shown inside a window on your PC screen.

- 6. Choose the desired language in the menu **Tools** \rightarrow **Language**.
- 7. Adjust the focus of the image by turning the exterior lens ring at the camera.

6.2 Software window



Figure 42: Software window

Software PIX Connect

- 1 IR image from the camera
- 2 Temperature profile: Shows the temperatures along max. 2 lines at any size and position in the image.
- 3 Reference bar: Shows the scaling of temperature within the color palette.
- 4 Temperature of measure area: Analyses the temperature according to the selected shape, e.g. average temperature of the rectangle. The value is shown inside the IR image and the control displays.
- 5 Control displays: Displays all temperature values in the defined measure areas like Cold Spots, Hot Spots, temperature at cursor, internal temperature and chip temperature.

Alarm settings: Bar showing the defined temperature thresholds for low alarm value (blue arrow) and high alarm value (red arrow). The color of numbers within control displays changes to red (when temp. above the high alarm value) and to blue (when temp. below the low alarm value).

- 6 Temperature time diagram: Shows the temperature curves over time for selectable region of interest (ROI)
- 7 Histogram: Shows the statistic distribution of single temperature values.
- 8 Automatic / manual scaling of the palette (displayed temperature range): Man., </> (min, max), 1σ : 1 Sigma, 3σ : 3 Sigma, OPT: Palette optimization
- 9 Menu and Toolbar (Icons)
- **10** Icon enabling switching between color palettes
- 11 Status bar: Serial number, optic, temperature range, cursor position, device framerate/ display framerate, emissivity, ambient temperature, flag status

6.2.1 Basis features of the software PIX Connect

Extensive infrared camera software

- No restrictions in licensing
- Modern software with intuitive user interface
- Remote control of camera via software
- Display of multiple camera images in different windows
- Compatible with Windows 7, 8 and 10

High level of individualization for customer specific display

		Annual Annual Annual
206,3°C	1	204.310
	1-1)
	5	SA .
	10102201017-19142	
	Tanks (e.d. Dat)	

Windows

- Various language option including a translation tool
- Temperature display in °C or °F
- Different layout options for an individual setup (arrangement of windows, toolbar)
- Range of individual measurement parameter fitting for each application
- Adaption of thermal image (mirror, rotate)
- Individual start options (full screen, hidden, etc.)

70

Software PIX Connect



Video recording and snapshot function (IR or BI-SPECTRAL)

- Recording of video sequences and detailed frames for further analysis or documentation
- BI-SPECTRAL video analysis (IR and VIS) in order to highlight critical temperatures
- Adjustment of recording frequency to reduce data volume
- Display of snapshot history for immediate analysis

Extensive online and offline data analysis

207.5	retimeting Area 1	rinn		1.	ſ	_	S X
134.1	Area 2 Area 3		m		_		-
84,1		*			,	Am	γ.
34,1	0.5	1.0	1.5	2.0	2.5		•
<	12		2202	22429	> -		¢

- Analysis supported by measurement fields, hot and cold spot searching, image subtraction
- Real time temperature information within main window as digital or graphic display (line profile, temperature time diagram)
- Slow motion repeat of radiometric files and analysis without camera being connected
- Editing of sequences such as cutting and saving of individual images
- Various color palettes to highlight thermal contrasts

Automatic process control



- Individual setup of alarm levels depending on the process
- BI-SPECTRAL process monitoring (IR and VIS) for easy orientation at point of measurement
- Definition of visual or acoustic alarms and analog data output
- Analog and digital signal input (process parameter)
- External communication of software via COM-Ports and DLL
- Adjustment of thermal image via reference values

Temperature data analysis and documentation

					ALMONT .	10.00				1.01.02.04.0
W										
	A		4	0	6	6	4	-		100
	118.7.	192.5	110.4	110.4	0187	112.4	112.6	112.5	144	1125
27	118.6	112.4	135.9	111	112.4	112.5	118.9	110.4	118.1	112.5
5	118.0	138.0	115.6	118.8	178.8	112.5	118.6	118.5	118.7	108.9
10	125	1787	179.7	118.8	115.2	178.5	178.6	179.8	178-8	118.6
1	122.8	125	+23.5	+23.2	123.7	+23.4	124.2	+25.3	125.4	104.3
577	137.5	122.5	140.5	141.2	143.3	144.0	145.0	147.7	142.1	101.1
61.1	165.7	067.2	187.9	165.7	108.5	175.4	172.2	175.4	174.5	175.9
	187.7	188.2	180.1	180.7	101.2	102.5	185	182.41	108.7	108.0
11	205.4	208 Y	287.3	228.7	208.4	212.0	272.2	278.3	214.5	215.4
21	222.2	222.6	254.4	225.4	208.9	228.4	229.7	226.7	224.5	233.2
× .	256.8	227.0	235.4	229.1	242.5	241.4	241.9	240.1	243.5	244.4
2	244.5	244.6	244.8	245.4	245.5	245	245.4	248.7	248.7	247.2
2	248.4	244.4	245.7	205.8	207.2	287.6	267.6	248.2	208	208.2
41	247.2	247.2	247.6	1412	248.4	248.5	248.4	249.2	144.8	248.7
\$	218.8	248.9	248.6	248.4	218-4	248.5	248.4	249.2	248-8	248.9
81.	251.2	251.1	251.5	251.6	253.2	248.0	250.7	246.1	246.4	247.6
5.1	243.8	277.4	283.6	040.8	251.5	245.4	261.6	245.2	247	241.2
£	265	201.0	282	281.8	210.5	243.4	248.0	245.1	247	241.5
¥	243 5	248	242.8	241.8	241.4	241	240.8	220.8	745.7	218.1
21	233 P.	232.5	282.7	232.3	2217	201.2	220.9	230.3	228.4	229.8
- 15	223 al	532	011.4	121.1	221.5	203.4	2101	2464	244	2424
81.	2110	2137	209.2	200.7	208.4	208.2	207.2	206.5	207.2	206.7
811	2014	202.6	189.3	100 4	200	201.6	190	198.5	105.9	202.0
4	795.1	164.1	187.2	101.4	197.8	198.2	200.1	106.7	798.1	208 1
81	197.1	198.5	189.5	195.4	197.8	200	257.6	221.3	197.5	201.2
6 T	107.0	100.4	201.6	301	197.7	201.4	203.0	254.7	202.2	202.8
811	107.6	201.4	265.5	204.8	202.2	203.2	206.5	208.1	208.2	204.7
	202.5	202 T	205.6	208.2	208.2	2047	209 X	7971	214.1	212.9
£17	208.0	204.7	209.1	271.7	223.4	213.8	312	276.6	218.1	201.1
27.1	215	213.2	245.6	1914	114.4	333.4	2+7.6	221.8	114	317.4
21.1	148.0	113.0	247.6	716.1	111.4	100 1	118.4	225.6	221.2	176.6

- Triggered data collection
- Radiometric video sequences (*.ravi) radiometric snapshots (*.tiff)
- Text files including temp. information for analysis in Excel (*.csv, *.dat)
- Data with color information for standard programs such as Photoshop or Windows Media Player (*.wmv, *.tiff)
- Data transfer in real time to other software programs DLL or COM-Port interfaces
7 Basics of Infrared Thermometry

Depending on the temperature each object emits a certain amount of infrared radiation. A change in the temperature of the object is accompanied by a change in the intensity of the radiation.

Searching for new optical material William Herschel by chance found the infrared radiation in 1800.



Figure 43: William Herschel (1738-1822)

He blackened the peak of a sensitive mercury thermometer. This thermometer, a glass prism that led sun rays onto a table made his measuring arrangement. With this, he tested the heating of different colors of the spectrum. Slowly moving the peak of the blackened thermometer through the colors of the spectrum, he

noticed the increasing temperature from violet to red. The temperature rose even more in the area behind the red end of the spectrum. Finally he found the maximum temperature far behind the red area.

Nowadays this area is called "infrared wavelength area".



Figure 44: The electromagnetic spectrum and the area used for temperature measurement

For the measurement of "thermal radiation" infrared thermometry uses a wave-length ranging between 1 μ m and 20 μ m. The intensity of the emitted radiation depends on the material. This material contingent constant is described with the help of the emissivity which is a known value for most materials (**>8 Emissivity**).

Infrared thermometers are optoelectronic sensors. They calculate the surface temperature on the basis of the emitted infrared radiation from an object. The most important feature of infrared thermometers is that they enable the user to measure objects contactless. Consequently, these products help to measure the temperature of inaccessible or moving objects without difficulties.

Basics of Infrared Thermometry



Figure 45: Main principle of non-contact thermometry

Infrared thermometers basically consist of the following components:

- Lens
- Spectral filter
- Detector
- Electronics (amplifier/ linearization/ signal processing)

The specifications of the lens decisively determine the optical path of the infrared thermometer, which is characterized by the ratio Distance to Spot size. The spectral filter selects the wavelength range, which is relevant for the temperature measurement. The detector in cooperation with the processing electronics transforms the emitted infrared radiation into electrical signals.

The advantages of non-contact thermometry are clear - it supports:

- temperature measurements of moving or overheated objects and of objects in hazardous surroundings
- very fast response and exposure times
- measurement without inter-reaction, no influence on the
- measuring object
- non-destructive measurement
- long lasting measurement, no mechanical wear



Figure 46: Non-contact thermometry

Application field:





Monitoring of electronic cabinets

R&D of electronics



R&D of electronic parts



Process control extruding plastic parts



Process control manufacturing solar modules



Process control at calendering



R&D of mechanical parts



Monitoring of cables

8 Emissivity

8.1 Definition

The intensity of infrared radiation, which is emitted by each body, depends on the temperature as well as on the radiation features of the surface material of the measuring object. The emissivity (ϵ – Epsilon) is used as a material constant factor to describe the ability of the body to emit infrared energy. It can range between 0 and 100 %. A "blackbody" is the ideal radiation source with an emissivity of 1.0 whereas a mirror shows an emissivity of 0.1.



Figure 47: Composition of IR radiation



ε + ρ+ τ = 1



Figure 48: Spectral emissivity of several materials: 1 Enamel, 2 Plaster, 3 Concrete, 4 Chamotte

If the emissivity chosen is too high, the infrared thermometer may display a temperature value which is much lower than the real temperature – assuming the measuring object is warmer than its surroundings. A low emissivity (reflective surfaces) carries the risk of inaccurate measuring results by interfering infrared radiation emitted by background objects (flames, heating systems, chamottes). To minimize measuring errors in such cases, the handling should be performed very carefully and the unit should be protected against reflecting radiation sources.

Emissivity

8.2 Determination of unknown emissivity

- ► First determine the actual temperature of the measuring object with a thermocouple or contact sensor. Second, measure the temperature with the infrared thermometer and modify the emissivity until the displayed result corresponds to the actual temperature.
- If you monitor temperatures of up to 380 °C you may place a special plastic sticker (emissivity dots Part No.: ACLSED) onto the measuring object, which covers it completely.



Figure 49: Plastic sticker at metal surface

Set the emissivity to 0.95 and take the temperature of the sticker. Afterwards, determine the temperature of the adjacent area on the measuring object and adjust the emissivity according to the value of the temperature of the sticker.

Cove a part of the surface of the measuring object with a black, flat paint with an emissivity of 0.98. Adjust the emissivity of your infrared thermometer to 0.98 and take the temperature of the colored surface. Afterwards, determine the temperature of a directly adjacent area and modify the emissivity until the measured value corresponds to the temperature of the colored surface.





Figure 50: Shiny metal surface left and blackened metal surface right

CAUTION: On all three methods the object temperature must be different from ambient temperature.

82

8.3 Characteristic emissivity

In case none of the methods mentioned above help to determine the emissivity you may use the emissivity table ► Appendix A and Appendix B. These are average values, only. The actual emissivity of a material depends on the following factors:

- temperature
- measuring angle
- geometry of the surface
- thickness of the material
- constitution of the surface (polished, oxidized, rough, sandblast)
- spectral range of the measurement
- transmissivity (e.g. with thin films)

Fixed radiometric values		
Emissivity:	1,000	*
Transmissivity: (IR-window compensation)	1,000	* *
Ambient temperature:	23,0	×

Figure 51: Adjustment of the emissivity in the software PIX Connect (menu Tools/ Configuration/ Device)

Appendix A – Table of emissivity for metals

	Material		typical Er	missivity	
Spec	tral response	1.0 µm	1.6 µm	5.1 µm	8-14 µm
Aluminium	non oxidized	0.1-0.2	0.02-0.2	0.02-0.2	0.02-0.1
	polished	0.1-0.2	0.02-0.1	0.02-0.1	0.02-0.1
	roughened	0.2-0.8	0.2-0.6	0.1-0.4	0.1-0.3
	oxidized	0.4	0.4	0.2-0.4	0.2-0.4
Brass	polished	0.35	0.01-0.05	0.01-0.05	0.01-0.05
	roughened	0.65	0.4	0.3	0.3
	oxidized	0.6	0.6	0.5	0.5
Copper	polished	0.05	0.03	0.03	0.03
	roughened	0.05-0.2	0.05-0.2	0.05-0.15	0.05-0.1
	oxidized	0.2-0.8	0.2-0.9	0.5-0.8	0.4-0.8
Chrome		0.4	0.4	0.03-0.3	0.02-0.2
Gold		0.3	0.01-0.1	0.01-0.1	0.01-0.1
Haynes	alloy	0.5-0.9	0.6-0.9	0.3-0.8	0.3-0.8
Inconel	electro polished	0.2-0.5	0.25	0.15	0.15
	sandblast	0.3-0.4	0.3-0.6	0.3-0.6	0.3-0.6
	oxidized	0.4-0.9	0.6-0.9	0.6-0.9	0.7-0.95
Iron	non oxidized	0.35	0.1-0.3	0.05-0.25	0.05-0.2
	rusted		0.6-0.9	0.5-0.8	0.5-0.7
	oxidized	0.7-0.9	0.5-0.9	0.6-0.9	0.5-0.9
	forged, blunt	0.9	0.9	0.9	0.9
	molten	0.35	0.4-0.6		boenew.
Iron, casted	non oxidized	0.35	0.3	0.25	0.2
	oxidized	0.9	0.7-0.9	0.65-0.95	0.6-0.95

Appendix A – Table of emissivity for metals

	Material		typical E	missivity	
Spect	tral response	1.0 µm	1.6 µm	5.1 µm	8-14 µm
Lead	polished roughened oxidized	0.35 0.65	0.05-0.2 0.6 0.3-0.7	0.05-0.2 0.4 0.2-0.7	0.05-0.1 0.4 0.2-0.6
Magnesium	202	0.3-0.8	0.05-0.3	0.03-0.15	0.02-0.1
Mercury			0.05-0.15	0.05-0.15	0.05-0.15
Molybdenum	non oxidized oxidized	0.25-0.35 0.5-0.9	0.1-0.3 0.4-0.9	0.1-0.15 0.3-0.7	0.1 0.2-0.6
Monel (Ni-Cu)		0.3	0.2-0.6	0.1-0.5	0.1-0.14
Nickel	electrolytic oxidized	0.2-0.4 0.8-0.9	0.1-0.3 0.4-0.7	0.1-0.15 0.3-0.6	0.05-0.15
Platinum	black	8	0.95	0.9	0.9
Silver		0.04	0.02	0.02	0.02
Steel	polished plate rustless heavy plate cold-rolled oxidized	0.35 0.35 0.8-0.9 0.8-0.9	0.25 0.2-0.9 0.8-0.9 0.8-0.9	0.1 0.15-0.8 0.5-0.7 0.8-0.9 0.7-0.9	0.1 0.1-0.8 0.4-0.6 0.7-0.9 0.7-0.9
Tin	non oxidized	0.25	0.1-0.3	0.05	0.05
Titanium	polished oxidized	0.5-0.75	0.3-0.5 0.6-0.8	0.1-0.3 0.5-0.7	0.05-0.2
Wolfram	polished	0.35-0.4	0.1-0.3	0.05-0.25	0.03-0.1
Zinc	polished oxidized	0.5	0.05	0.03	0.02 0.1

Appendix B – Table of emissivity for non-metals

N	laterial		typical Er	missivity	
Spectr	al response	1.0 µm	2.2 µm	5.1 µm	8-14 µm
Asbestos		0.9	0.8	0.9	0.95
Asphalt		22		0.95	0.95
Basalt		3		0.7	0.7
Carbon	non oxidized		0.8-0.9	0.8-0.9	0.8-0.9
	graphite		0.8-0.9	0.7-0.9	0.7-0.8
Carborundum			0.95	0.9	0.9
Ceramic		0.4	0.8-0.95	0.8-0.95	0.95
Concrete		0.65	0.9	0.9	0.95
Glass	plate		0.2	0.98	0.85
	melt		0.4-0.9	0.9	
Grit		3		0.95	0.95
Gypsum				0.4-0.97	0.8-0.95
lce		14		7.0	0.98
Limestone				0.4-0.98	0.98
Paint	non alkaline				0.9-0.95
Paper	any color			0.95	0.95
Plastic >50 µm	non transparent	(e		0.95	0.95
Rubber	116.7.114.0	2		0.9	0.95
Sand		3		0.9	0.9
Snow					0.9
Soil		(A		7	0.9-0.98
Textiles				0.95	0.95
Water					0.93
Wood	natural	20		0.9-0.95	0.9-0.95

Appendix C – Quick start for serial communication

Introduction

One special feature of the PIX Connect software contains the possibility to communicate via a serial COM-Port interface. This can be a physical COM-Port or a virtual COM-Port (VCP). It must be available on the computer where the PIX Connect software is installed.

Setup of the interface

- 1. Open the Configurations dialog and enter the tab "External Communication" to enable the software for the serial communication.
- 2. Select the mode "COM-Port" and choose the appropriate port.
- 3. Select the baud rate that matches the baud rate of the other communication device. The other interface parameters are 8 data bits, no parity and one stop bit (8N1).

These parameters are used in many other communication devices too. The other station must support 8 bit data.

4. Connect the computer with the communication device. If this is a computer too, use a null modem cable.

Command list



The command list is provided on the software CD and in the PIX Connect software ($\texttt{Help} \rightarrow \texttt{SDK}$). Every command must expire with CR/LF (0x0D, 0x0A).

Appendix D – Interprocess Communication (IPC)

The description of the initialization procedure as well as the necessary command list is provided on the CD and in the PIX Connect software ($\texttt{Help} \rightarrow \texttt{SDK}$).

2 SDK packages are available (can be found on the included software CD):

- 1. Connect SDK: requires the PIX Connect software
- 2. Direct SDK: no PIX Connect software required, supports Linux and Windows

The communication to the process imager device is handled by the PIX Connect software (Imager.exe) only. A dynamic link library (ImagerIPC2.dll) provides the interprocess communication (IPC) for other attached processes. The DLL can be dynamically linked into the secondary application. Or it can be done static by a lib file too. Both Imager.exe and ImagerIPC2.dll are designed for Windows Vista/ 7/ 8/ 10 only. The application must support call-back functions and polling mode.

The ImagerIPC2.dll will export a bunch of functions that are responsible for initiating the communication, retrieving data and setting some control parameters.

The main difference to the former Version 1 (ImagerIPC.dll) is the support of more than one Optris PI via multiple instances of Optris PIX Connect.

Appendix E – PIX Connect Resource Translator



A detailed tutorial is provided on the CD.

PIX Connect is a .Net Application. Therefore it is ready for localization. Localization as a Microsoft idiom means a complete adaption of resources to a given culture. Learn more about the internationalization topics consult Microsoft's developer documentation on

http://msdn.microsoft.com/en-us/goglobal/bb688096.aspx.

If desired the localization process can be illustrated in detail. Also the resizing of buttons or other visible resources and the support of right-to-left-languages are supported. Experts who have the appropriate tools should handle it. Nevertheless we have developed the small tool "Resource Translator" to make the translation of the resources of the PIX Connect application possible for everybody.

This tool helps to translate any visible text within the PIX Connect application.

Appendix F – Wiring diagrams PIF

Analog Output:

The maximum load impedance is 500 Ohm.

The analog output can be used as a digital output too. The current value for "no alarm" and "alarm on" is set within the software.

+optris

Digital Input:



Figure 52: Digital input

The digital input can be activated with a button to the PI GND-Pin or with a low level CMOS/TTL signal: Low level 0...0.6 V; High level 2...24 V

Example Button:



Figure 53: Button

92

Appendix F – Wiring diagrams PIF

Analog input (usable voltage range: 0 ... 10 V):



Figure 54: Analog input

Relay output at industrial PIF [Part No.: ACPIPIFMACBxx]

The analog output must be set to "Alarm". The range for AO1-AO3 can be set in the software (no alarm: 0-4 mA/ alarm: 10-20 mA).

REL1-3 (DO1-DO3): U_{max} = 30 VDC

 $I_{max} = 400 \text{ mA}$



Figure 55: Relay output at industrial PIF

EG-Konformitätserklärung EU Declaration of Conformity	
Wir /We Optris Gm Ferdinand Buiss D-13127 B	bH on Str. 14
erklåren in alleiniger Verantwortung, dass declare on our own responsibility that	
die Produktserie the product grou	optris PI o optris PI
den Anforderungen der EMV-Richtlinie 2014/30/EU ur entspricht meets the provisions of the EMC Directive 2014/30/EI	Id der Nederspannungsrichtlinie 2014/35/EU J and the Low Voltage Directive 2014/35/EU.
Angewandte harmonisierte Normen: Applied harmonized standards:	
EMV Anforderungen / EMC General Requirements: EN 61326-1:2013 (Grundlegende Prüfanforderungen EN 61326-2-3:2013	/ Basic requirements)
Gerätesicherheit von Messgeräten / Safety of measur EN 61010-1:2010 EN 60825-1:2014 (Lasersicherheit / Laser safety)	sment devices:
Dieses Produkt erfult die Vorschriften der Richtlinie 2. Parlaments und des Rates vom 8. Juni 2011 zur Besc gefährlicher Stöffe in Elektro- und Elektronkgeräten. This product is in conformity with Directive 2011/65/EI the Council of 8 June 2011 on the restriction of the us electrical and electronic equipment.	M1/65/EU (RoHS) des Europäischen Inarkung der Verwendung bestimmter J (RoHS) of the European Parliament and of e of certain hazardous substances in
Dodis 04.400045	
Ort, Datum / place, date	Dr. Ulrich Kienitz Geschäftsführer / General Manager

Appendix G – Declaration of Conformity

optris PI-MA-E2019-06-A