





















E150282
LISTED
4F67

Model OT-2
Cat. #2121.03

Outlet/ GFCI Tester (120V - 3 Wire US)

GFCI TEST OPERATION for 110 - 125 VAC GFCI Receptacles only.

1. ☐ Always test first on a known live circuit before use to ensure the tester is operating properly.
2. ☐ Make sure GFCI receptacle is installed in accordance with the manufacturers and code requirements.
3. ☐ Check for correct wiring of receptacle and all remotely connected receptacles on the branch circuit by plugging tester into each receptacle.
4. ☐ Press the TEST button on the installed GFCI receptacle. The GFCI should trip. If it does not trip do not use the outlet circuit, consult an electrician. If it does trip, press the RESET button on the GFCI receptacle and plug in the tester.
5. ☐ Press the test button on the tester for a minimum of 6 seconds. The indicator lights on the tester will shut off when the GFCI trips.
6. ☐ If tester does not trip the GFCI, either the GFCI is operable but the wiring is wrong, or the wiring is correct but the GFCI is inoperable. Consult an electrician to determine the problem.

INDICATOR	FAULT	REASON FOR WIRING FAULT
  	Open Ground	Ground wire not connected
  	Open Neutral	Neutral wire not connected
  	Open Hot	Hot wire not connected
  	Hot/Ground Reverse	Hot and ground wires reversed
  	Hot/Neutral Reverse	Hot and neutral wires reversed
  	Correct	Receptacle is wired correctly

 CLEAR

 RED

 ORANGE

WARNING!

- ☐ All corrective work must be made by qualified personnel.
- ☐ Equipment on the circuit being tested should be unplugged to help avoid erroneous readings.
- ☐ This tester is not a comprehensive diagnostic instrument but a simple instrument to detect nearly all probable common improper wiring conditions.
- ☐ This tester will not indicate quality of ground.
- ☐ This tester will not detect 2 hot wires in circuit.
- ☐ This tester will not detect a combination of defects.
- ☐ This tester will not indicate reversal of grounded and grounding conductors.
- ☐ Not for use on 2 wire (non grounded) circuits. GFCI test may be faulty on 2 wire systems.

Chauvin Arnoux®, Inc. d/b/a AEMC® Instruments

Foxborough, MA 02035 USA

(508) 698-2115 • (800) 343-1391

www.aemc.com

MADE IN TAIWAN