



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com





Kanomax USA, Inc. 219 Route 206 PO Box 372 Andover, New Jersey 07821 USA (800) 247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

Model 6812[™] VOLUME FLOW ANEMOMETER

User Manual

www.kanomax-usa.com

Copyright © 2008, Kanomax USA, Inc

6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 28 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 1 of 28





Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

CALIBRATION

To maintain your instrument in top working order, we recommend that you send it back to us for calibration each year, beginning one year after purchase.

Our calibration services include ensuring the instrument performs within its accuracy tolerance, making any necessary adjustments, and inspecting all aspects of the instrument's functionality so that you'll have another year of dependable service. Calibration also includes a complimentary firmware upgrade so that you know you'll have the latest advances in accuracy and reliability in your instrument.

NIST-Traceable multi-point calibration is also available from the factory. We can offer precise calibration tailored to your specific measurement needs using our state-of-the-art facilities and calibration equipment.

Please contact us or visit our website for the latest information on calibrating your instrument.

INTRODUCTION

Congratulations on your purchase of a 6812 Digital Anemometer with Volume Calculation! You now own one of the most accurate, reliable, and highly regarded airflow measurement instruments available today.

Kanomax's model 6812 digital anemometer is a versatile instrument for measuring air velocity in various applications such as HVAC, aerospace development, industrial process airflow, and fluids research.

Air Volume flow is automatically calculated in units of either cubic feet per minute (ft^3/min) or cubic meters per hour (m^3/hr).

The rugged yet precise probes can be used for airstreams that have a wide range of humidity, temperature and contaminants without compromising accuracy.

Features include choice of probe diameters, custom cable lengths, service temperatures up to 212° F (100°C) at the probe, high reliability, and long life.

6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 2 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 27 of 28





Duct Dimension Reference Table

The following reference table can be used to record which particular duct dimensions are stored under which Duct Number in your 6812 Anemometer.

Duct #	Length	Height	Diameter	Description
Duct 0				
Duct 1				
Duct 2				
Duct 3				
Duct 4				
Duct 5				
Duct 6				
Duct 7				
Duct 8				
Duct 9				



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

Warranty

This product is fully warranted against defective materials and/or workmanship for a period of one year after purchase, provided it was not improperly used. For your protection, please use this product as soon as possible. If returned, it must be securely wrapped, sent prepaid and insured to:

> Kanomax USA Inc. 219 Route 206 PO Box 372 Andover, New Jersey 07821 USA

Please include a note with name, address, telephone number and description of the problem. Although we provide assistance on Kanomax products both personally and through our literature, it is still the total responsibility of the customer to determine the suitability of the product for use in their application.

This manual is provided by Kanomax without any kind of warranty. Precautions have been taken in accurately preparing this manual; however, we neither assume responsibility for any omissions or errors that may appear nor assume liability for any damages that result from the use of the products in accordance with the information contained in the manual.

Kanomax USA, Inc www.kanomax-usa.com Page 26 of 28

Phone: 1-800-247-8887

info@kanomax-usa.com

(973) 786-7586

Fax:

6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 3 of 28



SECTION 1 - SPECIFICATIONS

Ranges:

Probe AP275:	40 to 7800 ft/min(feet per minute)0.2 to 40.00 m/sec(meters per second)		
Probe AP100:	60 to 6800 ft/min 0.3 to 35.00 m/sec		
Calculated Air Volu	me Flow: 0.0 to 9999 ft^3/min (cubic feet per minute) 0.0 to 9999 m^3/hr (cubic meters per hour)		
Accuracy:	±1.0% of reading ±1 digit		
Resolution:	1 ft/min or 0.01 m/sec $0.1 \text{ ft}^3/\text{min}$ or $0.1 \text{ m}^3/\text{hr}$		
Operating Temper Instrument: Probes:	ature: 32° to 125°F (0° to 50°C) -4° to 212°F (-20° to 100°C)		
Power Supply:	3 AA alkaline batteries		
Battery Life:	Approx. 150 hours, without backlight		
Battery check:	Automatic low battery display		
Display:	0.5" LCD, 4 digits, with LED backlight		



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

Below are examples of the formatted output data for Kanomax's 681x Instruments (units may be different depending on the units selected on the LCD display):

Model 6812 displaying i Model 6812 displaying i	n Air Velocity Mode: n Volume Flow Mode:	Air,47,FPM <cr> Air,251,CFM <cr></cr></cr>
Model 6812:	Air,47,FPM,Temp,56.7,C	CR>
Model 6813:	Air,47,FPM,Temp,56.7,C	C,RH,40.5,% <cr></cr>

Exporting and Graphing Data

Exporting serial port instrument data from the Kanomax Instrument to a spreadsheet application such as Microsoft Excel or OpenOffice Calc allows the data to graphed or recorded.

The simplest way to export the instrument data is to use a terminal emulator program, like Windows HyperTerminal, and either capture the serial data/text to a file (menu selection) or to manually highlight, copy, and then paste the instrument data into an editor such as Windows Notepad.

Once you have the instrument data in a file, save the file as a .CSV type (e.g., InstrumentData.csv).

Open the file in a spreadsheet application such as Microsoft Excel or OpenOffice Calc. A graph of the data as shown below can now be generated.

Kanomax USA, Inc www.kanomax-usa.com Page 4 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc.



You will now receive data from your instrument. The graphic below shows the serial port output data from Windows HyperTerminal when connected to a Kanomax 6812 Instrument.

na Kanomax 6812 - Hyp 🕷	erTerminal					_	
<u>File Edit View Call Ir</u>	ransfer <u>H</u> elp						
02 20	8						
Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM							
H1r,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM Air,0,FPM	1						
Connected 0:00:28	Auto detect	9600 8-N-1	SCROLL	CAPS	NUM	Capture	P //.

Serial Port Settings

Bits per Second (Baud)	9600
Data bit	8
Parity	None
Stop bits	1
Flow Control	None

Serial Port Protocol

Data Output Interval	One Second
Data Format	Comma-Separated Values (CSV)
Measurement Units	Same as Units shown on LCD Display



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

Options Available:

- Protective Boot and Splash-Proof Seal for the Instrument
- USB Communications
- RS232 Communications
- Analog 0-5 Volt Output
- Additional Probes, AP275 or AP100
- Extra extension and/or flexible rods
- Custom cable lengths

Included:

- (1) 6812 Instrument
- (1) Vane-type probe head, choice of AP100 or AP275
- (3) Rigid extension rods with handle grip
- (1) Flexible extension rod
- (1) Probe connection cable, 5 ft.
- (3) Size AA 1.5V alkaline batteries
- (1) Hard-shell carrying case with foam liner
- (1) 6812 operation manual

Dimensions

INSTRUMENT

6.26 Inch 1.32 Inch 160 mm 34 mm 3.07 Inch Image: Constraint of the second second

6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 24 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc.

Kanomax USA, Inc www.kanomax-usa.com Page 5 of 28





Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

Click on File \rightarrow Properties. You will see the window shown below. Click on the Settings tab and then click on ASCII Setup... as shown below.

AP275 PROBE	_ ∅2.75 INCH 70 MM	MOUNTING BO 3/8-16 UNC TAF .750 INCH DEEF		
		ELECTRICAL CONNECTOR	O O	
	.875 INCH 22 MM		•	
4.9 INCH 124 MM			1.7±.010 INCH 43 MM	-



Kanomax 6812 Properties ? × Connect To Settings - Function, arrow, and ctrl keys act as • Ierminal keys C Windows keys - Backspace key sends ● Ctrl+H ● Del ● Ctrl+H, Space, Ctrl+H Emulation: Auto detect • Telnet terminal ID: ANSI Backscroll buffer lines: 500 ÷ Play sound when connecting or disconnecting Input Translation.. ASCII Setup. OK Cancel

Make sure that "Append line feeds to incoming line ends" is CHECKED as shown below. Click OK.

ASCII Setup				
C ASCII Sending				
Send line ends with line feeds				
Echo typed characters locally				
Line delay: 0 milliseconds.				
Character delay: 0 milliseconds.				
ASCII Receiving				
Append line feeds to incoming line ends				
Force incoming data to 7-bit ASCII				
Wrap lines that exceed terminal width				
OK Cancel				

6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 6 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 23 of 28



On the next window, next to "Connect using," select the COM port you that you are using with your instrument. Click OK.

Kanoma	k 6812	
Enter details for	the phone number th	nat you want to dial:
<u>C</u> ountry/region:	United States of Ar	merica (1) 📃 💌
Ar <u>e</u> a code:	603	
Phone number:		
Connect using:	COM2	

In the next window, select the port settings as shown below and click OK. (The Serial Port settings are also listed at the end of this section).

COM3 Properties	?>
Port Settings	
Bits per second:	9600 🗸
Data bits:	8
Parity:	None
Stop bits:	1
Flow control:	None
	Restore Defaults
0	K Cancel Apply

Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

SECTION 2 – SWITCH FUNCTIONS

	3 ка	NOA	лах
	ANEMO MODE VOLUM ANEMO	MAST L 681 E FLO METE	ER 2 W ER
F	PM IPS		MAX MIN
6			HOLD RESET
e		UME OW TINGS	SET
C	Ö (*	ure ov	\bigcirc



Pressing the ON/OFF key switches the instrument ON. Hold down the key for 2 seconds to switch the unit OFF. The unit will automatically power off after 30 minutes without any key presses. To disable auto power-off, hold down the power button during turn-on. The unit will flash

ADFF, which means that the auto power-off has been disabled. The auto power-off is re-enabled each time the instrument is turned on.

. 11/.
No.
UT I

Press the BACKLIGHT key to turn the LCD backlight on for 30 seconds. To turn the backlight on permanently, hold the backlight key down for 3 seconds. The LCD will flash. The backlight is now switched on permanently. To switch the backlight off, press the backlight key again.



Press the FPM/MPS key to switch the measurement units from FPM (feet per minute, 1 FPM resolution) to MPS (meters per second, 0.01 MPS resolution). Either **FPM** or **MPS** will be displayed on the LCD.



Press the SAMPLE RATE key to change the measurement averaging rate ("sample rate") of the unit:

6812[™] User Manual, PN 10282 Rev 1.9. 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 7 of 28

6812[™] User Manual, PN 10282 Rev 1.9. 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 22 of 28



PO Box 372 Fax: (973) 786-7586 Andover, NJ 07821 USA info@kanomax-usa.com
--

- An average value of airspeed measurements during the preceding 2 seconds is displayed.
- 45EC An average value of airspeed measurements during the preceding 4 seconds is displayed.
- **B5E***C* An average value of airspeed measurements during the preceding 8 seconds is displayed.
- 15 5 An average value of airspeed measurements during the preceding 16 seconds is displayed.
- MAX MIN

Press the MAX/MIN key to record and display the maximum airspeed or volume flow reading. The maximum reading display will alternate with the letter "H" displayed with the sample rate. Press

the MAX/MIN key again to record and hold the minimum airspeed reading. The minimum airspeed reading display will alternate with the letter "L" displayed with the sample rate. For example:

1055 alternating with H = B signifies that 1065 is the highest reading since the MAX/MIN key was pressed, and the sample rate is set to 8 seconds.

B2 alternating with L 15 signifies that 82 is the lowest reading since the MAX/MIN key was pressed, and the sample rate is set to 16 seconds.

To exit MAX/MIN mode, press the SAMPLE RATE key.



Press the HOLD/RESET key to freeze the current reading on the display. **HOLD** is displayed on the LCD and the reading is held.

Press the HOLD/RESET key a second time to clear this mode and return the unit to normal operation.



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

APPENDIX F – VIEWING AND CAPTURING DATA (IF EQUIPPED WITH EITHER USB OR RS232 OUTPUTS)

There are many ways to capture the serial port data from the Kanomax Instrument. The simplest method is to use a terminal emulator program.

Using a terminal emulator allows the serial COM port to be opened, with the above port settings, and real-time data to be viewed from the instrument. One such terminal emulator program is Windows HyperTerminal.

To launch Windows HyperTerminal, go to: START \rightarrow All Programs \rightarrow Accessories \rightarrow Communications \rightarrow HyperTerminal

Enter a name for the Connection, such as "Kanomax 6812" and choose an icon.



Click OK.

6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 8 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 21 of 28



APPENDIX E – RS232 COMMUNICATIONS (IF EQUIPPED)

If the instrument is equipped with the RS232 Communications option, there will be a three pin male connector on the bottom of the instrument. Also, an RS232 cable will be included with the instrument. This cable will have a three pin female connector on one end and a DB9 Female connector on the other end.

RS232 Data Output – Instructions for Use

- STEP 1: Connect the RS232 cable (included) to the female connector on the bottom of your instrument. Connect the other end to an RS232 port on your computer.
- STEP 3: Turn the Instrument ON.
- STEP 4: Verify that the Instrument has been set up as a RS232 Serial Port with a unique COM port number. (You only need to do this once). For Windows users, open the Windows Device Manager (found in Control Panel) and verify that a serial port exists.

You are now ready to capture the data being measured by your instrument.

Please refer to **Appendix F – Viewing and Capturing Data** for further instructions.

219 Route 206 PO Box 372 Andover, NJ 07821 USA

Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

Press the HOLD/RESET key while in MIN/MAX mode to display BOTH the minimum and maximum airspeed reading since the MAX/MIN key was pressed. Once the HOLD/RESET key is pressed while in MAX/MIN mode, new airspeed readings are no longer recorded. To return to MAX/MIN mode, press the HOLD/RESET key again.



Press the "VOLUME FLOW" key to enter Volume Flow mode. Press it again to exit Volume Flow mode and return to Airspeed mode.



While in Volume Flow mode, or Airspeed mode, press "ADJ" to select which Duct setup you'd like to use when in Volume Flow mode. There

are 10 Duct setups to choose from and they are shown as duc 0 through duc 9.

While in Volume Duct Entry mode, press this key to advance to begin editing a setting, or to adjust a setting, like changing units from *l* nch (inches) to *Ent* (centimeters), or incrementing a duct size by 1 unit.



While in Volume Flow mode or Airspeed mode, press "SET" to enter Volume Duct Entry mode. This allows you to edit the Duct settings for the currently selected Duct setup.

While in Volume Duct Entry mode, press this key to accept a value. For

example, pressing "ADJ" will toggle the units setting between i nch and

Ent. Pressing "SET" will accept the currently displayed value and advance you to the next menu.



Press the SAMPLE RATE key while adjusting duct sizes to move one digit to the left. This will allow you to go back and adjust the digit you have just set.



Press the HOLD/RESET key at any time while adjusting duct sizes to exit the duct size adjustment. Any changes you have made to duct sizes **are not saved**.

Kanomax USA, Inc www.kanomax-usa.com Page 20 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 9 of 28



Duct Size Entry example:

Andover, NJ 07821 USA

The following example shows how to enter the dimensions of a 12 inch x 12 inch rectangular duct and save this duct at Duct # 4 in memory.

- 1. Turn the 6812 on.
- 2. Once turned on, press the "ADJ" key. Continue pressing and releasing until duc 4 is displayed. This now selects Duct setup 4.
- 3. Press the "SET" key to enter into Volume Duct Entry mode. The display shows UOL stating that we're in Volume Duct Entry mode,

then shows the Duct setup selection of duc 4, and then stops at

ll n l k. Press the "ADJ" key to enter the Units menu.

- 4. Press and release the "ADJ" key to toggle between *inch* and *EnE*. This determines whether the units will be in Inches or Centimeters.
- 5. Once i nch has been displayed, press the "SET" key to accept Inches as the Units.
- 6. The display now shows duct stating that we're now in the Duct Type menu. Press the "ADJ" key to enter the Duct Type menu.
- 8. Once rEct has been displayed, press the "SET" key to accept Rectangular duct as the Duct type.
- 9. The display now shows HE LE stating that we're now in the Height Entry menu. Press the "ADJ" key to enter the Height Entry menu. The Height can now be edited one digit at a time.
- 10. To enter in 12.0 inches, press the "SET" key to accept ¹/₂ and move to the cursor to the right, press the "ADJ" Key to increment the current

digit to 1, press the "SET" key to accept 1 and move to the cursor to the right, press the "ADJ" Key twice to increment the current digit to

 \vec{c} , press the "SET" key to accept \vec{c} and move to the cursor to the

right, press the "SET" key to accept D and to finish the editing of the

Kanomax USA, Inc www.kanomax-usa.com Page 10 of 28 219 Route 206 PO Box 372 Andover, NJ 07821 USA Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

🚇 Device Manager	
<u>File Action View H</u> elp	
PRIDELAPTOP	^
🕀 🐙 Batteries	
🗈 😼 Computer	
🗈 🥪 Disk drives	
🗈 🦉 Display adapters	
🗈 🥝 DVD/CD-ROM drives	
🗉 🗃 Floppy disk controllers	
🗉 🗃 IDE ATA/ATAPI controllers	
🗈 🥪 IEEE 1394 Bus host controllers	
🗄 🦢 Keyboards	
⊞ · () Mice and other pointing devices	
🗄 🦢 Modems	
🗄 🦉 Monitors	
E B Network adapters	
표 📕 PCMCIA adapters	
Ports (COM & LPT)	
Communications Port (COM1)	
ECP Printer Port (LPT1)	
USB Serial Port (COM7)	
+ See Processors	
🕀 🧐 Sound, video and game controllers	~

You are now ready to capture the data being measured by your instrument.

Please refer to **Appendix F** – **Viewing and Capturing Data** for further instructions.

Kanomax USA, Inc www.kanomax-usa.com Page 19 of 28



APPENDIX D - USB DATA OUTPUT (IF EQUIPPED)

If the instrument is equipped with the USB Communications option, there will be a four pin male connector on the bottom of the instrument. Also, a USB cable will be included with the instrument. This cable will have a four pin female connector on one end and a USB Type-A connector on the other end.

USB Data Output – Instructions for Use

STEP 1: Install a Virtual COM Port (VCP) Driver on your computer. Free VCP drivers can be downloaded for Windows, Linux, and MAC from FTDI Ltd on their website: <u>http://www.ftdichip.com/Drivers/VCP.htm</u>

We recommend downloading the setup executable, which automatically runs and configures the drivers for you.

- STEP 2: Connect the USB cable (included) to the male connector on the bottom of your instrument. Connect the other end to a USB port on your computer.
- STEP 3: Turn the Instrument ON.
- STEP 4: Verify that the Instrument has been set up as a USB Serial Port with a unique COM port number. (You only need to do this once)

For Windows users, open the Windows Device Manager (found in Control Panel) and verify that a USB serial port exists as shown below. 219 Route 206 PO Box 372 Andover, NJ 07821 USA

Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

Duct Height. (Note: The blinking digit is the current digit for editing. To increment the current digit, the "ADJ" key can be pressed. To save the current digit and move the cursor to the right, the "SET" key can be pressed. If a digit needs to be edited again, the "SAMPLE RATE/Arrow" key can be pressed to move the cursor to the left again.)

- 11. The display now shows LEn stating that we're now in the Length Entry menu. Press the "ADJ" key to enter the Length Entry menu. The Length can now be edited one digit at a time.
- 12. To enter in 12.0 inches, press the "SET" key to accept \square and move to the cursor to the right, press the "ADJ" Key to increment the current

digit to 1, press the "SET" key to accept 1 and move to the cursor to the right, press the "ADJ" Key twice to increment the current digit to

 2° , press the "SET" key to accept 2° and move to the cursor to the

right, press the "SET" key to accept \square and to finish the editing of the Duct Length.

- 13. The display now shows donE which means that we've completed the Duct setup and are exiting Volume Duct Entry mode.
- 14. Now press the "VOLUME FLOW" Key to enter Volume Flow Mode.
- 15. A 12" x 12" Rectangular duct can now be measured for Volume Flow. (Note: To get an accurate reading, increase the sample rate to 16 Seconds by pressing the "SAMPLE RATE" key. Then slowly move the air probe around the entire duct opening to get an average reading across the duct opening. This will give a more accurate value for the volume flow rate out of the duct..)

The following page shows a graphical representation of the steps required to enter the duct dimensions into the 6812.



219 Route 206 PO Box 372 Andover, NJ 07821 USA Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com



"VOL"

"duc1" (the current duct setup being modified)



Analog Output circuit block diagram and connector pin assignment





6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc.

Kanomax USA, Inc www.kanomax-usa.com Page 17 of 28

6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 12 of 28



APPENDIX C – ANALOG VOLTAGE OUTPUTS (IF EQUIPPED)

If the instrument is equipped with the analog output option, there will be a fivepin connector on the bottom of the instrument. Also, an analog output cable will be included with the instrument. This cable will have a five-pin connector on one end and four tinned wires on the other end.

The instrument will output a Voltage between 0 and 5 Volts that corresponds to the Air Velocity measured by the instrument. The output range, pin assignments, and wire colors are given in the table below. Also shown is a block diagram of the analog output circuit.

				Corresponding	
Wire			Analog Output	Measurement	Equation* to convert from
Color	Pin #	Function	Voltage Range	Range	Volts (V) to Measurement Value
BLK	1	Ground	N/A	N/A	N/A
GRN	2	Air Velocity	0 to 5 Volts	0 to 10,000 FPM	Air Velocity = $2000 \times V$
GRY	3	Not Used	N/A	N/A	N/A
WHT	4	Not Used	N/A	N/A	N/A

*To convert from Volts to Air Velocity in Feet per Minute, multiply by 2000.

- ► For example, an analog output of 2.375 Volts means that the instrument is measuring an air velocity of 4750 feet per minute (FPM).
- ► 2.375 Volts × 2000 = 4750 FPM

Note: When using analog outputs, there is an **additional** $\pm 1\%$ error in the analog output voltage. This is in addition to the normal measurement error.

- ► For example, an air velocity reading of 500 FPM would normally have an accuracy of ±1% of reading ±1 digit (±6 FPM) when the data is viewed on the LCD display.
- ► With the additional error associated with the analog output voltage, the effective accuracy of the analog output for this air velocity measurement will be ±2% of reading ±1 digit (±11 FPM).

Custom Analog Voltage Outputs are also available - contact Kanomax for details.

Kanomax USA, Inc www.kanomax-usa.com Page 16 of 28



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com



While in Volume Flow Mode, press the FPM/MPS key to switch between units of **cubic feet per minute** (CFM) and **cubic meters per hour** (CMH). **CUBIC** will be displayed along with either **FPM** or

MPS on the LCD display to tell you what units you are in.

Note: When **CUBIC** and **MPS** are displayed on the LCD display, the reading displayed is in units of CUBIC METERS PER **HOUR**.

Kanomax USA, Inc www.kanomax-usa.com Page 13 of 28



SECTION 3 – OPERATIONAL NOTES

Caution: Do not attempt to measure flow from a duct that is smaller than the diameter of the probe head that you are using. This will cause a false reading. Follow the minimum duct cross-section guidelines as detailed below:

AP275 probe (2.75 inch):	Minimum duct width of 2.7 inches (69 cm) Minimum duct height of 2.7 inches (69 cm) Minimum duct diameter of 2.7 inches (69 cm)
AP100 probe (1.0 inch):	Minimum duct width of 1.0 inches (2.7 cm) Minimum duct height of 1.0 inches (2.7 cm) Minimum duct diameter of 1.0 inches (2.7 cm)

9009 - Out of Range Error: There are a few circumstances which will cause the instrument to display **9009**, which is the out-of-range error. They are:

- 1. **Duct dimension is too small:** If one of the user-entered duct dimensions is smaller than the probe diameter as described above, the instrument will display the out-of-range error.
- 2. **Duct cross-sectional area is too large:** If the cross-sectional area of the duct is too large, the instrument will not be able to display a meaningful result. The out-of-range error will be displayed. The maximum duct cross-sectional areas are as follows:
 - a. $35 \text{ ft}^2 (3.25 \text{ m}^2)$ when displaying in cubic feet per minute (CFM)
 - b. 20 ft² (1.86 m²) when displaying in cubic meters per hour (CMH)
- 3. Volume flow rate is too high: If the calculated volumetric flow rate is higher than 9999 cubic feet per minute (CFM) or 9999 cubic meters per hour (CMH) the result cannot be displayed by the instrument. The out-of-range error is displayed.



Phone: 1-800-247-8887 Fax: (973) 786-7586 info@kanomax-usa.com

APPENDIX A – LCD DISPLAY SYMBOLS



APPENDIX B – BATTERY REPLACEMENT



Kanomax USA, Inc www.kanomax-usa.com Page 14 of 28 6812[™] User Manual, PN 10282 Rev 1.9, 10-Jun-2008 Copyright © 2008, Kanomax USA, Inc. Kanomax USA, Inc www.kanomax-usa.com Page 15 of 28