Rosemount[™] 499ADO

Dissolved Oxygen Sensor



A robust sensor for reliably measuring dissolved oxygen

The RosemountTM 499ADO dissolved oxygen sensor is an easy to use amperometric sensor with a rugged construction. This sensor is ideal for measuring dissolved oxyten in aeration basins in municipal and industrial wastewater treatment plants.



Overview



Ease of Maintenance

- Extend sensor life with simple membrane and electrolyte replacement; no special tools required.
- Automatic temperature correction with integral Pt-100 RTD.
- Easy in-air calibration.

Versatile Installation Options

- Forward and rear facing 1 in. MNPT process connections to meet a variety of application installation requirements.
- Installs in aeration basins and sidestream samples.
- Variopol (VP6) cable connector option eliminates cable twisting and allows for quick sensor replacement.

High Performance Design

- Measures dissolved oxygen concentrations between 0 and 20 ppm.
- Operates in process temperatures up to 50 °C (122 °F).
- High accuracy of ±0.2 ppm at 25 °C (77 °F).

Contents

Ordering Information	. 3
Specifications	.4
Dimensional Drawings	. 5
Accessories	.7

Ordering Information



The Rosemount 499ADO dissolved oxygen sensor is ideal for measuring dissolved oxygen at the ppm level. Sensors can be immersed directly in aeration basins using the handrail mounting assembly or mounted in a variety of flow cells and flow through tees. The sensor is available with either an integral cable or Variopol (VP6) connector. Variopol cables are sold separately (see "Accessories"). Sensors come standard with three replacement membrane assemblies, three O-rings, and a 4 oz (125 mL) bottle of electrolyte.

Table 1. Rosemount 499ADO Dissolved Oxygen Sensor Ordering Information

Model	Sensor type		
499ADO	Dissolved Oxygen Sensor		
Transmitter compatibility			
54	For use with Rosemount 1056, 56, 1066, and 5081 transmitters		

Options

Cable options		
-	No selection - standard 25 ft cable	
60	25 ft optimum EMI/RFI cable	
VP	Variopol (VP6) connector ¹	
Typical model number: 499ADO-54-VP		

1. For use with VP interconnecting cables (see "Accessories").

Specifications Sensor Specifications

Range: 0 to 20 ppm (mg/L) as O₂. For measurements at the ppb level, choose 499ATrDO.

Wetted parts: Noryl¹, Viton², EPDM, Teflon³ (TFE), and silicone

Cathode: Gold (not normally wetted)

Accuracy: ±0.2 ppm at 25 °C (77 °F)

Repeatability: ±0.5% of reading at 25 °C (77 °F))

Response time: <20 sec to 90% of final reading (0 to 2 ppm) at 25 °C (77 °F)

Pressure: 0 to 65 psig (101 to 549 kPa abs)

Temperature: 0 to 50 °C (32 to 122 °F)

Process connection: 1 in. MNPT

Electrolyte volume: 25 mL (approx.)

Electrolyte life: 4 to 6 months (approx.)

Cable length (standard integral cable): 25 ft (7.6 m)

Cable length (maximum): 300 ft (91 m)

Sample flow:

Flow through	1 to 5 gpm (3.8 to 19 L/min)
Open channel	1 ft/sec (0.3 m/sec)
Low flow cell	2 to 5 gph (7.6 to 19 L/hr)

Agitation produced by bubbles in aeration basins usually provides adequate flow.

Weight/shipping weight: 1 lb / 3 lb (0.5 kg / 1.5 kg)

1 Noryl is a registered trademark of General Electric.

2 Viton is a registered trademark of E.I. duPont de Nemours & Co.

3 Teflon is a registered trademark of E.I. duPont de Nemours & Co.

Other Specifications

Low Flow Cell PN 24091-01

Wetted parts: Polycarbonate, polyester, 316 stainless steel, and silicone

Process connection: 1/4-in. OD tubing compression fitting or 1/4-in. FNPT

Maximum pressure: 90 psig (722 kPa abs)

Maximum temperature: 70 °C (158 °F)

Note: The temperature and pressure specifications for the low flow cell exceed the specifications for the sensor.

Flow-Through Tee (1-1/2 in. body) PN 23567-00

Wetted parts: CPVC and Buna N; body is schedule 80 CPVC. Process connection: 1-1/2 in. socket Maximum pressure: 65 psig (549 kPa abs) Maximum temperature: 50 °C (122 °F)

Flow-Through Tee (2 in. body) PN 915240-03, 04, 05

Wetted parts: CPVC and Buna N; body is schedule 80 CPVC. Process connection: 3/4 in. NFPT, 1 in. NFPT, or 1-1/2 in. NFPT Maximum pressure: 65 psig (549 kPa abs) Maximum temperature: 49 °C (120 °F)

Spray Cleaner PN 12707-00

Wetted parts: PVC, polypropylene, and 316 stainless steel

Connection for cleaning fluid: Compression fitting for 3/4 in. tubing

Valved Rotameter 9390004 for use with Low Flow Cell

Flow: 0.4 to 5 gph (1.5 to 19 L/hr)


Wetted parts: Acrylic, 316 stainless steel, and Viton

Maximum pressure: 100 psig (858 kPa abs)

Maximum temperature: 65 °C (150 °F)

Dimensional Drawings








Figure 2. Rosemount 499ADO with Variopol Cable Connection Sensor Dimensions

Figure 3. Low Flow Cell (PN 24091-00)




Figure 4. Flow-Through Tee (1-1/2 in.) (PN 23567-00)




Figure 5. Flow-Through Tee (2 in.) (PN 915240-03, -04, -05) Figure 6. Handrail Mounting Assembly (PN 11275-01)





Figure 7. Jet Spray Cleaner (PN 12707-00)



Accessories

Part number	Description
23567-00	1-1/2 in. flow through tee
914240-03	2 in. PVC flow through tee with 3/4 in. FNPT connections
914240-04	2 in. PVC flow through tee with 1 in. FNPT connections
915240-05	2 in. PVC flow through tee with 1-1/2 in. FNPT connections
23747-06	Interconnecting cable, VP 6, 2.5 ft. (0.8 m)
23747-04	Interconnecting cable, VP 6, 4 ft (1.2 m)
23747-02	Interconnecting cable, VP 6, 10 ft (3.0 m)
23747-07	Interconnecting cable, VP 6, 15 ft (4.6 m)
23747-08	Interconnecting cable, VP 6, 20 ft (6.1 m)
23747-09	Interconnecting cable, VP 6, 25 ft (7.6 m)
23747-10	Interconnecting cable, VP 6, 30 ft (9.1 m)
23747-03	Interconnecting cable, VP 6, 50 ft (15.2 m)
23747-11	Interconnecting cable, VP 6, 100 ft (30.5 m)
24091-00	Low flow cell
9390004	Rotameter: 0.5 - 5.0 gph
11275-01	Sensor handrail mounting assembly
12707-00	Jet spray cleaner
23550-00	Junction box without preamplifier
9200266	Extension cable for option -54 cable, unprepped
9200275	Extension cable for optimum EMI/RFI cable, unprepped
23747-00	Extension cable for optimum EMI/RFI cable, prepped
2001492	Stainless steel tag
23501-00	Dissolved oxygen membrane assembly: includes 1 membrane assembly and 1 O-ring.
23502-00	Dissolved oxygen membrane assembly: includes 3 membrane assemblies and 3 O-rings
9210264	Dissolved oxygen sensor fill solution, 4 oz (125 mL)
33521-02	Membrane retainer
33523-00	Fill plug

Global Headquarters

Emerson Automation Solutions 8200 Market Blvd. Chanhassen, MN 55317, USA 1 +1 800 999 9307 or +1 952 906 8888 +1 952 949 7001 Liquid.CSC@Emerson.com

Latin America Regional Office

Emerson Automation Solutions

1300 Concord Terrace, Suite 400 Sunrise, FL 33323, USA ● +1 954 846 5030 ○ +1 952846 5121 ○ RFQ.RMD-RCC@Emerson.com

Europe Regional Office

Emerson Automation Solutions Europe GmbH
Neuhofstrasse 19a P.O. Box 1046
CH 6340 Baar
Switzerland
+1 954 846 5030
+1 952846 5121
RFQ.RMD-RCC@Emerson.com

Asia Pacific Regional Office

Emerson Automation Solutions Asia Pacific Pte LTD

1 Pandan Crescent Singapore 128461 ● +65 6777 8211 ○ +65 6777 0947 ○ Enquiries@AP.Emerson.com

Middle East and Africa Regional Office

Emerson Automation Solutions

Emerson FZE P.O. Box 17033 Jebel Ali Free Zone - South 2 +971 4 8118100 +971 4 88665465 REO RMTMEA@Emerson c

RFQ.RMTMEA@Emerson.com







Linkedin.com/company/Emerson-Automation-Solutions



Twitter.com/Rosemount_News



Facebook.com/Rosemount



Youtube.com/user/RosemountMeasurement



Google.com/+RosemountMeasurement

The Emerson logo is a trademark and service mark of Emerson Electric Co.

Rosemount and Rosemount logotype are trademarks of Emerson. All other marks are the property of their respective owners. © 2017 Emerson. All rights reserved.

